



MONTEREY BOATS

415 SPORT YACHT

OWNER'S MANUAL



Dear Valued Customer,

Welcome to the Monterey Life!

We would like to extend to you our "Thank You" for choosing a Monterey boat!

You have made an investment in our product and we are confident you will enjoy many years of boating pleasure. Your new boat has been built to the standards set forth by the United States Coast Guard and National Marine Manufacturers Association. We are proud to have you in our "Family!"

At this time, we need you to read your owner's manual and become familiar with all systems on your boat. Make certain that you and your dealer have filled out and mailed your warranty registration card back to us here at the factory. It is very important to us and it is also a U.S. Federal Regulation.

This manual is an important aid in the operation and maintenance of your boat. The information is intended as a guide and cannot cover every question you may have about your boat and boating in general. We encourage you to contact your dealership for any additional information you might need. If there is a question about your boat that can't be answered by your dealer, please contact our factory direct by calling the Monterey Boats Customer Service Department, (352) 529-9181 or online if you prefer at: www.info@montereyboats.com.

If you are new to boating, we recommend you participate in a boating class or group to gain more knowledge and confidence. Contact your dealer, local U.S. Coast Guard or U.S. Power Squadron Organizations for information in your area.

With proper care, routine service and preventive maintenance, your Monterey boat will not only reward you with enjoyment, but with reliability, dependability and one of the higher resale values in today's boating industry.

Enjoy your new boat and please respect our environment at all times. Always remember to practice safe boating procedures for your protection as well as those around you.

Sincerely,

The M.O.S.T. (Monterey Owners Support Team)

Please fill out the following information section and leave it in your Monterey owner's manual. This information will be important for you and Monterey service personnel to know, if you may need to call them for technical assistance or service.

BOAT	
MODEL:	HULL SERIAL #:
PURCHASE DATE:	DELIVERY DATE:
IGNITION KEYS #:	REGISTRATION #:
DOOR KEY #:	OTHER KEYS #:
ENGINES	
MAKE:	MODEL:
PORT SERIAL #:	STARBOARD SERIAL #:
IPS DRIVES	
MAKE:	MODEL:
PORT SERIAL #:	STARBOARD SERIAL #:
RATIO:	
GENERATOR	
MAKE:	MODEL:
SERIAL #:	KILOWATTS:
PROPELLERS	
MAKE:	BLADES:
DIAMETER/PITCH:	SHAFT:
AIR CONDITIONER	
MAKE:	MODEL:
SERIAL #:	BTU OUTPUT:
DEALER	MONTEREY
NAME:	PHONE:
DEALER/PHONE:	REPRESENTATIVE:
SALESMAN:	ADDRESS:
SERVICE MANAGER:	
ADDRESS:	MONTEREY E-MAIL:
	DEALER E-MAIL:

All information, illustrations, and specifications contained in this manual are based on the latest product information available at the time of publication. Monterey Boats reserves the right to make changes at anytime, without notice, in colors, materials, equipment, specifications, and models.

HULL LENGTH OVERALL _____ 12.5 m

WEIGHT DRY _____ 9,979 kg

WEIGHT WITH WATER AND FUEL _____ 1,1950 kg

BEAM _____ 3.8 m

DEADRISE _____ 17 °

DRAFT _____ 114 cm

BRIDGE CLEARANCE WITH STANDARD OPTIONS & ARCH _____ 3.23 m

FUEL CAPACITY _____ 1249 ltr

WATER TANK CAPACITY _____ 284 ltr

WASTE TANK CAPACITY _____ 147 ltr

MAXIMUM HORSEPOWER _____ T-320 kw

MAXIMUM NUMBER OF PERSONS _____ 12

MAXIMUM PERSON WEIGHT _____ 900 kg

MAXIMUM PERSONS / GEAR WEIGHT _____ 1,500 kg

Note: Dry weight is the average weight of the base boat without options, fuel, water, waste, batteries or gear.

(For Export Only)

To be in compliance with European directives for recreational boats as published by the International Organization for Standardization (ISO) in effect at the time this boat was manufactured, we are providing the following information.

Manufacturer:

Name SEABRING MARINE INDUSTRIES, INC., d.b.a. Monterey Boats

Address 1579 SW 18th St.

Williston, FL Zip Code: 32696

Identification Numbers:

Hull Identification Number US-RGF

Intended Design Category:

- | | |
|--|---|
| <input type="checkbox"/> Ocean (Cat A) | <input type="checkbox"/> Inshore (Cat C) |
| <input checked="" type="checkbox"/> Offshore (Cat B) | <input type="checkbox"/> Sheltered Waters (Cat D) |

Weight and Maximum Capacities:

Unladen Weight - Kilograms (Pounds) MLCC = 10,160 KG (22,400 lbs)

Maximum Load - Weight- Kilograms (Pounds) MLDC = 12,850 kg / (28329 lbs)

Number of People / Load 12 People / 1500 kg

Maximum Rated Engine Horsepower - Kilowatts (Horsepower) 649 kw (870 hp)

Certifications:

Certifications & Components Covered See Declaration of Conformity

Boat cetified by IMCI (#0009) under certificate BMOHT025

All instructions given in this book are as seen from the stern looking toward the bow with starboard being to your right, and port to your left. The information and precautions listed in this manual are not all inclusive. It may be general in nature in some cases and detailed in others and is designed to provide you a basic understanding of your Monterey boat and some of the responsibilities that go along with owning/operating your boat.

The suppliers of some of the major components such as engines, pumps, and appliances, provide their own owner's manuals which have been included with your boat. You should read the information in this manual and the manuals of other suppliers completely and have a thorough understanding of all component systems and their proper operation before operating your boat.

REMEMBER - IT IS YOUR RESPONSIBILITY TO ENSURE THAT YOUR BOAT IS SAFE FOR YOU AND YOUR PASSENGERS. ALWAYS EXERCISE GOOD COMMON SENSE WHEN INSTALLING EQUIPMENT AND OPERATING THE BOAT.

Warranty and Warranty Registration Cards

The Monterey Limited Warranty Statement is included with your boat. It has been written to be clearly stated and easily understood. If you have any questions after reading the warranty, please contact the Monterey Boats Customer Service Department

Monterey, engine manufacturers, and the suppliers of major components maintain their own manufacturer's warranty and service facilities. It is important that you properly complete the warranty registration cards included with your boat and engines and mail them back to the manufacturer to register your ownership. This should be done within 15 days of the date of purchase and before the boat is put into service. A form for recording this information for your records is provided at the beginning of this manual. This information will be important for you and service personnel to know, if and when you may need service or technical information.

The boat warranty registration requires the **Hull Identification Number "HIN"** which is located on the starboard side of the transom, just below the rubrail. The engine and generator warranty registration requires the engine serial numbers. Please refer to the engine and generator owner's manual for the location of the serial numbers.

IMPORTANT:

The terms and conditions of the Monterey Boats Limited Warranty are outlined in the warranty statement included in this manual. The manufacturer will automatically honor the warranty to the original purchaser for 15 days from the date of purchase. However, during that 15 day period, owners must comply with the steps outlined in the warranty statement to validate their warranty.

All boat manufacturers are required by the Federal Boat Safety Act of 1971 to notify first time owners in the event any defect is discovered "which creates a substantial risk of personal injury to the public." ***It is essential that we have your warranty registration card complete with your name and mailing address in our files so that we can comply with the law if it should become necessary.***

Your Monterey Boats Dealer will assist you in filling in the hull number and other data required on your Registration Card. Check to see that your card is complete and signed. Detach and mail. Your Warranty Registration Card will be added to our permanent files.

Transferring the Limited Structural Warranty

For a transfer fee, MONTEREY BOATS will offer to extend a Transferable Limited Structural Hull Warranty to subsequent owners of Monterey boats. Please refer to the Monterey Limited Warranty Statement for the terms and conditions of the Transferable Limited Structural Hull Warranty and the procedure to transfer the warranty.

Product Changes

Monterey is committed to the continuous improvement of our boats. As a result, some of the equipment described in this manual or pictured in the catalog may change or no longer be available. ***All information, illustrations, and specifications contained in this manual are based on the latest product information available at the time of publication. Monterey Boats reserves the right to make changes at any time, without notice, in colors, materials, equipment, specifications, and models.*** If you have questions about the equipment on your Monterey, please contact the Monterey Boats Customer Service Department.

Service

All warranty repairs must be performed by an authorized Monterey Dealer. Should a problem develop that is related to faulty workmanship or materials, as stated in the Limited Warranty, you should contact your Monterey dealer to arrange for the necessary repair. If you are not near your

dealer or another authorized Monterey dealer or the dealer fails to remedy the cause of the problem, then contact Monterey within 15 days. ***It is the boat owner's responsibility to deliver the boat to the dealer for warranty service.***

MONTEREY BOATS LIFETIME LIMITED WARRANTY

MONTEREY BOATS warrants to the original retail purchaser of its product beginning with the 2008 models that it will repair or replace defects in materials and workmanship found to exist in its product during the applicable warranty periods defined below if purchased from an authorized MONTEREY BOATS dealer, subject to the exclusions, limitations, conditions and provisions noted below. All repairs and replacements under the following warranties will be performed by MONTEREY BOATS or an authorized MONTEREY BOATS dealer or representative selected by MONTEREY BOATS at its sole discretion.

LIFETIME LIMITED STRUCTURAL HULL AND DECK WARRANTY:

MONTEREY BOATS warrants to the original retail purchaser of its product that MONTEREY BOATS will repair or replace the fiberglass hull or deck of its product if it is found to be structurally defective in materials or workmanship for as long as the original retail purchaser owns the product. For purposes of this limited warranty: (1) a structural defect is defined as a defect that causes the hull or deck to be unsafe or unfit for use under normal operating conditions; (2) the fiberglass hull is defined as the single fiberglass molded shell and integral fiberglass structural components including stringers, transom and related structural components which are below the hull flange; and (3) the deck is defined as the single fiberglass molded shell and integral fiberglass structural components attached to the hull flange. This warranty is further subject to the exclusions, limitations, conditions and provisions noted below.

TEN-YEAR TRANSFERABLE LIMITED STRUCTURAL HULL AND DECK WARRANTY:

Beginning with the 2008 models, MONTEREY BOATS also offers a Ten-Year Transferable Limited Structural Hull and Deck Warranty. Under this warranty, MONTEREY BOATS will repair or replace the fiberglass hull or deck if it is found to be structurally defective in materials or workmanship within the first ten (10) years after the date of purchase by the original retail purchaser. For purposes of this warranty: (1) a structural defect is defined as a defect that causes the hull or deck to be unsafe or unfit for use under normal operating conditions; (2) the fiberglass hull is defined as the single fiberglass molded shell and integral fiberglass structural components including stringers, transom and related structural components which are below the hull flange; and (3) the deck is defined as the single fiberglass molded shell and integral fiberglass structural components attached to the hull flange. This warranty may be transferred to subsequent purchasers (hereinafter "new owner") provided the new owner registers the transfer and pays the transfer fee in accordance with the requirements set forth below. This transfer will only apply to the balance of any warranty period left during the ten (10) year period commencing on the date of purchase by the original retail purchaser.

1. The request for transfer must be made in writing by the new owner and sent within thirty (30) days of the date of his/her purchase of the boat to:

MONTEREY BOATS
1579 SW 18th Street
Williston, Florida 32696

2. The request must include: A copy of the bill of sale with the Hull ID number, the new owner's name and address and a Certified Check or Money Order for the correct transfer fee amount.
3. The transfer fee is \$300.00 for boats with hull lengths under 27', \$500.00 for boats with hull lengths from 27' but under 33', and \$700.00 for boats with hull lengths 33' and over.

In the event fiberglass hull or deck work is required, the new owner must return the boat to the original selling dealer or to a dealer authorized to service MONTEREY BOATS products. The cost of returning the boat to and from MONTEREY BOATS or an authorized MONTEREY BOATS dealer or representative will be the sole responsibility of the new owner. This warranty is further subject to the exclusions, limitations, conditions and provisions noted below.

FIVE-YEAR LIMITED HULL BLISTER WARRANTY:

MONTEREY BOATS warrants to the original retail purchaser of its product that MONTEREY BOATS will repair any osmotic blisters which occur on the underwater gelcoated surfaces of the hull as a result of defects in materials or workmanship within five (5) years from the date of purchase by the original retail purchaser according to the following prorated schedule provided that the original factory gelcoat surface has not been altered in any way:

1. Up to two (2) years from the date of original retail purchase, MONTEREY BOATS will pay 100% of the repair costs.
2. After two (2) years but up to three (3) years from the date of original retail purchase, MONTEREY BOATS will pay 85% of the repair costs.
3. After three (3) years but up to four (4) years from the date of original retail purchase, MONTEREY BOATS will pay 65% of the repair costs.
4. After four (4) years but up to five (5) years from the date of original retail purchase, MONTEREY BOATS will pay 35% of the repair costs.
5. After five (5) years from the date of original retail purchase, MONTEREY BOATS will pay 0% of the repair costs.

Alterations which will void this warranty include, without limitation, damage, accident repair, sanding, scraping, sandblasting, or improper surface preparation for application of a marine barrier coating or bottom paint. A marine barrier coating must be properly applied to the hull bottom if the boat is to be moored in water for periods of more than sixty (60) days in any ninety (90) day period and a marine barrier coating is also required if the boat is to be bottom painted. This warranty is further subject to the exclusions, limitations, conditions and provisions noted below.

TWO-YEAR EXTERIOR COSMETIC GELCOAT LIMITED WARRANTY:

MONTEREY BOATS warrants to the original retail purchaser of its product that MONTEREY BOATS will correct or repair any cracking, crazing or fading of, and any air voids in, the exterior gelcoat surface of the boat as result of defects in materials or workmanship within two (2) years from the date of purchase by the original retail purchaser according to the following prorated schedule provided that the original factory gelcoat surface has not been altered in any way:

1. Up to twelve (12) months from the date of original retail purchase, MONTEREY BOATS will pay 100% of the repair costs.
2. After twelve (12) months but up to fifteen (15) months from the date of original retail purchase, MONTEREY BOATS will pay 55% of the repair costs.
3. After fifteen (15) months but up to twenty-four (24) months from the date of original retail purchase, MONTEREY BOATS will pay 30% of the repair costs.
4. After twenty-four (24) months from the date of original retail purchase, MONTEREY BOATS will pay 0% of the repair costs.

Alterations which will void this warranty include, without limitation, damage, accident repair, sanding, scraping, sandblasting, improper surface preparation for application of a marine barrier coating or paint, or if damage to the exterior gelcoat surface results from or is attributable to the addition of items not installed by MONTEREY BOATS. This warranty is further subject to the exclusions, limitations, conditions and provisions noted below.

LIMITED WARRANTY FOR NON-STRUCTURAL PARTS AND COMPONENTS:

MONTEREY BOATS warrants to the original retail purchaser of its product that MONTEREY BOATS will repair or replace the following described non-structural parts and components for the reasons and during the periods indicated below measured from the date of purchase by the original retail purchaser whether or not separately warranted by the part or component manufacturer:

1. Canvas: if it fades or dry rots within five (5) years or if it is found to be defective in materials or workmanship within two (2) years.
2. Upholstery: if it is found to be defective in materials or workmanship within two (2) years.
3. All other non-structural parts and components: if they are found to be defective in materials or workmanship within one (1) year.

WHAT IS NOT COVERED:

The limited warranties set forth above do not cover:

1. Engines, outdrives, generators, air conditioners, and trim tabs;
2. Any boat that has been repaired or altered by persons other than MONTEREY BOATS or an authorized MONTEREY BOATS dealer or representative or modified in any way so as to affect its use and operation;
3. Any boat used for racing or for rental or commercial purposes or that has been subject to misuse, neglect, accident or structural modification;
4. Normal wear, tear, deterioration (including rust) of hardware, vinyl coverings, vinyl and fabric upholstery, plastic, stainless steel, other metal, wood, and trim tape.
5. Any defect caused by the failure of the owner to provide reasonable care and maintenance.
6. Installation of engines, generators, air conditioners, wake board towers, parts or other after market accessories produced, installed or attached by anyone other than MONTEREY BOATS.
7. Loss of time, inconvenience, loss of the use of the boat or other matters not specifically covered hereunder; and
8. Any boat purchased by a consumer through an authorized dealer located in the United States, which said boat is registered and/or operated outside the United States.

GENERAL PROVISIONS:

All general, special, indirect, incidental and/or consequential damages are excluded from this warranty and are totally disclaimed by MONTEREY BOATS. It is the intent of the parties that the Owner's sole and exclusive remedy is the repair or replacement of the product or its allegedly defective component parts and that no other legal or equitable remedies shall be available to said owner. Some states do not allow the exclusion of incidental or consequential damages so the inclusion of incidental or consequential damages may not apply to you. This is a limited warranty. MONTEREY BOATS makes no warranty other than contained herein. To the extent allowed by law any warranties of merchantability or fitness for a particular purpose arising in state law are expressly excluded. To the extent allowed by law, any implied warranty of merchantability is limited to the duration of the limited warranty applicable to the particular warranted part, component, or defect. All obligations of MONTEREY BOATS are specifically set forth herein. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. MONTEREY BOATS' obligation with respect to this warranty is limited to making repairs to or replacing the defective parts and no claim for breach of warranty shall be cause for cancellation or rescission of the contract or sale for any boat manufactured by MONTEREY BOATS.

MONTEREY BOATS will discharge its obligations under this warranty as rapidly as possible, but cannot guarantee any specific completion date due to the different nature of claims which may be made and services which may be required. This limited warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. No person, including a MONTEREY BOATS dealer, is authorized to make any repairs or replacements under this warranty without the prior written approval of MONTEREY BOATS. MONTEREY BOATS shall in no way be responsible for any repairs not Pre-Authorized by a MONTEREY BOATS Customer Service Manager or repairs performed by a repair shop not Pre-Authorized by a MONTEREY BOATS Customer Service Manager.

MONTEREY BOATS does not authorize any person to create or assume for it any other obligation or liability with respect to its products. The sales personnel or other employees of MONTEREY BOATS dealers are not authorized to make warranties concerning MONTEREY BOATS products. No brochure, pamphlet or other written or pictorial presentation constitutes a warranty or representation as to any aspect of MONTEREY BOATS products.

MONTEREY BOATS shall have no obligation under this Lifetime Limited Warranty unless and until each of the following conditions are met:

1. The original retail purchaser of its product or the MONTEREY BOATS dealer either completes and returns the Warranty Registration to MONTEREY BOATS by mail or facsimile or the MONTEREY BOATS dealer registers the Warranty electronically "online" within fifteen (15) days from the date the product is delivered to the original retail purchaser;
2. Notice of each warranty claim is given to the MONTEREY BOATS dealer within a reasonable period of time after discovery of any claimed defect;
3. Notice of each warranty claim is made in writing to MONTEREY BOATS within the applicable time periods identified in the respective warranties as measured from the date of purchase by the original retail purchaser; and
4. All transportation charges incurred in transporting the boat for warranty work are paid for by the owner.




MONTEREY BOATS reserves the right to make changes at any time, without notice, in prices or to make changes in design, colors, specifications, equipment, options, materials, etc., and MONTEREY BOATS shall be under no obligation to equip or modify product built prior to such changes.

IMPORTANT: Proper registration of the Warranty with MONTEREY BOATS is important for purposes of recording customer information for notification and correction of product defects under the Federal Boat Safety Act.

MONTEREY BOATS is the registered tradename and trademark of SEABRING MARINE INDUSTRIES, INC., a Florida corporation, the warrantor herein.

SEABRING MARINE INDUSTRIES, INC.
d.b.a. MONTEREY BOATS
1579 SW 18th Street – Williston, Florida 32696
Telephone (352) 528-2628 / Facsimile (352) 529-2628

Your Monterey owner's manual has been written to include a number of safety instructions to assure the safe operation and maintenance of your boat. These instructions are in the form of **DANGER**, **WARNING**, and **CAUTION** statements. The following definitions apply:



All instructions given in this book are as seen from the stern looking toward the bow, with starboard being to your right, and port to your left. A glossary of boating terms is included.

IMPORTANT NOTE: Your boat uses internal combustion engines and flammable fuel. Every precaution has been taken by Monterey to reduce the risks associated with possible injury and damage from fire or explosion, but your own precaution and good maintenance procedures are necessary in order to enjoy safe operation of your boat.

Registration and Numbering

Federal law requires that all undocumented vessels equipped with propulsion machinery be registered in the State of principal use. A certificate of number will be issued upon registering the boat. These numbers must be displayed on your boat. The owner/operator of a boat must carry a valid certificate of number whenever the boat is in use. When moved to a new State of principal use, the certificate is valid for 60 days.

In order to be valid, the numbers must be installed to the proper specifications. Check with your dealer or state boating authority for numbering requirements. The Coast Guard issues the certificate of number in Alaska; all others are issued by the state.

Insurance

In most States the boat owner is legally responsible for damages or injuries he or someone else operating the boat causes. Responsible boaters carry adequate liability and property damage insurance for their boat. You should also protect the boat against physical damage and theft. Some States have laws requiring minimum insurance coverage. Contact your dealer or state boating authority for information on the insurance requirements in your boating area.

Reporting Boating accidents

All boating accidents must be reported by the operator or owner of the boat to the proper marine law enforcement authority for the state in which the accident occurred. Immediate notification is required if a person dies or disappears as a result of a recreational boating accident.

If a person dies or there are injuries requiring more than first aid, a formal report must be filed within 48 hours.

A formal report must be made within 10 days for accidents involving more than \$500.00 damage or the complete loss of a boat.

A Boating Accident Report form is located near the back of this manual to assist you in reporting an accident. If you need additional information

regarding accident reporting, please call the Boating Safety Hotline, 800-368-5647.

Education

If you are not an experienced boater, we recommend that the boat operator and other people that normally accompany the operator, enroll in a boating safety course. Organizations such as the U.S. Power Squadrons, United States Coast Guard Auxiliary, State Boating Authorities and the American Red Cross offer excellent boating educational programs. These courses are worthwhile even for experienced boaters to sharpen your skills or bring you up to date on current rules and regulations. They can also help in providing local navigational information when moving to a new boating area. Contact your dealer, State Boating Authority or the Boating Safety Hotline, 800-368-5647 for further information on boating safety courses.

Required Equipment

U.S. Coast Guard regulations require certain equipment on each boat. The Coast Guard also sets minimum safety standards for vessels and associated equipment. To meet these standards some of the equipment must be Coast Guard approved. "Coast Guard Approved Equipment" has been determined to be in compliance with USCG specifications and regulations relating to performance, construction, or materials. The equipment requirements vary according to the length, type of boat, and the propulsion system. Some of the Coast Guard equipment is described in the Safety Equipment chapter of this manual. For a more detailed description, obtain "Federal Requirements And Safety Tips For Recreational Boats" by contacting the Boating Safety Hotline 800-368-5647 or your local marine dealer or retailer.

Some state and local agencies impose similar equipment requirements on waters that do not fall under Coast Guard jurisdiction. These agencies may also require additional equipment that is not required by the Coast Guard. Your dealer or local boating authority can provide you with additional information for the equipment requirements for your boating area.

Your Monterey boat is inspected at each step of the manufacturing process. Before leaving the factory, every Monterey boat undergoes a thorough check for systems operation, fit and finish. Your Monterey Dealer also performs a Pre-Delivery inspection prior to final delivery. When the new boat is delivered to you, the customer, a final check is performed during orientation. Both the Pre-Delivery and Final Delivery inspections are documented to ensure trouble free operation and returned to Monterey Boats.

At the time of new boat delivery, your Monterey Dealer will ask you to sign the completed Inspection Report at the same time as the Warranty Registrations for the boat and other accessory equipment. By signing these documents, you acknowledge that you have reviewed and understand all information.

WARRANTY REGISTRATION AND NEW BOAT CHECKLIST		 MONTEREY BOATS	
SUPER SPORT & CRUISER			
Boat Number (HIN): RGF _____ Selling Dealer: _____ Engine Brand: _____ Engine Serial #1: _____ Engine Serial #2: _____ Date of Sale: _____ Owner Name (Last, F. Init): _____ Address: _____ City: _____ State: _____ Zip: _____ E-Mail Address: _____ Phone: _____ 2nd Phone: _____	Boat Model: _____ Dealer Code: _____ Engine Model: _____ Drive Serial #1: _____ Drive Serial #2: _____ Warranty Start Date: _____	1579 S.W. 18 th Street Williston, FL 32696 Tel 352-929-9191 Fax 888-922-6267 www.montereyboats.com	
PLEASE, INSPECT AND CHECK OFF THE FOLLOWING OPERATIONS			
Indicate Status with the following Key: ? or 1 - OK, 2 - Needs Correction, 3- Completed, N/A - Not Applicable			
<div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p style="text-align: center; margin-top: 0;">BOAT</p> <p>_____ Boat gel coat, striping & graphics</p> <p>_____ upholstery fit, clean and free of defects</p> <p>_____ Sundeck/Sun Island/lounger operation</p> <p>_____ Canvas fit, clean and free of defects</p> <p>_____ Cabin Doors, port lights, hatches, cabinet & head doors, latches</p> <p>_____ All thru-hull fittings, ball valves, head drain, galley drain, anchor well drain, drain plug - hull, wet bar drain are secure, no leaks</p> <p>_____ Windshield fit</p> <p>_____ Ladders</p> <p style="text-align: center; margin-top: 10px;">EQUIPMENT</p> <p>_____ Running Lights (Navigation)</p> <p>_____ Cabin lights, cockpit lights</p> <p>_____ Toilet (Head) operation & hoses</p> <p>_____ Stereo - Radio, CD, remote control</p> <p>_____ Bilge Pumps - Auto float switch</p> <p>_____ Air Conditioner/Heater - operation & components secure</p> <p>_____ Water pressure system (let pressure stand 15 minutes to see if pump goes on) & heater</p> <p>_____ Stove, coffee maker, oven, refrigerator, ice maker</p> <p>_____ Generator - Operation & components secure</p> <p>_____ Bilge Blower(s)</p> <p>_____ Wipers</p> <p>_____ Shore power (AC)</p> <p>_____ Tables</p> <p>_____ Plumbing Hose Clamps</p> <p>_____ Battery - Polarity, Voltage, Tight Connections</p> <p>_____ Battery Switch(es) - Operation</p> <p style="text-align: center; margin-top: 10px;">ENGINE - BEFORE STARTING</p> <p>_____ Engine mounts - tight</p> <p>_____ Fuel system operation - no leaks</p> <p>_____ Engine compartment components not missing, disconnected, loose, kinked, pinched or could chafe</p> <p>_____ Hose clamps on engine & exhaust</p> <p>_____ Steering system operation, components secure, steering wheel straight</p> <p>_____ Drains cooling system closed (Closed cooling coolant level)</p> <p>_____ Throttle control, operation & adjustment</p> <p>_____ Shifter control, operation & adjustment</p> <p>_____ Stern drive oil level at full mark</p> <p>_____ Crankcase & power steering oil levels at full mark</p> <p>_____ Stern drive trim operation</p> <p>_____ Prop Size:</p> <p>_____ Prop installed correctly with grease, nut(s), cotter pins</p> <p>_____ Prop rotation - Forward & Reverse</p> <p>_____ Neutral start switch, engine will not start in gear</p> <p>_____ Transom plate seal has no leaks - water, oil</p> </div> <div style="width: 48%;"> <p style="text-align: center; margin-top: 0;">ENGINE - AFTER STARTING: (in water)</p> <p>_____ Oil pressure</p> <p>_____ Fuel line connectors - no leaks</p> <p>_____ Engine has no water or oil leaks</p> <p>_____ Idle speed per engine specs, in gear</p> <p>_____ Ignition timing check with timing light or scan tool</p> <p>_____ Gear shift works properly - forward, neutral, reverse</p> <p>_____ Instruments read correctly</p> <p>_____ Exhaust system - no leaks</p> <p style="text-align: center; margin-top: 10px;">SEA TRIAL</p> <p>_____ Boat performance</p> <p>_____ Port engine operation</p> <p>_____ Starboard engine operation</p> <p>_____ Steering - operation</p> <p>_____ Stern drive trim operation</p> <p>_____ Instruments register normal</p> <p>_____ Maximum R.P.M. _____</p> </div> </div>			
<div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>Technical Check Performed by _____</p> <p>Technician _____ Date _____</p> </div> <div style="width: 48%;"> <p style="text-align: center; margin-top: 0;">PRE-DELIVERY FINAL CHECK</p> <p>_____ All accessory equipment operates (Mech. & Elect.)</p> <p>_____ Carpets, curtains, cushions & canvas installed</p> <p>_____ All boat, engine and accessory literature re</p> <p>_____ Boat properly cleaned, interior and exterior</p> <p>_____ Trailer wiring, wheels, fenders & brakes</p> <p style="text-align: center; margin-top: 10px;">OWNER ORIENTATION</p> <p>_____ Review & familiarize Owner with operation of all features and options on boat</p> <p>_____ Sea Trial with Owner</p> <p>_____ Review of Owners Manual</p> <p>_____ Review of Warranties</p> <p>_____ Review of Owner Responsibilities</p> <p>_____ Review of Service & Maintenance Procedures</p> <p>_____ Review of Care & Cleaning</p> </div> </div>			
<div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>Owner Orientation Performed by _____</p> <p>Dealer Personnel _____ Date _____</p> </div> <div style="width: 48%;"> <p style="text-align: center; margin-top: 0;">COMMENTS</p> <p>_____</p> <p>_____</p> </div> </div>			
<div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p><i>I have read and agree with the checklist. I have read and understand the Monterey Boats Lifetime Limited Warranty as it appears on the back of this form.</i></p> <p>Owner Signature _____</p> </div> <div style="width: 48%;"> <p>Date _____</p> </div> </div>			

WELCOME	3
BOAT INFORMATION	4
SPECIFICATIONS.....	5
CERTIFICATIONS & SPECIFICATIONS.....	6
INTRODUCTION & IMPORTANT INFORMATION	7
WARRANTY.....	9
MONTEREY BOATS LIFETIME LIMITED WARRANTY.....	9
SAFETY INFORMATION	12
OWNER'S / OPERATOR'S INFORMATION	13
NEW BOAT DELIVERY.....	14

Chapter 1:

PROPULSION SYSTEM

1.1 General.....	19
1.2 Drive Systems.....	19
1.3 Engine Exhaust System.....	19
1.4 Engine Cooling System.....	20
1.5 Propellers.....	20
1.6 Performance Issues and Propellers.....	20
1.7 Engine and Helm Instrumentation	21

Chapter 2:

HELM CONTROL SYSTEMS

2.1 General.....	25
2.2 Engine Throttle and Shift Controls	25
2.3 Steering System.....	26
2.4 Trim Tabs	27
2.5 Control Systems Maintenance	28

Chapter 3:

FUEL SYSTEM

3.1 General.....	31
3.2 Diesel Engine Fuel System	32
3.3 Generator Fuel System.....	33
3.4 Fueling Instructions.....	34
3.5 Fuel System Maintenance.....	35

Chapter 4:

ELECTRICAL SYSTEM

4.1 General.....	37
4.2 12-Volt System.....	37
4.3 120-Volt System	47
4.4 Generator	52
4.5 Bonding System.....	53
4.6 Electrical System Maintenance.....	53
4.7 AC Line Load Estimator	55

Chapter 5:

FRESH WATER SYSTEM

5.1 General	57
5.2 Fresh Water System Operation	57
5.3 Water Heater	58
5.4 Shore Water Connection	58
5.5 Shower Operation	59
5.6 Fresh Water System Maintenance	59

Chapter 6:

RAW WATER SYSTEM

6.1 General	61
6.2 Air Conditioning	61
6.3 Raw Water System Maintenance	62

Chapter 7:

DRAINAGE SYSTEMS

7.1 General	63
7.2 Bilge Drainage	63
7.3 Cockpit and Deck Drains	64
7.4 Cabin Drains	65
7.5 Drainage System Maintenance	65

Chapter 8:

VENTILATION SYSTEM

8.1 Cabin Ventilation	67
8.2 Windshield Ventilation	68
8.3 Carbon Monoxide and Proper Ventilation	68
8.4 Engine Compartment Ventilation	69
8.5 Maintenance	70

Chapter 9:

EXTERIOR EQUIPMENT

9.1 Deck	71
9.3 Cockpit	76
9.4 Hardtop and Enclosure	81

Chapter 10:

INTERIOR EQUIPMENT

10.1 Head Compartments and Marine Toilets	83
10.2 Galley and Sink	86
10.3 Main Salon	88
10.4 Air Conditioners	90
10.5 Master Stateroom	91
10.6 Aft Stateroom	92
10.7 Entertainment System	93
10.8 Cabin Floors and Woodwork	95

Chapter 11:

SAFETY EQUIPMENT

11.1 General.....	97
11.2 Engine Alarms.....	97
11.3 Neutral Safety Switch.....	97
11.4 Required Safety Equipment.....	98
11.5 Automatic Fire Extinguishing System.....	99
11.6 Carbon Monoxide Monitoring System.....	101
11.7 First Aid.....	102
11.8 Additional Safety Equipment.....	102
11.9 Caution and Warning Labels.....	103

Chapter 12:

OPERATION

12.1 General.....	105
12.2 Rules of the Road.....	105
12.3 Pre-Cruise Check.....	108
12.4 Operating Your Boat.....	109
12.5 Docking, Anchoring and Mooring.....	110
12.6 Controls, Steering, or Propulsion System Failure:.....	112
12.7 Collision.....	112
12.8 Grounding, Towing and Rendering Assistance.....	112
12.9 Flooding or Capsizing.....	113
12.10 Fishing.....	113
12.11 Man Overboard.....	113
12.12 Trash Disposal.....	114
12.13 Transporting Your Boat.....	114

Chapter 13:

ROUTINE MAINTENANCE

13.1 Exterior Hull and Deck.....	115
13.2 Upholstery, Canvas and Enclosures.....	119
13.3 Cabin Interior.....	124
13.4 Bilge and Engine Compartment.....	125
13.5 Drainage System.....	125

Chapter 14:

SEASONAL MAINTENANCE

14.1 Lay-up and Storage.....	127
14.2 Winterizing.....	129
14.3 Recommissioning.....	131

Appendix A:

GENERAL MAINTENANCE SCHEDULE AND LOG.....	133
---	-----

Appendix B:

FLOAT PLAN.....	137
-----------------	-----

Appendix C:
BOATING ACCIDENT REPORT..... 139

Appendix D:
GLOSSARY OF TERMS..... 143

Appendix E:
TROUBLESHOOTING GUIDE..... 149

PROPULSION SYSTEM

1.1 General

The Monterey 415 Sport Yacht is designed to be powered with Volvo's Inboard Power System (IPS) and diesel engines. Volvo provides an owner's information manual with its product. It is important that you read the manual(s) very carefully and become familiar with the proper care and operation of the engine and drive system. A warranty registration card has been furnished with each new engine and can be located in the engine owner's manual. All information requested on this card should be filled out completely by the dealer and purchaser and then returned to the respective engine manufacturer as soon as possible.



Volvo Diesel Engine and IPS Drive System



CERTAIN MOVING PARTS ARE EXPOSED AND CAN PROVE DANGEROUS TO SOMEONE UNFAMILIAR WITH THE OPERATION AND FUNCTION OF THE EQUIPMENT. DO NOT ATTEMPT TO SERVICE ANY ENGINE OR DRIVE COMPONENT WITHOUT BEING TOTALLY FAMILIAR WITH THE SAFE AND PROPER SERVICE PROCEDURES.

1.2 Drive Systems

The inboard engines are mounted in the stern and coupled to the IPS drives which do all shifting, steering, and propulsion functions. The IPS drives are supplied by Volvo and have specific lubrication and maintenance requirements.

Proper engine alignment is very important. This was done by the factory when the engines were installed and should not be required again unless the an engine is removed, a drive is damaged or an engine mount becomes loose. If you experience excessive vibrations or suspect that the engine is out of alignment, please contact your Monterey dealer.

Marine growth and galvanic corrosion is a concern if the boat is to be kept in the water. Marine growth occurs when components are left in the water for extended periods and can cause poor performance or permanent damage to the exposed components. The type of growth and how quickly it occurs is relative to the water conditions in your boating area. Water temperature, pollution, current, etc. can have an effect on marine growth. If the boat is to be left in saltwater, the hull and drive system must be protected with antifouling

paint. It is extremely important that the proper antifouling paint is used on each component. Contact your Monterey dealer for information on the proper paint to use in your area.

Galvanic corrosion is the corrosion process occurring when different metals are submerged in an electrolyte. Sea water is an electrolyte and submerged IPS components must be properly protected. The drives are connected to sacrificial anodes, mounted on the transom below the waterline, that prevent galvanic corrosion problems. The anodes must be monitored and replaced as necessary. For recommendations regarding corrosion protection for the IPS system, please refer to the engine owner's manual.



MANY ANTIFOULING PAINTS DESIGNED FOR BOAT HULLS CAN CAUSE SEVERE DAMAGE TO THE IPS DRIVE IF THEY ARE NOT PROPERLY APPLIED. PROPER PAINT SELECTION AND PROCEDURES MUST BE FOLLOWED WHEN PAINTING THE IPS DRIVE. CONTACT YOUR MONTEREY DEALER OR ENGINE MANUFACTURER FOR INFORMATION ON THE PROPER PAINTING PROCEDURES.

1.3 Engine Exhaust System

Inboard engines use the exhaust system to expel exhaust gases and cooling water. Engine exhaust exits the bottom of the boat through the IPS drive system. The system consists of engine exhaust manifolds, exhaust hoses and the IPS drive.

A periodic inspection of the coolant hoses, exhaust hoses and related parts should be made to ensure that leaks, heat deterioration or damage has not resulted. Replace them as necessary. Refer to the engine owner's manual for more information on the exhaust system in your Monterey.



DO NOT INHALE EXHAUST FUMES! EXHAUST CONTAINS CARBON MONOXIDE THAT IS COLORLESS AND ODORLESS. CARBON MONOXIDE IS A DANGEROUS GAS THAT IS POTENTIALLY LETHAL.



A RUPTURED COOLING OR EXHAUST HOSE CAN CAUSE SEVERE ENGINE DAMAGE OR ALLOW A LARGE AMOUNT OF WATER TO FLOW INTO THE BILGE. SHOULD AN ENGINE INTAKE, EXHAUST OR COOLING HOSE RUPTURE, TURN THE ENGINE OFF IMMEDIATELY. PROCEED UNDER TOW IF NECESSARY, TO A SERVICE FACILITY FOR APPROPRIATE REPAIRS. MAINTAIN A CLOSE VISUAL WATCH ON THE PROBLEM HOSE AND THE BILGE WATER LEVEL.

1.4 Engine Cooling System

All marine engines use surface water as a cooling medium. The cooling water enters the system through a water intake in the IPS drive and is expelled through the exhaust system. Water is pumped through the water inlets, circulated through the heat exchanger, and relinquished with the exhaust gases through the IPS drive. The water pump uses a small impeller made of synthetic rubber. The impeller and water pump cannot run dry for more than a few seconds.



RUNNING THE ENGINE WITHOUT WATER FLOWING TO THE WATER PUMP CAN CAUSE SERIOUS DAMAGE TO THE WATER PUMP IMPELLER OR ENGINE. NEVER RUN THE MOTOR WITHOUT WATER FLOWING TO THE WATER PUMP.

Fresh Water Cooling

Installation of a "Fresh Water" or Closed" cooling system that is cooled by a heat exchanger and the seawater cooling system provides adequate engine cooling without exposing the internal engine cooling components to the harmful effects of surface water. This system is standard with all diesel engines on the 415 Sport Yacht. The engine owner's manual provides additional information regarding service and maintenance of this equipment.

1.5 Propellers

The drive unit uses dual, counter rotating propellers that convert the engine's power into thrust. They come in a variety of styles, diameters and pitches. Pitch is the theoretical distance traveled by the propeller in each revolution.

The propellers that will best suit the needs of your boat will depend somewhat on your application and expected average load. Propeller sizes are identified by a number or code stamped on the prop. Always repair or replace a propeller immediately if it has been damaged. A damaged and therefore out of balance propeller can cause vibration that can be felt in the boat and could damage the drive gear assembly.

Please refer to the engine owner's manual for specific information on propellers and the proper installation procedure.

1.6 Performance Issues and Propellers

It is extremely important that the boat is propped to run at or very near the recommended top RPM with an average load. If the top RPM is above or below the recommended range, the propellers must be changed to prevent loss of performance and possible engine damage.

Diesel and gas engines can be damaged and the warranty voided if the boat is not propped correctly. Always consult your Monterey or authorized engine service dealer when making changes to the propellers or if the boat does not run near the top recommended RPM.

Your boat was shipped with propellers that typically provide optimum performance for your boat. However there are factors that can affect performance and propeller requirements.

Note: Before changing propellers to correct boat performance problems, be sure other factors such as engine tuning, bottom and running gear growth, etc. are not the source of performance changes. Always be sure the load conditions are those normally experienced before changing propellers.

- The addition of heavy equipment like life rafts, personal water craft, additional coolers, etc., will cause additional load on the engines. Consequently, different propellers may be required.
- If the boat ran in the required RPM range when it was new and you have not added any additional gear or heavy equipment and have not damaged the propellers, there is a good chance the propellers are not the problem.
- Boats operated at high altitudes (above 2000 feet). Engines operated at high altitudes will not be able to develop as much horse power as they do at or near sea level. Consequently, different propellers may be required.



Typical IPS Propellers



Engine Gauge Panel

1.7 Engine and Helm Instrumentation

The helm station is equipped with a set of engine instruments, alarms and warning lamps. These instruments allow the pilot to monitor the engine operational conditions. Close observation of these instruments allows the pilot to operate the engines at the most efficient level and could save the engines from serious costly damage. The instrumentation is unique to the type of inboard motors installed on your Monterey. Some or all of the following gauges and instruments may be present.

Tachometer

The tachometer displays the speed of the engine in revolutions per minute (RPM). This speed is not the boat speed nor necessarily the speed of the propellers. The tachometer may not register zero with the key in the "OFF" position.



MAINTAINING MAXIMUM, OR CLOSE TO MAXIMUM RPM FOR EXTENDED PERIODS CAN REDUCE THE LIFE OF THE ENGINE. NEVER EXCEED THE MAXIMUM RECOMMENDED OPERATION RPM OF THE ENGINE.

Temperature Gauge

The temperature gauge indicates the temperature of the engine cooling system. A sudden increase in the temperature could signal a blocked cooling passage or a water pump malfunction



CONTINUED OPERATION OF AN OVERHEATED ENGINE CAN RESULT IN ENGINE SEIZURE. IF AN UNUSUALLY HIGH TEMPERATURE READING OCCURS, SHUT THE ENGINE OFF IMMEDIATELY. THEN INVESTIGATE AND CORRECT THE PROBLEM.

Oil Pressure Gauge

The oil pressure gauge monitors the engine lubrication system pressure. The oil pressure indicated when the engine is new is usually the reference for normal oil pressure for that engine. A drop in oil pressure is a possible indication of oil pump problems, a leak or fuel diluted oil.

Fuel Gauge

The fuel gauge indicates the amount of fuel in the fuel tank. This gauge is merely a relative indication of the available fuel supply and not a calibrated instrument.

Voltmeter

The voltmeter displays the voltage for the battery and the charging system. The normal voltage is 11 to 12.5 volts with the engines off, and 13 to 14.5 volts with the engine running.

Hour Meter

The hour meter keeps a record of the operating time for the engine. The hour meters are located in the in the tachometers or multi-meters on most installations.

BI Data Gauge

The depth gauge indicates the depth of the water below the bottom of the boat, the boat speed, and water temperature.

Fuel Management

A fuel management system is part of the Volvo EVC engine monitoring system. It is used to monitor the gallons per hour and/or total gallons used. Please refer to the engine manual for information on that system.

Engine Alarm and Warning Lamp Display


Each inboard engine is equipped with an audible alarm and a display that monitors selected critical engine systems. The system monitors oil pressure, coolant temperature, the engine battery charging system and the fuel system. The alarm will sound and/or a warning lamp will light if one of these systems begins to fail.

The warning lamps will light when the key switch is turned to the run position before the engine is started. This enables the operator to ensure that the lamps are functioning properly. When the engine starts all lamps should go out and remain out during normal operation.

If an engine alarm sounds and/or a warning lamp lights, immediately shut off the engine until the problem is found and corrected. Refer to the engine owner's manual for information on the alarms and warning lamps installed with your engines.

Volvo Penta EVC Display

The Volvo Penta electronic engine monitoring system is standard with Volvo IPS engines. The system monitors all of your engine functions on one instrument at the touch of a button. Engine speed, coolant temperature, battery voltage and boost pressure can be monitored in analog or digital display in 8 different languages. In addition to monitoring basic engine information, you



Volvo EDC Display

can switch modes to monitor current or average fuel consumption.

The display can also communicate with the navigation system in the boat to provide boat speed and miles per gallon from data received from the GPS or fish finder log. The type of navigation equipment you have installed in your boat will determine the functions available. Refer to the Volvo engine and EVC display owner's manuals for more information on the Volvo electronic engine monitoring system.

High Water Alarm

Your boat is equipped with an audible high water alarm system. The alarm will sound if water in the bilge rises high enough to activate the alarm switch.

The automatic switch for the alarm is mounted significantly higher than the automatic float switches for the bilge pumps. Therefore, immediate action should be taken to find and correct the problem if the alarm sounds. It could be that the automatic bilge pump system has failed or is being overcome by incoming water from a loose or broken hose, a loose thru-hull fitting, a defective or damaged IPS drive component or damage to the hull.

Compass

The compass is on top of the console. To adjust the compass for your area, read the instructions on "Compass Compensation" given to you in the literature packet. The compass cannot be adjusted accurately at the factory because it must be compensated for the influence of the electrical equipment and electronics unique to your boat. Therefore, the compass should be adjusted by a professional after the electronics are installed and before operating the boat.

Instrument Maintenance

Electrical protection for the engine instruments and ignition circuitry is provided by circuit breakers located on the engines. The navigational electronics are protected by the electronics breaker in helm breaker panel. The ignition switch and instrument wire connectors should be sprayed periodically with a contact cleaner/lubricant. The ignition switch and all instruments, controls, etc. should be protected from the weather when not in use. Excessive exposure can lead to gauge and ignition switch difficulties.



Compass

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

HELM CONTROL SYSTEMS

2.1 General

The helm controls consist of three systems: the engine throttle and shift controls, the steering system, and the trim tab control switches. These systems provide the operator with the ability to control the direction and attitude of the boat from the helm station.

The engine manufacturer supplies the control systems for the Volvo IPS drives and provides owner's manuals with its product. It is important that you read the manuals and become familiar with the proper care and operation of the control systems.

2.2 Engine Throttle and Shift Controls

The shift and throttle controls on your boat may vary slightly depending on the engines used. The following description is typical of most electronic IPS remote controls. Refer to the engine or control manual for specific information on the controls installed on your boat.

Electronic Engine Controls

Electronic engine controls are standard on the Volvo IPS drives. The following control description is typical of most electronic control installations.

The helm is designed for a binnacle style control with a single lever for each engine. The electronic control system consists of three major components: the electronic control head, an EVC (Electronic Vessel Control) keypad, the control processors and applicable harnesses. The controls are completely electronic and there are no cables.

Movement of the helm control arm sends a signal to the control processor, located in the engine compartment that operates the engine throttle and transmission control lever. The controls have a single lever for each engine that operates as a gearshift and a throttle. General operation will include a position for neutral (straight up and down or slightly aft of vertical), a forward position (the 1st detent forward of neutral), and a reverse position (the 1st detent aft of neutral). Advancing the control lever beyond the shift range advances the throttle in forward or reverse. Each control is equipped with a means of permitting the engine to be operated at a higher than idle RPM while in



Volvo Engine Controls and Control Head



Electronic Vessel Control (EVC)

neutral for cold starting and warm-up purposes. The control levers are equipped with adjustable control head detent and friction settings.

The EVC key pad has integrated switches and indicator lights which allow the operator to control all aspects of the boat's propulsion system. The throttle and shift control must be activated by the key pad before the engines will start. LED lights on the control pad indicate that the control is activated and the engines can be started. The most common features activated or monitored by the keypad are:

- Starter lockout, which prevents the engine from being started in gear.
- Gear lockout, which allows the engine RPM to be advanced in neutral safely.
- Battery voltage warning indicator that warns the operator of high or low voltage supplied to the system (audible alarm)
- An engine synchronization feature that automatically keeps both engines at the same RPM while cruising. Refer to Engine Synchronizing in this section for more information regarding engine synchronization.

These features and others not mentioned require specific procedures to activate and operate them properly. Some of the procedures and features are unique to the engines and other options installed on your boat. It is essential that you read the owner's manual for the controls and be completely familiar with their operation before using your boat.



ALWAYS RETURN THE ENGINE THROTTLE LEVER TO THE EXTREME LOW SPEED POSITION BEFORE SHIFTING. NEVER SHIFT THE UNIT WHILE ENGINE SPEED IS ABOVE IDLE RPM.

Engine Synchronizer

During most operations of a twin engine boat, it is advantageous for both engines to be operated at the same RPM. This reduces noise, and vibration, and can increase engine efficiency. Setting the throttles so that the engines are running the same RPM (synchronized) can be done by listening to the engine sounds at low RPM, and with the auto-

matic synchronizer feature built into the electronic engine controls when the engines are operating above 800 RPM. Attempting to synchronize the engines solely by using the tachometer readings or control lever placement generally will not work. When the engines are in proper synchronization, the throttle levers may not necessarily be even.

Please refer to the engine or control owner's manual for more information on the engine synchronizer and other features for the electronic controls installed on your boat.



IN SOME SITUATIONS, IT MAY BE POSSIBLE TO ACCIDENTALLY START THE ENGINES IN GEAR WITH THE THROTTLES ABOVE IDLE IF THE NEUTRAL SAFETY SWITCHES ARE NOT OPERATING PROPERLY. THIS WOULD CAUSE THE BOAT TO ACCELERATE UNEXPECTEDLY IN FORWARD OR REVERSE AND COULD RESULT IN LOSS OF CONTROL, DAMAGE TO THE BOAT, OR INJURY TO PASSENGERS. ALWAYS TEST EACH NEUTRAL SAFETY SWITCH PERIODICALLY AND CORRECT ANY PROBLEMS BEFORE USING THE BOAT.

2.3 Steering System

IPS Electronic Steering System

Your Monterey is equipped with an electronic steering system that is supplied with the IPS engine package that provides precise and responsive steering. The system is 100% electronic and there are no mechanical connections between the steering wheel and the drives. Each drive unit is turned independently by an electric servo controller and motor located on the drive allowing improved tight quarter maneuvering and the addition of a Joy stick at the helm.

For safety and improved tight quarter maneuvering, the controlling software senses the engine speed and adjusts the maximum steering angle to preset limits as the engine speed increases or decreases. A friction brake built into the helm steering wheel adds resistance as the boat speed increases to provide additional safety and a more natural feel to the helm. The steering angles and steering wheel resistance at specific engine speeds are programed into the system at the factory and are not adjustable.

The steering on each drive is totally independent with full redundancy built into the system. If the steering fails on one drive unit, the other will continue to operate. Should a failure in one

steering system occur, the controlling software will sense the failure and limit the engine RPM as a safety precaution. The failed unit can and should be manually turned to the straight ahead position for improved handling while steering the boat with only one drive. You should refer to the engine and steering system owner's manuals for detailed information on the operation of the steering system and instructions on manually turning the drive if it should become necessary.

Helm and Steering wheel

The steering wheel can be tilted to five different positions by activating the tilt lock lever located on the bottom side of the helm. When the lever is released, it automatically locks the steering wheel at or close to that angle.



Steering Wheel Tilt Adjustment Lever

Joystick

The joystick can only be used at slow speeds and is engaged by moving the shift and throttle controls to the neutral position and pressing the on/off button on the base of the joy stick control. Once activated, the boat moves in the direction the joystick is pushed with the engine speed increasing the harder the stick is pushed, up to preset limits. Turning the knob on the top of the joystick rotates the boat in the direction the knob is turned. Another button on the joystick raises the preset engine speed for maneuvering in high winds and/or strong tides.

When the joystick is released, it automatically returns to center, the drives shift to neutral, rotate to the straight ahead position, and the engine speed is reduced to idle. It is deactivated by pressing the on/off button at the base of the joystick or moving the shift and throttle control levers.

Refer to the engine, steering system and joystick owner's manuals for specific information on the operation and maintenance for the steering system.



Joystick

2.4 Trim Tabs

The trim tabs are mounted to the hull on the transom below the swim platform. A push button switch panel with an LED display in the helm is used to control the trim tabs. The switches are labeled and control bow up and down movements. They also control starboard and port up and down movements. Bow up and bow down will control the hull planing attitude, while port and starboard up and down provides control for the hull listing. An indicator next to each switch displays the

position of your trim tabs. The display indicates trim tab deflection. When the indicator is at the bottom of the display, the tabs are in the "full-up" (bow up) position. When the indicator is at or near the top of the display, the tabs are fully extended (bow down). The trim tabs are wired so they automatically retract when the ignition switch is turned off.

Before leaving the dock, make sure that the tabs are in the full "UP" position by holding the control in the bow up position for ten (10) seconds.

Always establish the intended heading and cruise speed before attempting to adjust the hull attitude with the trim tabs. After stabilizing speed and direction, move the trim tabs to achieve a level side to side running attitude being careful not to over trim.

After depressing a trim tab switch, always wait a few seconds for the change in the trim plane to take effect. **Avoid depressing the switch while awaiting the trim plane reaction.** By the time the effect is noticeable the trim tab plane will have moved too far and thus the boat will be in an overcompensated position.

When running at a speed that will result in the boat falling off plane, lowering the tabs slightly, bow down, will improve the running angle and operating efficiency. Positioning trim tabs too far in the down position can reduce operating efficiency and cause substantial steering and handling difficulties.

Be extremely careful when operating in a following sea. The effect of trim tabs is amplified under such conditions. Steering and handling difficulties can result from improper trim tab usage, particularly in a following sea. Always raise the tabs to the full bow up position in these conditions.

When running at high speeds be sure that the tabs are in the full "UP" position. Only enough trim plane action should be used to compensate for any listing. Trim tabs are extremely sensitive at high speeds. Adjust for this and be prepared to slow down if difficulties arise.


When running into a chop, a slight bow down attitude will improve the ride. Be careful not to over trim. Handling difficulties may result.

2.5 Control Systems Maintenance

Control and Steering System Maintenance

The engine controls and steering system are electronic and supplied by the engine manufacturer. The systems have maintenance requirements that are specific to the engines, drive units and control options installed in your boat.

You should refer to the engine and controls systems owner's manuals for information and maintenance on the control and steering system installed in your boat. Their recommendations should be followed exactly.



Trim Tab Switch and Indicators

Your engine controls and steering systems are fully electronic and activated by controlling software in each drive unit. If adjustment becomes necessary do not attempt to address the problem yourself. You should contact your Monterey dealer or Monterey Customer Service for assistance.



IMPROPERLY ADJUSTED ENGINE CONTROLS CAN CAUSE LOSS OF CONTROL AND SEVERE ENGINE OR DRIVE DAMAGE. IF YOUR CONTROLS ARE NOT OPERATING PROPERLY, DO NOT ATTEMPT CONTROL SYSTEM ADJUSTMENTS YOURSELF. CONTACT YOUR DEALER OR MONTEREY CUSTOMER SERVICE FOR ASSISTANCE AND DO NOT USE THE BOAT UNTIL THE SITUATION IS CORRECTED.

Trim Tab Maintenance

Marine growth can interfere with the proper operation of the trim tab planes and actuators. To reduce problems due to marine growth, always return the trim tabs to the full "UP" position after operating the boat and periodically inspect and clean marine growth from the actuators and planes.

The trim tab fluid should be checked often. Keep the fluid level between the marks on the trim tab pump reservoir.

If your boat will be left in the water for extended periods, it will be necessary to monitor the zinc anodes on the trim tab planes that prevent galvanic corrosion. Galvanic corrosion is the corrosion process occurring when different metals are submerged in an electrolyte. While galvanic corrosion primarily occurs in salt water, it is possible that galvanic corrosion can occur in fresh water. Sacrificial anodes are installed as standard equipment on the trim tabs. The anodes will need to be changed when they are 75% of their original size.

Refer to the trim tab owner's manual for additional maintenance information, fluid specifications and operating instructions.



Trim Tab Pump

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

FUEL SYSTEM

3.1 General

The fuel system used in Monterey boats is designed to meet or exceed the requirements of the U.S. Coast Guard and the Boating Industry Association in effect at the time of manufacture.

All fuel systems have been factory inspected and pressure tested in accordance with regulations in effect at the time of manufacture. This inspection assures that the system is air tight, leak proof and safe. It is the responsibility of the purchaser to maintain it in that condition. Make frequent inspections to assure that no deterioration or loosening of connections is resulting from vibration.

Fuel Tanks and Fuel Withdrawal Tubes

Your boat is equipped with two fuel tanks. The port fuel tank supplies the port engine and the starboard fuel tank supplies the starboard engine. The fuel withdrawal tubes are positioned in the fuel tanks to achieve optimum fuel usage, fuel line routing, etc. At certain speeds and hull trim angles, the fuel supply at the withdrawal tank location can increase or decrease accordingly. Be extremely careful when attempting to operate the boat when low on fuel. Though some fuel may be in the tank, the relative trim angle of the boat may cause the fuel to flow away from the withdrawal.

The generator is supplied fuel from either the port tank or the starboard tank. Selector valves in the engine room near the generator allow the operator to select which tank the generator draws fuel from. The generator fuel system uses withdrawal tubes that are shorter than the main engine tubes to prevent the generator from exhausting the reserve fuel in the selected tank.

Fuel Gauges

The fuel gauges indicate the amount of fuel in the tanks. Due to the mechanical nature of the fuel senders, variations in readings during various speeds of operation may occur. This system is merely a relative indication of the available fuel supply and not a calibrated instrument.

There is a fuel gauge sender located in the top of each tank that is connected to fuel gauge at the helm. The starboard tank fuel gauge sender



Typical Fuel Gauge Sender

is located below an access plate in cockpit sink cabinet. The fuel gauge sender for the port tank is below an access plate located in the cockpit lounge seat storage compartment.

Fuel Fills

The fuel fill deck plates are located on both sides of the transom and are marked "Diesel." The fuel fill is opened by turning it counter clockwise with a special key. Be sure to use the proper type and grade fuel. Refer to the engine owner's manual for additional information on the fuel requirements for your engines.

Note: Do not over tighten the fuel cap. If the cap is over tightened, the O-ring seal could be damaged allowing water to contaminate the fuel system.



DO NOT CONFUSE FUEL FILL DECK PLATES WITH THE WATER OR WASTE FILL DECK PLATES. THESE PLATES ARE ALSO LABELED ACCORDINGLY. IF DIESEL FUEL IS ACCIDENTALLY PUMPED INTO THE WATER OR WASTE TANK, DO NOT ATTEMPT TO PUMP IT OUT YOURSELF. WATER AND WASTE PUMPS ARE NOT DESIGNED TO PUMP FUEL AND A FIRE OR EXPLOSION COULD RESULT. CONTACT YOUR DEALER OR THE MONTEREY CUSTOMER SERVICE DEPARTMENT FOR ASSISTANCE IN HAVING THE FUEL PROFESSIONALLY REMOVED.

Fuel Vents

There are fuel vent fittings located on each side of the hull. While the tanks are being filled, the air displaced by the fuel escapes through the vents. When the tank is almost full, fuel will be ejected from the fuel vent. You should calculate the amount of fuel you need to avoid overfilling the tank and ejecting fuel from the vent or fuel fill.

After fueling, replace the fill caps, and wash the areas around the fuel fill plate and below the fuel vents. Residual fuel left on the hull sides can be dangerous, and will yellow the gelcoat or damage the striping.

3.2 Diesel Engine Fuel System

The fuel system on the 415 Sport Yacht has two fuel tanks, one tank for each engine. Diesel engines circulate much more fuel than they consume and there are no selector valves for the supply or return fuel lines. The supply and return lines for the port engine are connected directly to the port tank and the supply and return lines for the starboard engine are connected directly to the starboard tank. The generator can be supplied from either the port or starboard fuel tank and is controlled by selector valves near the generator in the engine compartment.

Proper diesel engine operation requires a good supply of clean, dry diesel fuel. Improper marina fuel storage techniques, limited boat usage, etc. can cause the fuel to become contaminated. Periodically, it may be necessary to pump accumulating water and contaminated fuel from the bottom of the fuel tank. If the fuel system on your boat becomes contaminated, contact your dealer or the Monterey Customer Service Department for assistance.

Bacteria, commonly called algae, can grow in the accumulated water in diesel fuel tanks. This condition is most prevalent in warm climates. Periods of storage or limited use allow the bacteria to accumulate, making the situation worse. Periodically adding a high quality diesel fuel conditioner containing a biocide (sometimes called algaecide) may be required to control bacteria in your boating area. Please contact your Monterey dealer or engine manufacturer for additional information regarding fuels and additives.

Diesel Fuel Filters

The primary diesel fuel filters are installed in the engine compartment near each engine. Another



Fuel Fill Location On Each Side Of Transom

fine micron filter is located on each engine. Check the primary filters for water before each use and replace the filter elements as needed. Water is drained from the filters by placing a cup under the filter and draining through the fitting at the bottom of the filter until clean fuel flows. It is particularly important to monitor the condition of the fuel filters frequently because diesel engines circulate much more fuel than they consume.

A fuel shut-off valve is located at the withdrawal location on each fuel tank. The valve should always be closed before servicing the fuel filter. Follow the filter or engine manufacturer's instructions for cleaning and replacing the filter elements.

It is recommended that the filters are inspected after the first 25 hours of use and then serviced as needed. Always follow the engine or filter manufacturer's instructions when servicing or replacing the fuel filters.

Note: Diesel fuel systems may need to be primed after servicing. Refer to the engine owner's manual for information on priming the fuel system.

3.3 Generator Fuel System

The generator fuel system is much like the primary engine fuel system. With diesel engines, there is a fuel supply and a fuel return line. The generator can be supplied by either the port fuel tank or the starboard fuel tank.

The "Generator Fuel Crossover Valves" on the starboard side of the engine compartment near the generator allow the operator to select the fuel tank that supplies the generator. The fuel system on diesel powered generators has two valves. The "Supply" valve selects the tank the generator will draw fuel from and the "Return" valve selects the tank unused fuel will return to. Always make sure the supply and return valves are set to the same tank.

The fuel valves are labeled "Stbd Tank" and "Port Tank." The labels refer to the fuel tank the valve selects. The starboard fuel tank valve position is also labeled "Normal." This is the preferred setting for typical operation. To keep the boat properly balanced during extended use of the generator, the fuel supply should be managed by switching tanks every six hours of generator operation.

The generator withdrawal tubes are shorter than the main engine withdrawal tubes to prevent the generator from consuming the reserve fuel. Therefore, the generator will run out of fuel if the fuel level in either fuel tank drops below 1/4 of the tank.

A water separating fuel filter is located near the generator. Water is drained from the diesel fuel filter by placing a cup below the filter and draining through the fitting at the bottom of the filter until clean fuel flows. The diesel filter should be checked for water before each trip. The filter cartridge for the generator should be replaced when the main engine fuel filter cartridges are changed. Diesel fuel systems have a shut-off valve at the withdrawal location on the fuel tank. The valve should always be closed before servicing the fuel filter.

It is recommended that the filters are inspected after the first 25 hours of use and then serviced as needed. Always follow the generator or filter



Typical Primary Diesel Fuel Filter




Typical Diesel Generator Coolant Recovery Tank, Fuel Crossover Valves, Fuel Supply Pump and Fuel Filter

manufacturer's instructions when servicing or replacing the fuel filters.




IT IS EXTREMELY IMPORTANT THAT THE GENERATOR FUEL SELECTOR VALVE OR VALVES BE USED TO MANAGE THE FUEL DURING NORMAL GENERATOR OPERATION. IF THE TANKS ARE NOT SWITCHED EVERY SIX HOURS OF GENERATOR OPERATION, IT WILL CAUSE THE BOAT TO BECOME UNBALANCED AND LIST WHICH COULD AFFECT HANDLING AND THE SAFE OPERATION OF THE BOAT.

3.4 Fueling Instructions



FUEL IS VERY FLAMMABLE AND CAN CAUSE A FIRE OR EXPLOSION. BE CAREFUL WHEN FILLING THE FUEL TANK. NO SMOKING. NEVER FILL THE TANK WHILE THE ENGINES ARE RUNNING. FILL THE FUEL TANK IN AN OPEN AREA. DO NOT FILL THE TANK NEAR OPEN FLAMES.



TO PREVENT DAMAGE TO THE FUEL SYSTEM, USE ONLY A GOOD GRADE OF DIESEL FUEL FOR DIESEL ENGINES. REFER TO THE ENGINE MANUFACTURER OWNER'S MANUAL REGARDING FUEL REQUIREMENTS FOR YOUR ENGINE.




Typical Fuel Cap Key

To fill the fuel tanks at a marina, follow this procedure:

- Make sure the boat is securely moored.
- Make sure all switches are in the "OFF" position.
- Make sure all passengers leave the boat.
- Close all windows and hatches and make sure the blower is off to prevent fuel fumes from entering the cabin or engine compartment.
- Estimate how much fuel is needed and avoid overfilling the fuel tanks.

Note: When the fuel tank is full, fuel will come out through the fuel tank vent. The fuel tank vents are located on the side of the boat. Monitor the vents closely while fueling to prevent fuel from spilling into the water.

- A special key to open the fuel cap is supplied.
- Turn the key counter clockwise to open the cap.
- Remove the cap.
- Put the nozzle in the fuel opening and make sure it stays in contact with the fuel fill opening.



STATIC ELECTRICITY GENERATED BY FLOWING FUEL CAN CAUSE A FIRE OR EXPLOSION. TO PREVENT STATIC SPARKS WHEN FILLING THE TANK, MAKE SURE THE NOZZLE IS ALWAYS IN CONTACT WITH THE FUEL FILL OPENING.

SPILLED FUEL CAN CAUSE A FIRE OR AN EXPLOSION. MAKE SURE YOU DO NOT SPILL ANY FUEL. IF A SMALL AMOUNT OF FUEL IS SPILLED ON THE FIBERGLASS, USE A CLOTH TO REMOVE THE FUEL AND PROPERLY DISPOSE OF THE CONTAMINATED CLOTH. IF FUEL IS SPILLED ON THE WATER, EXERCISE EXTREME CAUTION. FUEL FLOATS ON THE SURFACE OF THE WATER AND CAN IGNITE. IF FUEL IS SPILLED INTO THE WATER, IMMEDIATELY EVACUATE THE AREA AND NOTIFY THE MARINA AND THE PROPER OFFICIALS.

- Fill the tank slightly less than the rated capacity to avoid spilling fuel out of the vent or the fuel fill and to allow for expansion.
- Remove the nozzle.
- Install the fuel cap.
- Open all hatches, windows and doors to completely ventilate the boat.
- Check the fuel compartment and below the deck for fuel odors. If you smell fuel, do not start the engine.

3.5 Fuel System Maintenance

Periodically inspect all connections, clamps and hoses for leakage and damage or deterioration. Replace as necessary. Spray the valves, tank fuel gauge senders and ground connections with a metal protector.

Frequently inspect and lubricate the fuel fill cap O-ring seal with Teflon or silicone grease. The O-ring seal prevents water from entering the fuel system through the fuel fill cap and it should be replaced immediately if there is any sign of damage or deterioration.

Contaminated fuel may cause serious damage to your engines. The filters must be checked for water and other contamination frequently. Diesel engine filter elements must be changed at least twice a year or more frequently depending on the type of engine and the quality of the fuel. Please refer to the engine or fuel filter manufacturer's instructions for information on servicing and replacing the fuel filter elements.

Algae can grow in the accumulated water in diesel fuel tanks. This condition is most prevalent in warm climates. Periodically adding a high quality diesel fuel additive containing an algaecide may be required to control algae in your boating area. Since algae also can grow in accumulated water in the fuel filters, it is important to run the main engines and the generator for at least 30 minutes after the algaecide has been added so it will be circulated throughout the fuel system. This is even more important during periods of storage or if the boat is not used enough to require refueling at least once a month.

Severe algae in a diesel fuel system can be extremely difficult and expensive to clean. You should be diligent in monitoring the fuel system by checking the filters for water frequently and being alert for signs of algae in fuel that is drained from the filters. Most algae appears as black, carpet-

like fibers suspended in fuel and water drained from the filters. Severe cases of algae will produce a black jelly like substance that quickly clogs the filters and starves the engines for fuel.

Please contact your Monterey dealer or engine manufacturer for additional information regarding fuels and additives.

Note: Diesel engines circulate far more fuel than they consume. Therefore, it is extremely important that the fuel filters are checked for water and serviced frequently on boats equipped with diesel engines.



LEAKING FUEL IS DANGEROUS AND CAN CAUSE A FIRE AND/OR EXPLOSION. AFTER THE FILTER ELEMENT HAS BEEN CHANGED, PRIME THE FUEL SYSTEM AND CHECK ALL FITTINGS FOR LEAKS BEFORE AND AFTER STARTING THE ENGINES.

DO NOT DRAIN ANY FUEL IN THE BILGE. THIS COULD LEAD TO A FIRE OR EXPLOSION. CHECK ALL FUEL LINE FITTINGS FOR LEAKS BEFORE AND AFTER STARTING THE ENGINES FOLLOWING ANY FUEL SYSTEM SERVICE.



TO REDUCE THE POSSIBILITY OF A FIRE OR EXPLOSION, MAKE SURE ALL ELECTRICAL SWITCHES ARE IN THE "OFF" POSITION BEFORE SERVICING THE FUEL SYSTEM.



AVOID SERIOUS INJURY OR DEATH FROM FIRE OR EXPLOSION RESULTING FROM LEAKING FUEL. INSPECT SYSTEM FOR LEAKS AT LEAST ONCE A YEAR. DO NOT DRAIN ANY FUEL INTO THE BILGE.

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

ELECTRICAL SYSTEM



Battery Switches, Voltage Sensitive Relays (VSR), Constant Hot and Switched Circuit Breakers, and Optional Windlass Breaker

4.1 General

Your Monterey is equipped with 120-volt AC and 12-volt DC electrical systems. The AC system can draw current from one of two sources, either shore power outlets at dockside or the generator. The DC system draws current from on board batteries.

Your boat and engine charging system is designed for 12-volt, lead acid, wet cell or AGM marine batteries. They will require similar maintenance as those found in automobiles. Do not attempt to use gel cell or other non wet cell batteries. The engine charging system is not designed to recharge these batteries which could cause unusually short battery life or engine starting problems. You also should not mix the size or brand of the wet cell batteries. Always consult your Monterey dealer before changing the type of batteries in your boat.

4.2 12-Volt System

The 12-volt system is a standard marine system. There are four batteries, one for the starboard engine, one for the port engine, and two in parallel for the house, accessory circuits and

the generator. The batteries themselves can be charged by the engines or by the battery charger when hooked to shore power or when operating the generator.

An automatic battery isolator/relay manages the charging current for the starboard engine and house batteries. Whenever the starboard engine is running, the isolator/relay automatically senses the condition of each battery bank and directs the available current to the batteries that require charging. The port engine battery is charged by the port engine. The system is equipped with a battery parallel feature that will connect both engine starting batteries in parallel for extra battery power while starting the engines. The battery parallel switch is activated by a momentary rocker switch located in the helm switch panel. When the switch is pressed and held for three seconds, a relay is engaged that connects both engine starting batteries. Once engaged, the relay remains activated for ten minutes and then automatically deactivates and the batteries are isolated. A flashing LED light below the switch indicates that the battery parallel feature has been activated.

Most 12-volt power is distributed to the 12-volt accessories through individual circuit breakers

located in the 12-volt breaker panels in the cabin, at the helm and in the breaker panel below the battery switches in the engine compartment. Main breakers located near the battery switches or in the engine compartment breaker panel protect the house, helm systems and windlass from an overload. Other circuit breakers in the engine compartment panel protect the battery charger DC circuits, stereo and electronics memory, engine control memory, CO monitors, sump pump, amp, the automatic switches for the bilge pumps, generator DC charge circuit and the high water alarm. Main breakers located on each engine protect the ignition, charging systems and gauges. Some 12-volt accessories are operated directly by a circuit breaker in the cabin breaker panel while others are operated by a switch fed by the panel breakers. Most of the 12-volt accessories on the deck and in the cockpit are operated by switches in the helm switch panel.

Battery Switches and Batteries

Your boat is equipped with the latest in marine battery switching. Rather than having manually operated battery switches located somewhere in the cockpit, this boat has remotely operated electric battery switches mounted out of the way in the engine room. This method of switching is more convenient and more secure since they are controlled from the inside of a lockable cabin.

Upon commissioning of your new boat, take a moment to locate the bank of battery switches located in the rear of the engine room. They are easy to identify by their distinctive grey cases and the battery cables that run from under them. There are 4 large cases and one small case. The 4 large cases consist of 3 identical battery switches (port engine battery, starboard engine battery, and house battery) and one case marked "VSR Voltage Sensitive Relay Module." This is your parallel switch. It is controlled by the "Parallel" switch at the helm. The small grey case (also Marked VSR) is the voltage sensitive relay that keeps the house battery bank charged when only the engines are running.

Each battery switch in the engine compartment has a manual override that can activate or deactivate the switch if the relay fails. The manual override is a red knob on each battery switch/relay that can rotated to select the "ON", "AUTO" or "OFF" position. The normal operating position for each switch is the "Auto" Position. However, to properly engage the automatic function of each switch, the red lever must first be placed in the

"Off" position and then rotated into the "Auto" position. Once this has been done, the only time these levers would ever need to be operated again would be if there was damage to the boat in an emergency situation. The "Auto" position simply means that the battery switches are now under the control of the remote switches on your vessel's DC panel.

Each battery switch is controlled by a single momentary switch on your cabin DC breaker panel. Press the top of each remote switch to engage the battery switch. A red light will illuminate to indicate that the battery is now "on." To turn off, simply press the bottom of the momentary switch. The red light may not turn off immediately or will slowly fade out if there are no loads present on the system. This is normal as the capacitors in the system drain.

An automatic isolator/relay controls the charging of the starboard engine and house battery banks whenever the starboard engine is operating. The port engine battery is dedicated to starting and operating the port engine. It is charged by the port engine whenever the port engine is operating. The port and starboard engine batteries can be temporarily connected in parallel by the parallel switch in the helm to provide additional starting current for each engine. The engine and house batteries are also charged by the battery charger whenever it is operating.

When in port or at anchor, the port and starboard engine switches should be off. Only the battery switch that activates the House battery should be on. This will keep both engine starting batteries in reserve for starting the engines. If the house battery bank becomes discharged to the point that the generator will not start, the starboard engine can be started to recharge the house battery bank enough to start the generator.

Note: Current is supplied to the high water alarm and the automatic float switches for the bilge pumps when the batteries are connected and the battery switches are off.

The DC electrical system on your boat is designed for wet cell, gel cell or AGM marine batteries. The battery charger is equipped with a switch to select the type of batteries to be charged. The batteries will be damaged if the charger is not set properly. You should refer to the battery charger owner's manual to make sure the charger is set



Helm Circuit Breaker Panel Located in the Helm Station Below the Steering Wheel

to the type of batteries in your boat and do not mix the size, type or brand of marine batteries. Always consult your dealer before changing the type of batteries.

Parallel Switch and Dead Batteries

In the event of a dead battery on either engine, the port and starboard batteries can be placed in a temporary parallel configuration. This allows you to start either engine from both the port and starboard engine batteries. To do this, locate the "Parallel" switch at the helm. Make sure the house battery is on. Hold down the Parallel switch for 3 seconds. The green LED light below the switch will begin to flash. Start the dead engine normally. After 10 minutes, the parallel will automatically disengage.

In the event of a dead house battery bank, there are several options.

- If at the dock, simply plug in your shore power and turn on the battery charger until the battery is recharged.
- If at sea, start the starboard engine. The VSR (small grey box) will begin to click rapidly and will gradually slow until it stops and stays engaged. The starboard engine will charge its own battery and then the VSR will release the excess charge into the house battery bank. After about 10 minutes, the generator can be started and the battery charger turned on to accelerate the charge into the house bank.

Note: If battery is fully discharged/dead for a lengthy period it may become permanently damaged and will not be able to hold a charge

Constant Hot and Switched Circuit Breakers

The panel beneath the battery switches houses the constant hot and switched circuit breakers. There is no need to do anything with this panel unless one of the listed functions fails to operate. The bilge pumps, sump pump and CO monitor are constantly hot devices and are divided among the batteries for safety and backup purposes. Note that the cabin main and helm main are only active when the house battery switch is turned on. Refer to the "Engine Compartment Panel Breakers" section later in this section for more information on the circuit breakers in this panel.

12-Volt Accessory Switch Panels

The main accessory switch panels and the engine start switch panel are located at the helm. The circuit breakers that protect the accessories and activate the engine starting circuits are located in a breaker panel below the helm switches and in the engine compartment breaker panel.

The following is a description of the accessories controlled by the main accessory switch panel:

Port Ignition Switch

The port ignition switch is a key activated switch, located near the helm below the steering wheel, which activates the port engine. The switch has

off/on and momentary start positions. To start the engine, make sure the shift lever is in the neutral position and your hand is on the throttle lever in the idle position. Turn the ignition key to the start position. When the engine starts, release the key and the switch will automatically go to the run position. Stop the engine by turning the key to the off position. It is protected by a breaker located in the helm breaker panel and main breakers located on the engine.

Starboard Ignition Switch

The starboard ignition switch is a key activated switch, located near the helm below the steering wheel, which activates the starboard engine. The switch has off/on and momentary start positions. To start the engine, make sure shift lever is in the neutral position and your hand is on the throttle levers in the idle position. Turn the ignition key to the start position. When the engine starts, release the key and the switch will automatically go to the run position. Stop the engine by turning the key to the off position. It is protected by a breaker located in the helm breaker panel and main breakers located on the engine.

Note: Diesel engines have starting and shut down procedures that are unique to each manufacturer and model of engine installed in your boat. You should refer to the engine owner's manual for specific instructions for starting and shutting down your engines.

The following is a description of the accessories controlled by the main accessory switch panel:

Engine Hatch

The engine hatch control is a momentary switch that controls the electric actuator for the engine hatch. Note that the House battery switch must be turned on for the hatch lifter to operate.

Engine Room Lights

Activates the 12-volt lights in the engine compartment.

Cockpit Lights

Activates the lights that illuminate the cockpit area and the cabin steps.

Panel Lights

Activates the lights that illuminate the engine gauges.



Helm Switch Panel - Port Side



Helm Switch Panel - Starboard Side



Ignition Switches

Nav/Anchor Lights

The switch is a three-position switch. The middle position is "OFF." Moving the switch in one direction will activate the navigation lights. Moving the switch in the opposite direction activates the anchor light.

Arch Light

Activates the overhead lights above the bridge deck. The switch is a three-position switch. The middle position is "OFF." Press the top of the switch to activate the red map lights. Press the bottom of the switch to activate the white overhead lights.

Note: Red lights have less effect on night vision and should be selected if you need to illuminate the bridge deck while navigating at night.

Windshield Vent

Activates the electric actuator that opens and closes the center windshield panel that provides ventilation for the bridge deck/cockpit.

Bow Thruster (Optional)

Activates the control panel for the optional bow thruster. To activate the bow thruster, press the switch once. The LED light in the switch flashes. Press the switch again, the steady LED light in the switch indicates the bow thruster control panel is activated and the bow thruster is operational. This switch is labeled "Accessory" and reserved for additional 12-volt equipment if the bow thruster or another optional accessory is not activated by the switch.

Windlass Switch

This switch controls the optional windlass which is mounted to the deck directly above the rope locker. It is protected by a circuit breaker of the type and rating recommended by the windlass manufacturer that is located in the engine compartment breaker panel. There could also be optional foot activated switches on the deck next to the windlass.

Wiper

Activates the windshield wipers.

Bilge Pump

Manually activates the aft bilge pump which is installed in the bilge near the transom, between the engines. The pump moves water out through the thru-hull fitting in the hull. To start the pump, place the switch in the "ON" position.

Emergency Pump

Manually activates the emergency bilge pump which is installed in the stern bilge, below the access plate in the floor in the engine room. The pump moves water out through the thru-hull fitting in the hull. To start the pump, place the switch in the "ON" position.

Cabin Pump

Manually activates the cabin bilge pump which is installed in the forward bilge, below the aft berth in the cabin. The pump moves water out through the thru-hull fitting in the hull. To start the pump, place the switch in the "ON" position.

Note: The bilge pumps will start automatically when there is sufficient water in the bilge to activate the automatic float switch near each pump. The float switch for the emergency pump is located above the normal operating range of the aft bilge pump float switch. The automatic float switches are protected by breakers located in the engine compartment breaker panel and are always supplied current when the batteries are connected. Refer to the Drainage Systems chapter for more information on the bilge pump systems and high water alarms.

Blower

This switch supplies electrical current to the blowers that provide ventilation to the engine compartment. Two LED lights below the switch illuminate when each blower is operating.



GASOLINE VAPORS CAN EXPLODE. BEFORE STARTING THE ENGINES OR GENERATOR, OPERATE THE BLOWERS FOR FOUR (4) MINUTES. OPEN THE ENGINE COMPARTMENT ACCESS HATCH, INSPECT THE FUEL SYSTEM AND CHECK FOR THE ODOR OF GASOLINE VAPORS. ALWAYS OPERATE THE BLOWER WHILE THE ENGINES ARE OPERATING BELOW CRUISE SPEED OR WHENEVER THE GENERATOR IS OPERATING. UNDER NO CIRCUMSTANCES SHOULD THIS PROCEDURE BE OVERLOOKED

Parallel

The battery parallel switch is a momentary switch that provides additional starting power to the engine starters. When activated, both port and starboard engine batteries are momentarily used to crank the engines. When the switch is pressed and held for three seconds, a relay is engaged that connects both engine starting batteries. Once engaged, the relay remains activated for ten minutes and then automatically deactivates and the batteries are isolated.

Horn

Activates the boat horn.

Additional Accessory Switch Panels

Additional switch panels are located in various locations in the helm, cockpit and cabin. The following is a description of additional panels that

may be on your Monterey and the accessories they control:

Trim Tab Switch

Located in the helm. This switch controls the trim tabs located on the transom of the boat. Please refer to the Helm Control Systems chapter for detailed information on the operation of the trim tab controls.

Stereo Control Pad

Located in the helm. Controls the stereo that is mounted in the cabin. Refer to the stereo owner's manual for details on operating the stereo control pad.

Holding Tank Macerator

The holding tank overboard discharge macerator switch panel is located in the master head compartment next to the holding tank monitor. It is a momentary switch that activates the level indicator lights and the macerator discharge system for the holding tank. Refer to the Marine Head System in the Interior Equipment chapter for additional information on the operation of the overboard macerator discharge system.

Spot Light (Optional)

Located in the helm. Controls the spot light that is mounted on the deck. Refer to the spot light owner's manual for details on operating the control pad.


12-Volt Receptacles (2)

Provides electrical current for portable 12-volt equipment.

Bow Thruster Control (Optional)

This touch pad control panel is located in the helm and controls the optional bow thruster that is mounted to the hull in the bilge below the V-berth. The bow thruster provides the operator additional control of the bow while docking or anchoring the boat in tight quarters or high winds and strong currents.

The momentary touch pad buttons are activated by the rocker switch next to the touch pad and control port and starboard movement of the bow. The arrow on each button indicates the direction the bow will move when it is pressed. The bow thruster will stop when the button is released. Always turn the rocker switch off to deactivate the touch pad when the thruster is not being used.



Trim Tab Switch and Indicators



Typical Stereo Control Pad



Bow Thruster Control (Optional)

Refer to the bow thruster owner's manual for details on operating the bow thruster and using the control pad.

Automatic Fire Extinguisher Indicator Panel and Override Switch

The panel is equipped with lights that indicate the status of the automatic fire extinguishing system. The green light indicates the system is charged and ready. The red light indicates the system has discharged.

The system is completely automatic and will shut down the engines when it is activated. The panel is equipped with an override switch that enables the operator to restart the engines when he has determined it is safe to do so. This switch is necessary because diesel engines will consume fire extinguishing agent and must be shut down by the system when it is activated. The shut down system and the fire extinguishing agent will shut down gasoline engines which can be restarted once the fire extinguishing agent has dissipated from the engine compartment. Refer to the Automatic Fire Extinguishing System in the Safety Equipment chapter and the manufacturer's owner's manual for more information on the operation of the automatic fire extinguishing system.

MP3 Connection

Located next to the helm seat. Provides an input for MP3 players to connect to the boat stereo system. It is not provided when optional multi disk CD changer is installed.

Underwater Lights (Optional)

Activates the optional underwater lights located in the transom, below the swim platform.

DC Accessory Breaker Panels

Power is distributed to most of the 12-volt accessories through individual circuit breakers located in the DC breaker panels. There are three DC breaker panels, the engine compartment breaker panel located in the engine compartment near the main battery switches, the cabin DC breaker panel located in the main salon on the AC/DC panel and the helm breaker panel at the helm station below the steering wheel. Main breakers located in the engine compartment breaker panel protect the system from an overload. Some 12-volt accessories are operated directly by the circuit breaker in the panel while others are operated by switches fed by the panel breakers.




Fire Extinguisher Indicator Panel and Override Switch



MP3 Connection

A DC voltage meter is located in the cabin panel to monitor the voltage level in the House and engine batteries. It will monitor the voltage of the batteries plus any electrical charges supplied when the engines or the battery charger are operating.



Engine Compartment Panel Breakers

The following is a description of the accessories controlled by the "push to reset" and main DC breakers in the engine compartment breaker panel located in the engine compartment near the battery switches.



Constant Hot and Switched Circuit Breaker Panel Near Battery Switches in Engine Compartment

Stereo Memory

Provides protection and continuous power for the stereo and electronics memory. This "push to reset" breaker is always supplied current when the batteries are connected.

Amp

Provides protection and power for the stereo amplifier. This "push to reset" breaker is supplied current when the House battery selector switch is activated.

Cabin Pump

Provides protection and continuous power for the automatic float switch on the forward bilge pump in the cabin bilge. This "push to reset" breaker is always supplied current when the batteries are connected. Another breaker in the helm breaker panel provides circuit protection for the manual switch.

Emergency Pump

Provides protection and continuous power for the automatic float switch on the emergency bilge pump in the engine compartment bilge, below the step. This "push to reset" breaker is always supplied current when the batteries are connected. This breaker also provides protection and power for the high water alarm. Another breaker in the helm breaker panel provides circuit protection for the manual switch for the emergency pump.

Bilge Pump

Provides protection and continuous power for the automatic float switch on the aft bilge pump. This "push to reset" breaker is always supplied current when the batteries are connected. Another breaker in the helm breaker panel provides circuit protection for the manual switch.

Sump Pump

Provides protection and continuous power for the automatic float switch in the cabin sump pump. This "push to reset" breaker is always supplied current when the House battery switch is activated.

CO Detector

Provides protection and continuous power for the carbon monoxide detectors in the cabin. This is a "push to reset" breaker that is normally on, unless tripped by an overload, when the House battery switch is activated. It should be checked and the power indicator on the carbon monoxide detectors should be lit whenever someone is occupying the cabin. If the breaker has tripped, it indicates that there is a problem with the carbon monoxide detector, the breaker, or the wiring from the breaker panel to the detector. Always determine the cause of the problem and correct it before resetting the breaker.

Gen Charge

The wire that supplies DC charging current to the house batteries while the generator is operating is protected by a circuit breaker in the generator panel and an external "push to reset" breaker for the battery output wire. The external breaker protects the DC charging circuit from the batteries to the generator. The circuit breaker in the generator panel protects the DC charging circuit from the generator to the batteries.

Port Ignition

Provides protection and power for the port engine. This "push to reset" breaker is always supplied current when the batteries are connected.

Stbd Ignition

Provides protection and power for the starboard engine. This "push to reset" breaker is always supplied current when the batteries are connected.



Cabin DC Breaker Panel

Port Charge - Stbd Charge

The wires that supply DC charging current to the batteries are protected by an internal fuse in the battery charger and three external "push to reset" breakers, one for each battery output wire. The external breakers protect the DC charging circuit from the batteries to the charger. The internal fuses in the charger protect the DC charging circuit from the charger to the batteries.

Helm and House Main Breakers

The primary circuits for the cabin DC panel and helm switch panel are protected and powered by heavy duty circuit breakers. The breakers are supplied power whenever the House battery switch is on. These are heavy duty "push to reset" breakers that require a firm push to reset if they trip.

Windlass Main Breaker

The windlass breaker is located next to the engine compartment breaker panel and main battery switches. If this heavy duty circuit breaker is

tripped by an overload, a yellow lever near the center of the breaker will point to the "Off". Reset the breaker by pushing the lever until it resets and locks in the "On" position.

Engine Main Breakers

The primary circuits for the engines are protected by a heavy duty, "push to reset" breaker on each engine. They are supplied power whenever the engine battery switches are on. Refer to the engine owner's manual for information on the location and operation of the engine circuit breakers.

Cabin DC Breaker Panel

The cabin DC breaker panel is located on the starboard side of the cabin in a cabinet near the companionway.

DC Volt and Amp Monitor

Monitors voltage in all three battery banks and Indicates the charge and discharge amps in the

house battery circuit. The display is illuminated for easy night viewing and is controlled by buttons on the face of the display. Refer to the owner's manual included with this manual for detailed information on the operation of the monitor.

Water Gauge

Indicates the water level in the freshwater tank whenever the house battery is activated.

Main

Supplies the 12-volt current to the DC accessory breakers and protects the panel from an overload.

Cabin Lights

Supplies 12-volt electrical current to the cabin light switches.

Stereo

Supplies 12-volt electrical current to the stereo located in the cabinet above the dinette.

Water Pump

Supplies 12-volt electrical current directly to the fresh water pump pressure switch located on the pump. The pressure switch automatically controls the water pump when the system is activated and properly primed. It is protected by the circuit breaker in the panel and an automatically resetting breaker on the pump motor.

FWD/AFT TV/DVD

Supplies 12-volt electrical current to the TV's and DVD players.

FWD Head System

Supplies electrical current directly to the vacuum pump on the electric head system for the forward (master) head compartment. A vacuum switch on the pump automatically controls the pump and maintains proper vacuum in the system.

AFT Head System

Supplies electrical current directly to the vacuum pump on the electric head system for the aft head compartment. A vacuum switch on the pump automatically controls the pump and maintains proper vacuum in the system.

Macerator

Supplies electrical current to the holding tank monitor in each head compartment and the switch in the master head compartment that activates the macerator overboard discharge pump for the holding tank.

Cabin Refrigerator

Supplies 12-volt electrical current directly to the refrigerator in the galley when AC current is not being used.

Cockpit Refrigerator

Supplies 12-volt electrical current directly to the optional cockpit refrigerator when AC current is not being used.

12V Acc

A "push to reset" breaker that is reserved for additional 12-volt equipment.

Head Fan

A "push to reset" breaker that supplies electrical current to the exhaust fan switch in each head compartment.

Blower 1

A "push to reset" breaker that supplies electrical current to the starboard bilge blower in the engine compartment.

Blower 2

A "push to reset" breaker that supplies electrical current to the port bilge blower in the engine compartment.

Courtesy Lights

A "push to reset" breaker that supplies continuous electrical current to the courtesy light switch near the cabin door.

Accessory Breaker

Reserved for additional 12-volt equipment

Battery Switches

These momentary switches remotely activate the relays that control the Starboard Engine, Port Engine and House/Generator battery switches. A red LED light in each switch glows when the battery switch it controls is on. Press the top of each switch to activate the indicated battery switch. Press the bottom of the switch to turn the indicated battery switch off. The red light may not turn off immediately or will slowly fade out if there are no loads present on the system.



AC Shore Connections and Circuit Breakers, Phone and TV Connection and Shore Water Connection

4.3 120-Volt System

Boats designed to operate in the United States are equipped with two 30 amp inlets located in a compartment on the port side of the transom, just forward of the swim platform. There is a main circuit breaker for each power cord located above the inlets and a main breaker for each circuit in the cabin AC breaker panel. The AC system can be fed by either the shore power inlets or by the generator. It is wired totally separate from the 12-volt DC system and is equipped with an on board isolation system. Main breakers in the AC panel are used to select the source of power desired. The AC main breakers must be switched to the "OFF" position before changing the source of power.

All AC current is distributed to the AC accessories through individual circuit breakers located in the AC panel. The main breakers in the panel protect the system from an overload and the reverse polarity lights indicate any problems due to an improper shore power supply. All AC outlets in the cabin are protected by ground fault interrupts to protect against electrical shock. While moored

dockside, 120-volt, 60 cycle, AC power should be utilized from dockside power, if available. A cord set is provided to supply power from the shore power outlets to the boat's 120-volt AC system.



ELECTRICAL SHOCKS FROM 120VOLT EQUIPMENT CAN CAUSE SEVERE INJURY OR DEATH. TO REDUCE THE RISK OF ELECTRICAL SHOCK IN WET WEATHER, AVOID MAKING CONTACT WITH THE SHORE CABLE OR MAKING A CONNECTION TO A LIVE SHORE OUTLET. NEVER SPRAY WATER ON ELECTRICAL CABLES WHILE WASHING DOWN DECKS.



TO REDUCE THE POSSIBILITY OF AN ELECTRICAL SHOCK, IT IS IMPORTANT THAT THE AC GROUND SYSTEM IS FUNCTIONING PROPERLY AND THAT A PROPER CONNECTION EXISTS BETWEEN THE SHORE POWER CORD, THE SHORE POWER INLET, THE BOAT BONDING SYSTEM AND THE OUTLET GROUND CIRCUITS. IF THERE IS ANY DOUBT ABOUT THE INTEGRITY OF THE GROUND CIRCUIT, A QUALIFIED MARINE ELECTRICIAN SHOULD BE CONTACTED IMMEDIATELY AND THE AC POWER SHOULD BE DISCONNECTED UNTIL THE NECESSARY REPAIRS ARE COMPLETED.

Recommended procedure for making a shore connection:

Turn the boat inlet AC main breakers, cabin panel AC main breakers and all AC accessory breakers to the "OFF" position. If the dockside outlet includes a disconnect breaker, turn it to the "OFF" position also.

To avoid strain on the cables, make sure they have more slack than the mooring lines. Dress the cables so that they cannot be damaged by chafing between the boat and the dock. Make sure the cables do not come in contact with the water. Then connect the cables in the plug outlets, making sure the connection plug includes a three prong plug with a ground wire. Rotate the plugs clockwise to lock them in the inlets and tighten the lock rings on both the shore and the boat connector plugs.

Turn the shore disconnect and main inlet breakers to the "ON" position and check for proper polarity. If reverse polarity has been achieved, the red polarity indicators in the AC panel will light. If this should happen, make sure the AC main breakers on the panel and at the inlets are in the "OFF" position and turn the dock power breakers off. Notify a qualified electrician to check the wiring at the dock outlet. If the red polarity lights do not illuminate when power is supplied to the panel, the polarity is correct and the AC main breakers can be moved to the "ON" position.



REVERSE POLARITY WILL DAMAGE THE SYSTEM AND EXPOSE PASSENGERS TO ELECTROCUTION HAZARDS. THIS CONDITION COULD ALSO CAUSE A FIRE IN THE ELECTRICAL SYSTEM. DO NOT OPERATE THE AC ELECTRICAL SYSTEM FROM SHORE POWER WITH REVERSE POLARITY.



ELECTRIC SHOCK CAN CAUSE SEVERE INJURY OR EVEN DEATH. DO NOT ATTEMPT TO CORRECT THE WIRING YOURSELF. ALWAYS HAVE A QUALIFIED ELECTRICIAN CHECK WIRING



KEEP CHILDREN AWAY FROM ANY ELECTRICAL CABLES OR EQUIPMENT AND ALWAYS USE GROUNDED APPLIANCES ON BOARD YOUR BOAT.



UNDETECTED FAULTS IN THE AC ELECTRICAL SYSTEM COULD CAUSE THE WATER AROUND THE BOAT TO BECOME ENERGIZED. THIS COULD CAUSE A SEVERE SHOCK OR EVEN DEATH TO SOMEONE IN THE WATER NEAR THE BOAT. NEVER SWIM OR ALLOW SWIMMING AROUND THE BOAT WHEN THE AC SYSTEM IS ACTIVATED BY THE GENERATOR OR THE SHORE POWER CONNECTION.

Disconnecting procedure for shore power connection:

Turn the main breakers on the AC panel and at the inlets to the "OFF" position. Turn the disconnect breakers on the dockside outlet to the "OFF" position.

Loosen the lock rings and rotate the plugs counterclockwise to disconnect the cables from the dockside outlets and replace the outlet caps. Disconnect the cables from the boat and replace the outlet caps. Store cables in the compartment below the rear sun lounge.

AC Accessory Breaker Panel

The AC panel is located in the main salon. The following is a description of the AC panel equipment and the breakers that protect the accessories:

AC MAIN # 1 and MAIN # 2 Selector Switches and Main Breakers

One shore cord supplies AC MAIN # 1 and one shore cord supplies AC MAIN # 2. Both main breakers protect the overall distribution network. These breakers are very sensitive. The resulting power surge, which occurs when connecting the dockside cords, may cause the main breakers to trip. To avoid this surge, always turn the main breakers to the "OFF" position prior to plugging or unplugging the shore power cord.

These switches are used to select either shore power or the generator to supply 120-volt power to the AC breaker panel. When connected to dockside power, move the AC MAIN # 1 and AC MAIN # 2 selector switches to the SHORE POSITION and activate the SHORE POWER main breakers. When using the generator, move the AC MAIN # 1 and AC MAIN # 2 selector switches to the generator position and activate the GENERATOR main breakers. The main breakers must be in the "OFF" position before the selector switches can be moved to the GENERATOR or SHORE position.



AC Breaker Panel

AC Volt, Amp and Frequency Monitor

Monitors AC volts supplied to the panel, load amps, AC frequency and Kilowatt load. It is equipped with alarms for hi or low voltage, high amps and improper frequency. The display is illuminated for easy night viewing and is controlled by buttons on the face of the display.

You should always check the voltage and frequency for each circuit before activating the cabin AC accessories. If the monitor indicates 120-volts AC and a frequency of 60 Hz (US electrical systems

only), the AC accessories can be activated. If the monitor indicates any voltage other than 120-volts or a frequency other than 60 Hz, do not activate the AC panel breakers and contact the marina or a qualified marine electrician for assistance.

Refer to the monitor owner's manual included with this manual for detailed information on the operation of the monitor.



OPERATING THE COMPONENTS OF THE AC ELECTRICAL SYSTEM FROM A POWER SOURCE THAT IS NOT THE CORRECT VOLTAGE AND/OR HZ CURRENT CAN DAMAGE AC ELECTRICAL COMPONENTS AND BE A SAFETY HAZARD FOR THOSE ABOARD YOUR BOAT. 120-VOLT, 60 HZ CURRENT IS THE STANDARD FOR AC ELECTRICAL POWER IN THE UNITED STATES. THE AC ELECTRICAL SYSTEM AVAILABLE FOR BOATS OPERATING IN OTHER COUNTRIES MAY REQUIRE THAT THE AC ELECTRICAL SYSTEM AND COMPONENTS IN YOUR BOAT OPERATE AT A DIFFERENT VOLTAGE AND FREQUENCY. ALWAYS MAKE SURE YOUR BOAT'S AC ELECTRICAL SYSTEM AND ACCESSORIES ARE RATED FOR THE AVAILABLE CURRENT IN THE AREAS IN WHICH YOU BOAT. DO NOT OPERATE THE AC ELECTRICAL SYSTEM FROM A SHORE POWER SOURCE THAT IS NOT RATED THE SAME AS THE SYSTEM AND COMPONENTS IN YOUR BOAT.

Note: All AC electrical outlets are provided with ground fault interrupts to protect against electric shock. These outlets should be tested periodically to ensure proper operation by pressing the test/reset buttons in the center of faceplate. G.F.I. outlets do not protect against short circuits and overloads. This is done by the outlet breakers on the AC panel.



G.F.I. OUTLETS DO NOT PROVIDE 100% PROTECTION FROM ELECTRIC SHOCK. EVEN THOUGH GROUND FAULT INTERRUPTERS PROVIDE PROTECTION BY REDUCING EXPOSURE TIME FROM LINE TO GROUND SHOCK HAZARDS, IT IS STILL POSSIBLE TO RECEIVE AN ELECTRIC SHOCK FROM DEFECTIVE APPLIANCES OR POWER TOOLS AND MISUSED ELECTRICAL EQUIPMENT.

Reversed Polarity Lights

The red lights indicate reverse polarity current supplied to the panel for each circuit. This situation will cause the red light to remain lit. If reverse polarity is achieved, immediately turn off all cabin AC breakers and dockside outlet breakers. Disconnect the power cable from the dockside outlet and notify a qualified marine electrician to check the dockside wiring.

Reverse Polarity Light Test Switches

There is a momentary switch located next to the reverse polarity lights in the AC breaker panel. This switch is used to test the reverse polarity lights to ensure that they are functioning. The lights can be tested by depressing the switch whenever the AC system is activated. The reverse polarity lights should be tested each time the AC system is activated. If one or both of the lights does not activate when the switch is pressed, disconnect the shore power cable and notify a qualified electrician to check the light and the dockside wiring if necessary.

Shore 1 Breakers

Port Outlets

Supplies 120-volt AC electrical current to the cabin ground fault interrupter (G.F.I.) outlets on the port side of the cabin.

Stove

Supplies 120-volt AC electrical current to the stove in the galley.

Water Heater

Supplies electrical current directly to the hot water heater circuit. A thermostat in the water heater control panel automatically controls the water temperature. Before operation, you must have water in the water heater. See the water heater manual for details.

Battery Charger

Supplies electrical current directly to the automatic battery charger. The battery charger charges and maintains the 12-volt batteries simultaneously when activated. It is fully automatic.

The wires that supply DC charging current to the batteries are protected by an internal fuse in the battery charger and 3 external breakers, one for each battery output wire, located in the engine compartment breaker panel near the battery switches. The external breakers protect the DC charging circuit from the batteries to the charger. The internal fuses in the charger protect the DC charging circuit from the charger to the batteries. Refer to the battery charger owner's manual for more information on the features and operation of the battery charger.

The charge to the engine batteries can be monitored by using the DC monitor in the cabin DC panel or by using the volt meters in the engine gauge cluster. To monitor the engine batteries with the volt meters, activate the charger and turn the engine battery switches on. Turn the ignition key switch for each engine to the "ON" position (**DO NOT START THE ENGINES**) and read the voltage on the volt meter for each engine. To monitor the house or engine batteries with the DC monitor in the cabin DC panel, activate the charger and turn the battery switches on. Select to read the voltage on the desired battery using the button on the monitor. If the batteries are in good condition and charging properly, the volt meters will indicate between 12 and 14.5 volts. If the reading is below 12 volts, then the battery is not accepting a charge or the charger is not working properly. Always turn the ignition switches off immediately after the monitoring is complete when using the voltmeters in the engine gauge cluster. Refer to the battery charger and DC monitor owner's manuals for more information.

FWD A/C

Supplies electrical current to the air conditioner control panel located in the main cabin.

Cockpit Grill (Optional)

Supplies 120-volt AC electrical current to the optional electric grill in the cockpit.

A/C Pump

Provides protection and continuous power air conditioning pump. This "push to reset" breaker is always supplied current when the shore 1 AC circuit is activated. The pump will start automatically when one or both of the cabin air conditioning units is in use.

Note: After a certain amount of time without water flow, the air conditioning unit will automatically power down.

Shore 2 Breakers

STBD Outlets

Supplies 120-volt AC electrical current to the cabin ground fault interrupter (G.F.I.) outlets on starboard side of the cabin.

Microwave

Supplies 120-volt AC electrical current to the cabin ground fault interrupter (G.F.I.) outlet that activates the Microwave.



Battery Charger on Forward Engine Compartment Bulkhead

Cabin Refrigerator

Supplies 120-volt electrical current directly to the refrigerator when AC power is available and chosen over the 12-volt power supply. See the refrigerator manual for more information.

Cockpit Refrigerator/Ice maker (Ice Maker is Optional)

Supplies AC electrical current directly to the cockpit refrigerator or optional ice maker when AC power is available. See the ice maker manual for more information.

Aft A/C

Supplies electrical current to the air conditioner control panel located in the aft cabin.

Central Vac

Supplies electrical current directly to the central vacuum system.

Home Theater

Supplies electrical current to the AC components of the home theater system.

Generator Operation Panel

These switches control the starting, running, and stopping of the optional generator. The procedures may vary depending on the model and type of generator installed in your boat. The generator panel also includes gauges and warning lights that monitor critical engine systems. An owner operator's manual for the generator has been supplied with this manual. Please refer to it for details on the generator operation.

The blowers provide ventilation and cooling for the engine compartment when the generator is operating. Always make sure the blowers are activated by the blower switch on the DC panel before starting the generator.

Additional AC Switch Panels and Breakers **Shore Power Inlet Breakers**

Located in the transom inlet connector compartment above the shore power inlet plugs. These breakers protect the AC system between the shore power inlet plugs and the cabin AC panel.

4.4 Generator

The generator is activated by the house battery bank and is located in the engine compartment. The generator oil and coolant should be checked whenever you check the oil and coolant in the main engines.

There is a control panel in the cabin AC breaker panel that activates the generator. The generator can also be operated from a control panel on the generator. The circuit breakers that protect the generator AC and DC circuits are also on this panel. An owner operator's manual for the generator has been supplied with this manual. Please refer to it for details on the generator operation.

Note: Generators consume DC electrical current and charge the house/generator battery just enough to compensate for the DC electrical current the engine requires to operate. Therefore, it is important to activate the battery charger to maintain the house and engine batteries whenever the generator is running.

Note: The generator may not be able to operate all 120-volt accessories at the same time. POWER MANAGEMENT PRACTICES may need to be observed depending on the AC power load.

The generator engine uses a closed cooling system with a seawater-cooled heat exchanger. There is an expansion tank for the engine coolant mounted near the generator. Make sure the fluid level in the expansion tank is kept between the maximum and minimum lines of the tank.

The seawater cooling system operates like the cooling system on the main engines. It includes a strainer that prevents debris in the seawater from entering the cooling pump. The strainer is located in the stern bilge near the generator. It is important to check and clean the strainer regularly to ensure the seawater system can circulate enough water to provide cooling for the closed cooling and exhaust systems on the generator.



Typical Diesel Generator



Generator Sea Strainer

You should also check the exhaust port for water flow each time the generator is started. If there is no discharge within thirty seconds, shut down the generator and find and correct the problem.

Cleaning the Sea Strainers

- Turn off the engines and generator.
- Close the generator water intake valve.
- Open the top of the strainer and remove the screen.
- Thoroughly flush the screen and the inside of the strainer to remove foreign matter.

- Lubricate the seal.
- Reassemble the strainer making sure that all fasteners are tight.
- Open the intake valve.
- Start the generator and inspect the strainer for leaks.

The generator fuel system is equipped with a water separating fuel filter and operates much like the fuel system for the main engines. Please refer to the Fuel System chapter for more information on generator fuel system.

You also should read the generator owner's manual for detailed information on the safe operation and maintenance of the generator.



GENERATOR ENGINES PRODUCE CARBON MONOXIDE WHICH IS A LETHAL, TOXIC GAS THAT IS COLORLESS AND ODORLESS. IT IS A DANGEROUS GAS THAT WILL CAUSE DEATH IN CERTAIN LEVELS. ONLY OPERATE THE GENERATOR IN WELL VENTILATED AREAS AND NEVER OPERATE THE GENERATOR WHILE YOU ARE SLEEPING.

4.5 Bonding System

Your boat is equipped with a bonding system that interconnects all underwater metal hardware and thru-hull fittings to ensure that they are of the same electrical potential. Anodes mounted on the transom are attached to the bonding system at the IPS drives. The anodes deteriorate before the other metals, thereby protecting the underwater metals from galvanic corrosion or stray electrical current. Since the anodes are sacrificial, it is important to monitor them and replace them when they have deteriorated to 50 - 75% of their original size. The bonding system is connected to the DC ground and the earth ground wire for the AC electrical system. It provides a path to the safety earth ground in the event of a fault in the shore earth ground connection and when the boat is away from the dock.

4.6 Electrical System Maintenance

12-Volt AC Electrical System Maintenance

At least once a year, spray all exposed electrical components behind the helm and in the plugs, with

a protector. Exterior light fixture bulbs should be removed and the metal contact areas coated with a non-water soluble lubricant like Teflon or silicone grease. The sockets should be sprayed with a protector. Care must be taken not to get any oil or grease on the glass portion of the bulbs as this will cause the bulb to overheat and burn out.



WHEN REPLACING LIGHT BULBS IN MARINE LIGHT FIXTURES, ALWAYS USE A BULB WITH THE SAME RATING AS THE ORIGINAL. USING A DIFFERENT BULB COULD CAUSE THE FIXTURE TO OVERHEAT AND MELT OR SHORT CIRCUIT.

Inspect all wiring for proper support, sound insulation, and tight terminals, paying particular attention to portable appliance cords and plugs.

Check all below deck wiring to be sure it is properly supported, that the insulation is sound, and that there are no loose or corroded terminals. Corroded terminals should be thoroughly cleaned with sandpaper or replaced, tightened securely and sprayed with a metal and electrical protector. Inspect all engine wiring.

Check the electrolyte level in lead acid, wet cell batteries regularly and add distilled water as necessary. If the batteries are frequently charged by the automatic battery charger, the electrolyte level will have to be checked more often. The correct fluid level in the cells is usually approximately 1/4 to 1/2 inch above the plates. If fluid is needed, fill to the proper level with distilled water. **Do not over fill!** Please note that some batteries are sealed and cannot be filled.

Your boat could be equipped with absorbed glass mat (AGM) type batteries. These advanced batteries are sealed (maintenance free) and, therefore do not allow or require the inspection of the electrolyte. Additionally, they are not vented which reduces corrosion on the battery posts and on other equipment near the batteries in the engine compartment.

Keep the battery tops clean and dry. Dirt and water can conduct electricity from one post to the other causing the battery to discharge.

The battery posts should be kept free of corrosion. Remove the cables and clean the posts and cable clamps with a battery post cleaner or sandpaper

as required. Coating the battery posts and cable clamps with Teflon or silicone grease will protect them and reduce corrosion.

Battery cables, both hot and ground, must be replaced when they show signs of corrosion or fraying. Deteriorated cables cause a considerable voltage loss when high currents are drawn, such as starting the engine.



A BATTERY CAN EXPLODE IF A FLAME OR SPARK IGNITES THE HYDROGEN GAS THE BATTERY EMITS WHILE BEING CHARGED. NEVER USE AN OPEN FLAME IN THE BATTERY STORAGE AREA. AVOID STRIKING SPARKS NEAR THE BATTERY.

AC Electrical System Maintenance

Periodically inspect all wiring for nicks, chafing, brittleness, improper support, etc. Examine each shore power cord closely for cracks in the insulation and corrosion in electrical connectors. Spraying receptacles and electrical connections with an electrical contact cleaner or a metal and electrical protector will reduce corrosion and improve electrical continuity.

Inspect all wiring for proper support, sound insulation, and tight terminals, paying particular attention to portable appliance cords and plugs.

The entire AC circuitry, especially the shore power cords, should be seasonally tested for proper continuity by an experienced electrician. This will detect any shorts, open wires, or ground faults. Ground fault interrupts should be tested periodically to ensure proper operation by pressing the test/reset buttons in the center of face plate. The polarity indicator system also should be inspected for proper operation.

Generator Maintenance

The engine maintenance required on the generator is similar in many ways to the main engines. The most important factors to the generator's longevity are proper ventilation and maintenance of the fuel system, ignition system, cooling system, lubrication system and the AC alternator.

Maintenance schedules and procedures are outlined in your generator owner's manual that has been supplied with this manual. They should be followed exactly.



CORROSION ALLOWED TO BUILD ON THE ELECTRICAL CONNECTORS CAN CAUSE A POOR CONNECTION RESULTING IN SHORTS, GROUND FAULTS OR POOR GROUND CONNECTIONS. ELECTRICAL CONNECTORS SHOULD CHECKED AT LEAST ANNUALLY AND CLEANED AS REQUIRED. DO NOT ALLOW CORROSION TO BUILD ON CONNECTIONS.



ELECTRIC SHOCK CAN CAUSE SEVERE INJURY OR EVEN DEATH. THE AC AND DC ELECTRICAL SYSTEMS ALWAYS SHOULD BE DISCONNECTED FROM THE POWER SOURCE BEFORE INSPECTING OR SERVICING THE SYSTEM. NEVER SERVICE ANY COMPONENT OF AN ELECTRICAL SYSTEM WHILE IT IS ENERGIZED.

Depending on the AC power load your boat requires and the power available from the shore supply or the generator, you may not be able to operate all 120-volt AC accessories at one time. POWER MANAGEMENT PRACTICES may need to be observed, particularly when only one 30 amp shore supply outlet is available or when supplying power from the generator. You should be aware of the load each accessory draws and make sure you don't overload the circuit.

require and managing the electrical load on each circuit. An owner's manual for each AC accessory installed on your boat at the factory has been included with your boat. Additionally, you should make sure you have the manuals for accessories installed by your dealer or that you bring aboard. The specification section of the owner's manual will provide the wattage or amperage the accessory requires. Enter the load requirements in the table provided and use the information as a quick reference tool to calculate the electrical load. If only watts are given in the specifications, divide the watts by the voltage to determine the amps.

[illegible]

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

FRESH WATER SYSTEM

5.1 General

The fresh water system consists of a potable water tank, distribution lines and a distribution pump. The pump is equipped with an automatic pressure switch and is located on the transom in rear of the engine compartment. The water tank is located in the bilge below the aft berth in the cabin. The tank is filled through a labeled deck plate located near the cockpit step next to the wet bar. Shut off valves in the cold and hot water lines in the engine compartment enable the operator to turn off the water lines if necessary.




DO NOT FILL SYSTEM WITH ANYTHING OTHER THAN WATER. SHOULD THE SYSTEM BECOME CONTAMINATED WITH FUEL OR OTHER TOXIC FLUIDS, COMPONENT REPLACEMENT MAY BE NECESSARY.



WATER AND WASTE PUMPS ARE NOT DESIGNED TO PUMP FUEL AND A FIRE OR EXPLOSION COULD RESULT. DO NOT CONFUSE FUEL FILL DECK PLATES WITH THE WATER OR WASTE FILL DECK PLATES. THESE PLATES ALSO ARE LABELED ACCORDINGLY. IF GASOLINE OR DIESEL FUEL IS ACCIDENTALLY PUMPED INTO THE WATER OR WASTE TANK, DO NOT ATTEMPT TO PUMP IT OUT YOURSELF. CONTACT YOUR DEALER OR THE MONTEREY BOATS CUSTOMER SERVICE DEPARTMENT FOR ASSISTANCE IN HAVING THE FUEL PROFESSIONALLY REMOVED AND COMPONENTS OF THE FRESH WATER SYSTEM REPLACED AS NECESSARY.



Fresh Water Fill



*Hot and Cold Water Lines and Shut Off Valves
On Port Side of Engine Compartment*

5.2 Fresh Water System Operation

Fill the water supply tank slowly through the labeled deck plate. After filling the water tank, partially open all faucets. The Water Pump breaker on the cabin DC panel should be on. Allow the pump to run until all of the air is purged from the system and a steady stream of water is flowing from each outlet. Next, turn off the faucets one by one. As the pressure builds, the pump will automatically shut off.

When properly primed and activated the water system will operate much like the water system in a home. An automatic pressure sensor keeps the system pressurized. If the system has been recently filled or has not been used for an extended

period, air bubbles may accumulate at the pump and the system may have to be reprimed.

Whenever the boat is left unattended, the Water Pump breaker should be placed in the "OFF" position.



DO NOT ALLOW THE FRESH WATER PUMP TO RUN DRY. THE FRESH WATER PUMP WORKS ON DEMAND AND WILL NOT SHUT OFF AUTOMATICALLY WHEN THE TANK IS EMPTY. THIS CAN RESULT IN DAMAGE TO THE PUMP. ALWAYS TURN THE WATER PUMP BREAKER OFF WHEN THE FRESH WATER SYSTEM IS NOT IN USE.

5.3 Water Heater

The water heater is located in the engine compartment. It has a 120-volt element that is thermostatically controlled at the heater and activated by a circuit breaker located in the 120-volt panel. The water heater is also equipped with a heat exchanger that is plumbed to the water cooling system on one of the engines. The heat exchanger will heat the water in the hot water tank whenever that engine is operating.

Plumbing the heat exchanger to an engine is standard on Monterey boats. For highest efficiency, the engine heat exchanger is of the single wall type. The fresh water supply could become contaminated with engine coolant if the heat exchanger in the water heater fails.



Water Heater in Rear of Engine Compartment



MOST ENGINE COOLANT IS TOXIC AND CAN CAUSE SERIOUS INJURY OR DEATH IF IT CONTAMINATES THE FRESH WATER SUPPLY AND SOMEONE DRINKS THE WATER. NEVER DRINK THE WATER FROM THE FRESHWATER SYSTEM FAUCETS WHEN THE ENGINE HEAT EXCHANGER IS ACTIVATED IN THE WATER HEATER.

A high pressure relief valve protects the system from excessive pressure. Always make sure all air is purged from the water heater and lines before activating the water heater breaker. Refer to the water heater owner's manual for additional information.



DO NOT SUPPLY CURRENT TO AN EMPTY WATER HEATER. DAMAGE TO THE HEATER WILL RESULT. THE SYSTEM MUST BE FILLED AND PRIMED BEFORE USING THE WATER HEATER.



Shore Water Connection in Stern Equipment Locker

To use shore water, connect a hose from the shore water faucet to the shore water fitting in the stern equipment locker. Next, turn on the shore water. The pressure pump will not run and the water in the boat's water tank will not be used.

Note: The water tank will not be filled by connecting to shore water.

5.4 Shore Water Connection

The shore water connection allows the direct connection of the water system to a shore side water supply. This provides the system with a constant supply of fresh water and minimizes the pressure pump operation. A female inlet fitting is mounted in the stern equipment locker near the AC inlet plugs. A pressure reducer is installed in the system along with two check valves. One check valve keeps water from running out of the shore water inlet fitting when the pressure pump operates. The second prevents hot water from mixing with the cold water.



DO NOT MODIFY OR CHANGE THE SHORE WATER INLET CONNECTOR WITH ANOTHER TYPE WITHOUT CONSULTING MONTEREY BOATS CUSTOMER SERVICE OR YOUR DEALER. THE USE OF THE WRONG TYPE OF INLET CONNECTOR CAN DAMAGE THE FRESH WATER SYSTEM.



A SHORE WATER CONNECTION PROVIDES AN UNLIMITED SUPPLY OF WATER THAT COULD SINK THE BOAT. YOU SHOULD MONITOR THE SYSTEM FOR LEAKS WHEN IT IS CONNECTED AND ALWAYS TURN THE SHORE WATER SUPPLY VALVE OFF WHEN LEAVING THE BOAT UNATTENDED.

5.5 Shower Operation

There is a shower located in each head compartment and at the transom on the port side, near the transom door. Each shower has hot and cold water and a retractable shower head with an on/off valve.

Make sure the Water Pump breaker in the DC breaker panel is on, then turn the water on. Adjust the hot and cold water faucet until the desired temperature is obtained. Some minor variations in the water temperature may occur as the pressure pump cycles. To conserve water, use the valve on the shower head to turn the water on and off as you shower.

Shower water is drained from the head compartments by a sump pump system located below the aft berth in the cabin. An automatic float switch in the shower sump controls the pump. The pump is activated and protected by the shower sump pump circuit breaker in the engine compartment breaker panel. After showering, let the cold water flow for a period of time to flush the drainage system of soap residue. It is essential that the shower drain strainer is cleaned regularly and the sump is inspected periodically for accumulated debris that needs to be removed.



Master Head Compartment Shower

5.6 Fresh Water System Maintenance

Information and owner's manuals supplied with water system components is included with this manual. Refer to this information for additional operation and service data.

The following items should be done routinely to maintain your fresh water system:

- Periodically remove and clean the water strainer located near the intake side of the fresh water pump.
- Remove the filter screens from the faucet spouts and eliminate any accumulation of debris. A build up of debris can cause the pump to cycle excessively.
- Periodically remove the lid on the shower sump assembly located below the aft berth in the cabin. Clean debris from the sump and flush with clean water.
- Periodically spray the pumps and metal components with a metal protector.
- The batteries must be properly maintained and charged. Operating the pressure pump from a battery with a low charge could lead to pump failure.



Transom Shower at Starboard Side of Swim Platform

- Add a commercially available potable water conditioner to the water tank to keep it fresh.

Note: The freshwater system must be properly winterized prior to winter lay-up. Refer to the section on winterizing for more information.

Sanitizing the Fresh Water Tank

The fresh water system should be sanitized if it has not been used for a long period or you are unsure of the quality of the water in the system.

The following steps can be used to sanitize the system:

- Activate the system, open all hot and cold faucets and pump out as much water as you can.
- Make a chlorine solution by mixing two ounces of household chlorine bleach in a gallon of water. This mixture will treat approximately fifteen gallons. If the water tank on your boat is larger or smaller than 15 gallons, then adjust the mixture accordingly. Always mix the chlorine with water in a separate container first and never add straight chlorine to the fresh water tank.
- Fill the water tank half full with fresh water, then pour the mixture into the water tank and top off the tank.
- Activate the system and allow the water to run for about one minute at each faucet. Let the treated water stand for 4-6 hours.



Fresh Water Pump and Strainer

- Drain the system by pumping it dry and flush with several tank fulls of fresh water.
- The system should now be sanitized and can be filled with fresh water. If the chlorine smell is still strong, it should be flushed several more times with fresh water.

Note: The quality of the water in marine freshwater systems can be questionable. We recommend that you avoid using the water from the fresh water system for drinking and cooking. You should only use bottled water for these purposes.

RAW WATER SYSTEM

6.1 General

In the raw or sea water systems, all water pumps are supplied by hoses connected to ball valves and thru-hull fittings located in the in the engine compartment bilge. Always make sure the ball valves are open before attempting to operate any component of the raw water system.

The air conditioner uses a 120-volt AC sea water supply pump. This is the only 120-volt AC pump in the system and it is automatically activated when the air conditioning or heating system is in use.

Priming the System

The intake for the air conditioner sea water pump is equipped with a scoop and ball valve. If the pump runs but will not prime after cleaning the strainer or at the time of launching, make sure the valve is open. If the pump still won't prime, it may be air locked. Make sure the valve is open and run the boat at or above 15 M.P.H. The water pressure from the scoop will force the trapped air through the pump and allow it to prime. If this procedure doesn't work, contact your Monterey dealer.

Closing the thru-hull ball valves before the boat is hauled from the water will help to eliminate air locks in raw water systems.

Note: It may be necessary to reprime the raw water system if the system is not used for an extended period and at the time of launching.

6.2 Air Conditioning

The air conditioning units are self-contained and sea water cooled. An AC centrifugal raw water pump supplies sea water that cools both condensing units as it circulates through the system and is discharged overboard. The pump is located in the stern bilge below the access hatch in the engine compartment floor. It is activated whenever AC current is available and either air conditioning unit is operating.

Sea water is supplied to the pump from a thru hull fitting located in the hull near the pump. A sea strainer between the pump and thru hull fitting protects the system from contaminants that



Air Conditioning Pump



Air Conditioner Sea Strainer

could damage the pump or the air conditioning system. Make sure the sea water pump receives adequate sea water by periodically cleaning the sea strainer basket.

Cleaning the Sea Strainer

- Turn both air conditioner units off at the control panels. Then turn the air conditioning breakers in the AC panel off.
- Close the water intake valve.
- Open the top of the strainer and remove the screen.

- Thoroughly flush the screen and the inside of the strainer to remove foreign matter.
- Lubricate the seal.
- Reassemble the strainer making sure that all fasteners are tight.
- Open the intake valve.
- Activate the air conditioner units and inspect the strainer for leaks.
- If the system will not prime, follow the procedure for priming the system in this chapter.

You should refer to the air conditioner owner's manual for more information on the operation and maintenance of the air conditioner.

6.3 Raw Water System Maintenance

The following items should be done routinely to help maintain your raw water system:

- Check hoses, particularly the sea water supply lines, for signs of deterioration.
- Remove and clean the sea water strainer for the air conditioner as required.
- Spray pumps and thru-hull valves with a protective oil periodically.
- Operate all thru-hull valves at least once a month to keep them operating properly.



SHOULD A HOSE RUPTURE, TURN THE PUMP OFF IMMEDIATELY. ALWAYS CLOSE THE THRU-HULL VALVE WHEN PERFORMING MAINTENANCE ON A SEA WATER PUMP.

THE RAW WATER SYSTEM MUST BE PROPERLY WINTERIZED PRIOR TO WINTER LAY-UP. SEE SECTION ON WINTERIZING.



Air Conditioner Sea Strainer Screen



Air Conditioner Sea Strainer



Air Conditioner Sea cock

DRAINAGE SYSTEMS

7.1 General

Most water is drained by gravity to overboard thru-hull fittings located in the hull sides above the waterline. You should check the drain system frequently to ensure it is free flowing and that the hoses on the thru-hull fittings are secure and not leaking.

7.2 Bilge Drainage

There are three bilge pumps, (cabin, emergency, and aft,) that are activated automatically by float switches located next to the pumps. The bilge pumps are activated both manually by switches in the helm station and automatically by float switches located next to the pump or built into the pump. The automatic float switches are connected to the house battery. They are protected by “push to reset” circuit breakers in the engine compartment breaker panel and remain activated when the battery switches are in the “OFF” position and the batteries are connected. The manual switches are supplied current when the house battery switch is activated. They are protected by a breaker in the helm switch breaker panel.

All bilge pumps pump water out of thru-hulls located above the waterline in the starboard side of the hull. The aft bilge pump and built in automatic switch are located near the transom, aft of the engines, the emergency bilge pump and automatic switch are below the forward access hatch in the engine compartment floor and the forward pump and built in automatic switch are located in the bilge below the aft berth in the cabin.

The manual bilge pump switches should be activated briefly each time the boat is used. This will ensure that the pumps are operating properly and increase the service life of the pumps. The automatic switches should be manually activated periodically, by turning the test knob on the side of external switches and flooding the bilge with a hose on pumps with built in automatic switches, to verify operation. This is particularly important before operating the boat offshore.

The automatic float switch for the emergency bilge pump is mounted above the normal operating range of the aft bilge pump automatic switch. It activates an alarm if the bilge water level rises



Aft Bilge Pump and Automatic Float Switch



*Automatic Float Switch for High Water Alarm and Emergency Bilge Pump
Located Below the Engine Compartment Floor.*

above the normal operating range of the bilge pump automatic switches. The alarm switch is connected to the house battery and is protected by the emergency pump “push to reset” breaker located in the engine compartment breaker panel. It remains activated when the battery switches are in the “OFF” position and the batteries are connected.

When the boat is out of the water, the bilge can be drained by a thru-hull drain located in the hull near the transom. The plug should be removed

whenever the boat is hauled out of the water and installed just prior to launching. It is important to check the drain plug regularly to make sure it is tight.



A LOOSE DRAIN PLUG WILL ALLOW SEAWATER TO ENTER THE BILGE AND COULD CAUSE THE BOAT TO SINK. IT IS VERY IMPORTANT TO CHECK THE DRAIN PLUG FREQUENTLY TO ENSURE IT IS PROPERLY TIGHTENED.

Note: See Electrical Systems for additional information on bilge pump operation.

Note: Any oil spilled in the bilge must be thoroughly removed and properly disposed of before operating the bilge pump. The discharge of oil from the bilge is illegal and subject to a fine.



THE FEDERAL WATER POLLUTION CONTROL ACT PROHIBITS THE DISCHARGE OF OIL OR OILY WASTE INTO OR UPON THE NAVIGABLE WATERS OF THE UNITED STATES OR THE WATERS OF THE CONTIGUOUS ZONE IF SUCH DISCHARGE CAUSES A FILM OR SHEEN UPON, OR A DISCOLORATION OF THE SURFACE OF THE WATER, OR CAUSES A SLUDGE OR EMULSION BENEATH THE SURFACE OF THE WATER. VIOLATORS ARE SUBJECT TO A PENALTY OF \$10,000.



Engine Compartment Hatch, Day Hatch and Cockpit Drain System

7.3 Cockpit and Deck Drains

Cockpit and Engine Compartment

Water is drained from the cockpit through the transom door opening and the drain system for the engine compartment hatch. The engine compartment hatch is equipped with a gutter that drains the water to thru-hull fittings in the hull side. A flap built into the thru-hull fitting on side of the hull reduces the surge of sea water through the scupper and into the cockpit.

Water is channeled away from the engine compartment day hatch by a gutter system. The water then drains to the thru-hull fittings and then overboard.

Wet Bar Sink Drains

The sink and ice maker are drained by gravity to a thru-hull fitting in the hull side. These drains should be flushed out periodically to keep them clean and free flowing.



Rope Locker Drains in Bow

Bridge Deck and Cockpit Storage Compartments

The storage boxes, located below the cockpit lounge seats, are drained by gravity to the cockpit deck. Water drains from the bridge deck to the stern cockpit and then overboard through the engine compartment hatch drain system.

Rope Locker Drains

The rope locker drains overboard through fittings in the port and starboard hull sides. It is impor-

tant to inspect the drain frequently to remove any accumulated debris.

7.4 Cabin Drains

The galley sink, head sinks, and refrigerator are drained by gravity to thru-hull fittings in the starboard hull side.

The showers and air conditioner condensation pans are drained by a sump pump system. An automatic float switch in the sump controls the pump. The sump pump is protected by the sump pump breaker in the engine compartment breaker panel. The sump system is activated whenever the batteries are connected to ensure the showers and air conditioners will drain properly whenever they are used. After showering, let the cold water flow for a period of time to flush the drainage system of soap residue.

The sump system is located below the aft berth in the cabin and accessed by removing the mattress and opening the access hatch. The sump has a removable lid to allow the system to be inspected and serviced. It is essential that the sump system be inspected periodically and any accumulated debris removed. Manually activate the system to verify operation.

Optional Grey Water System

If your boat is equipped with this option, all sink drains and the head shower are drained by the shower sump system which pumps the waste water to the waste/grey water holding tank. The air conditioner condensation pans are connected to a separate sump pump system that pumps the accumulated condensation overboard thru a fitting in the hull side. Both sump systems are controlled by an automatic float switch in the sump and are protected by individual circuit breakers in the battery switch panel. They are activated whenever the house battery switch is on and are located below the forward berth in the aft cabin.

The fluid level in the waste/grey water holding tank is monitored by the "Tank Watch Monitor" in the head compartments. When the holding tank is full, it must be pumped out by an approved waste dumping station. You should monitor the waste level carefully and not allow the tank to become full. The toilets will not flush when the tank is full and an overfilled holding tank will force waste into the vent filter. This will clog the filter, prevent

the sinks from draining and could cause damage to the holding tank. It will also cause unpleasant odors in the cabin.

Note: The overboard macerator discharge pump option for the waste holding tank is not available with the grey water system.

7.5 Drainage System Maintenance

It is essential that the following items be done periodically to maintain proper drainage of your boat:

- Clean the cockpit and bridge deck drain rails with a hose to remove debris that can block water drainage.
- Clean the bilge pump strainers of debris and check the bilge for foreign material that can cause the automatic switch to malfunction.
- Frequently test the automatic bilge pump switches for proper operation. This is accomplished by turning the knob on the external float switch until the pump is activated. You can also use a garden hose to raise the water level in the bilge until the it is high enough to activate the external float switches or pumps with built in automatic switches.
- Flush all gravity drains with fresh water to keep them clean and free flowing.
- Flush the drain in the air conditioning condensation pans with fresh water periodically to remove mold and debris that can accumulate and block drainage to the sump system.
- Clean and inspect the shower and air conditioning drain sump system. Remove accumulated debris and flush with fresh water. Frequently test the automatic pump switch for proper operation.

Note: All drains and pumps must be properly winterized before winter lay-up.

Note: Never use harsh chemical drain cleaners in marine drain systems. Permanent damage to the hoses and fittings may result.

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

VENTILATION SYSTEM

8.1 Cabin Ventilation

Ventilation to the cabin area is provided by three deck hatches. Additionally, there is a 12-volt exhaust blower in each head compartment that provides forced ventilation to that area whenever the blower is activated by the switch on the head compartment wall.

Deck Hatches

The deck hatches are supported in the open position by one or two adjustable hatch adjusters. They are secured in the closed position by one or two cam levers on the inside of the hatch. There is a sliding lock on each cam lever to prevent them from opening accidentally.

To open a hatch, release the lock and rotate the cam lever to the open position. Raise the hatch and secure it by tightening the knob on the hatch lifter. To close the hatch, loosen the hatch adjuster and lower the hatch. Secure in the closed position with the two cam levers and slide locks.

The cam levers can secure the hatch in two positions, the vent position or fully closed. The hatch is secured in the vent position by opening hatch slightly until the cam levers align with the notch in the hatch frame just above the fully closed, watertight position. With the cam levers secured in this position, the hatch will be open just enough to let air circulate into the cabin. Always secure the hatch in the water tight position when leaving the boat unattended or when running offshore.

When the aft hatches above the galley and forward head compartment are open, a removable screen can be installed in the hatch trim ring to prevent insects from entering the cabin. The screen is secured in place by spring tension built into the screen. The screen must be removed to access the cam levers to open or close the hatch.

The main hatch above the V-berth is equipped with a retractable sunshade and screen. To use the screen, pull the plastic tab for the screen on the side of the hatch and attach it to the plastic tab on the other side of the hatch. To use the sunshade, pull the plastic tab for the sunshade and attach it to the plastic tab on the other side hatch. When the tabs are attached, they can slide in either direction to select the screen or the sunshade.



V-Berth Deck Hatch



Galley Hatch Fully Closed Screen Installed



Galley Deck Hatch Secured in Vent Position



Port Window

Disconnect the tabs to store the screen and the sunshade or to open and close the hatch.

Port Windows

Opening port windows are located in V-berth and main salon. Each window opens to provide ventilation into the cabin area and is equipped with a removable screen.

The windows are secured by adjustable cam levers. The cam levers should be adjusted so they are tight enough to seal the windows in the closed position, but not so tight that the window becomes difficult to secure.

Always make sure the windows are closed and secured with the cam levers whenever the boat is underway. Sea spray could enter the cabin through an open window and damage upholstery, woodwork and cabin equipment.

8.2 Windshield Ventilation

Ventilation through the windshield is provided by an opening panel in the center section of the windshield. The center vent panel is opened and closed by an electric actuator controlled by the "Windshield" switch in the helm switch panel. To open the vent, press the switch and open the panel to the desired position. To close the panel, press the switch until the panel is completely closed. A clutch in the actuator will slip when the actuator reaches the full open or closed position to prevent damage to the windshield or the actuator. Always release the switch immediately when vent panel reaches the full open or closed position to prevent excessive slipping of the clutch.

8.3 Carbon Monoxide and Proper Ventilation




FAILURE TO PROPERLY VENTILATE THE BOAT WHILE THE ENGINES ARE RUNNING MAY PERMIT CARBON MONOXIDE TO ACCUMULATE WITHIN THE CABIN AND OPEN AREAS OF YOUR BOAT. CARBON MONOXIDE IS A COLORLESS AND ODORLESS GAS THAT IS LETHAL WHEN INHALED. CARE MUST BE TAKEN TO PROPERLY VENTILATE THE BOAT AND TO AVOID CARBON MONOXIDE FROM ACCUMULATING IN THE BOAT WHENEVER AN ENGINE IS RUNNING.




Windshield Vent Panel and Electric Actuator


A by-product of combustion, carbon monoxide (CO) is invisible, tasteless, odorless, and is produced by all engines and gas heating and cooking appliances. The most common sources of CO on boats are gasoline engines, auxiliary generators and propane or butane stoves. These produce large amounts of CO and should never be operated while sleeping. The hazard also may be created by a boat nearby whose exhaust fumes are entering your boat. Boats also have a problem due to the "station wagon effect" where engine exhaust fumes are captured in the vacuum or low pressure area, usually the cockpit, bridge deck and cabin, that can be created by the forward speed of the boat.




Onboard Generator Exhaust - exhaust accumulates because of bulkhead.




Nearby Generator Exhaust - wind carries exhaust to the other boat




Back Drafting / Station Wagon Effect - at cruising speed with no forward ventilation



Back Drafting / Station Wagon Effect - at cruising speed with canvas closed



Slow Speed or Boat Stopped w/ engines running - CO can accumulate in cabin, cockpit & bridge



Desired Air Flow Through the Boat

Boats underway should close all aft facing hatches and doors. The forward facing deck hatches should be open whenever possible to help pressurize the living spaces of the boat. No sleeping in the cabin should be permitted while underway. Proper ventilation should be maintained on the bridge deck by opening windshield or forward clear connector vents, as far as possible to help pressurize the cockpit area. The canvas drop or aft curtain must be removed and the side curtains should be opened or removed to increase air flow and maintain proper ventilation whenever the engines are running. **Under no circumstances should the engines be operating with side curtains closed and the aft or drop curtain installed.**

Extreme caution must be taken while at anchor or in a slip when an auxiliary power generator is operating. Wind still nights can easily allow exhaust fumes, containing high concentrations of CO, from the generator on your boat or from an adjacent boat's generator to enter the boat. The exhaust fumes may enter your boat through open hatches or windows.

Carbon monoxide detectors have been installed in your cabin as standard equipment. While a CO detector enhances your protection from CO poisoning, it does not guarantee it will not occur. Do not use the carbon monoxide detector as a replacement for ordinary precautions or periodic inspections of equipment. Never rely on alarm systems to save your life, common sense is still prudent and necessary. Remember, the operator of the boat carries the ultimate responsibility to make sure the boat is properly ventilated and the passengers are not exposed to dangerous levels of carbon monoxide. You should always be alert to the symptoms and early warning signs of carbon monoxide poisoning. You also should read the "Carbon Monoxide Monitoring System" in the Safety Equipment chapter of this manual, and the owner's manual supplied by the CO detector manufacturer for operation instructions and additional information regarding the hazards and symptoms of carbon monoxide poisoning.



ACTIVATION OF THE CARBON MONOXIDE DETECTOR INDICATES THE PRESENCE OF CARBON MONOXIDE (CO) WHICH CAN BE FATAL. EVACUATE THE CABIN IMMEDIATELY. DO A HEAD COUNT TO CHECK THAT ALL PERSONS ARE ACCOUNTED FOR. DO NOT REENTER THE CABIN UNTIL IT HAS BEEN AIRED OUT AND THE PROBLEM FOUND AND CORRECTED.



Engine Compartment Vent



PERIODICALLY TEST THE CARBON MONOXIDE ALARMS PER THE MANUFACTURER'S INSTRUCTIONS. PLEASE REFER TO THE CARBON MONOXIDE ALARM MANUAL OR CONTACT THE MANUFACTURER FOR MORE INFORMATION ON MAINTAINING AND CALIBRATING THE ALARM.

8.4 Engine Compartment Ventilation

All Monterey inboard boats are equipped with an engine compartment ventilation system consisting of intake ducts and exhaust blowers. The ventilation system is designed to meet or exceed the requirements of the United States Coast Guard in effect at the time of manufacture and remove fuel vapors and excess heat from the engine room.

Free Air System

A flow of air into the engine compartment is provided by two vents located on either side of the deck. Exhaust ventilation designed into the vents provides a flow of air out of the engine compartment. The exhaust area of the vents have ducts that reach to the lower part of the engine compartment. This provides adequate air movement while operating at or near cruise speeds.

The vents are designed with special baffles that prevent sea water or spray from entering the engine compartment while providing adequate air movement for the engines.

Forced Ventilation

Two electric blowers provide ventilation to the engine compartment while operating below cruise speed or running the generator. They are activated by a switch at the helm or in the cabin DC

breaker panel. The blowers are located in the vent hoses on the port and starboard side of the engine compartment. When activated, the blowers remove bilge fumes and excessive heat through the bilge exhaust vents. Refer to the Electrical Systems chapter for more information on blower operation.

Inspect the blowers frequently to make sure they are operating properly. Always replace worn or defective components with new components of the same type. Refer to the Electrical Systems chapter for more information on blower operation.



ALWAYS RUN THE EXHAUST BLOWERS WHEN OPERATING THE BOAT BELOW CRUISE SPEEDS OR WHEN THE GENERATOR IS RUNNING TO ENSURE ADEQUATE VENTILATION AND COOLING OF THE ENGINE COMPARTMENT.



DO NOT OBSTRUCT OR MODIFY THE VENTILATION SYSTEM.

8.5 Maintenance

- Periodically lubricate all hinges and latch assemblies with a light oil.
- Periodically clean and coat gasket materials with silicone to help keep them pliable.

- The opening cabin deck hatches and the cabin door are made of acrylic plastic glass. Acrylic glass scratches easily. Never use a dry cloth or glass cleaning solutions on acrylic glass. Use a soft cloth and mild soap and water for routine cleaning. Solvents and products containing ammonia can permanently damage acrylic glass. Please refer to the Routine Maintenance chapter for more information on the proper maintenance for acrylic plastic glass.
- Periodic inspection and cleaning of the engine compartment ventilation ducts is necessary to ensure adequate air circulation. A buildup of leaves, twigs, or other debris can severely reduce ventilation. It also is important to be sure that the drains in the vent baffles are open to prevent excessive sea water from accumulating in the vents and overflowing into the engine compartment.
- The bilge blowers are permanently lubricated and require no maintenance. Blower operation can and should be tested by placing a hand over the exhaust vents. Do not rely on the sound of the blowers. A substantial amount of air should be exhausted by each blower. Frequently check the intake vents for obstructions, preferably before each cruise.

Note: Should blower noise become excessive, the source of the noise should be found and corrected before operating the boat.

EXTERIOR EQUIPMENT

*Deck Rails, Hardware and Accessories*

9.1 Deck

Rails and Deck Hardware

The rail system and hardware fittings have been selected and installed to perform specific functions. Bow and hand rails are installed to provide a hand hold in certain areas of the boat. You should make sure you keep at least one hand on the hand holds as you move about the boat.

The stern of your boat is equipped with cleats that are retractable and flush with the deck when not in use. To use the cleats, pull up on the center of the cleat until it locks in the mooring position. Mooring lines should be secured to the cleats and not to rails or stanchions. Be sure a clear lead exists when running dock lines or anchor lines. A line inadvertently run around a stanchion or over the rail could cause damage.

Note: All fittings must be inspected periodically for loose fit or wear and damage. Any problems should be corrected immediately.



MONTEREY BOATS ARE NOT EQUIPPED WITH HARDWARE DESIGNED FOR TOWING PURPOSES. THE MOORING CLEATS ARE NOT TO BE USED FOR TOWING ANOTHER VESSEL OR HAVING THIS BOAT TOWED.



PASSENGERS RIDING ON THE FORWARD DECK OR THE SWIM PLATFORM WHILE THE BOAT IS UNDERWAY COULD BE THROWN OVERBOARD BY WAVE ACTION OR AN UNEXPECTED MANEUVER CAUSING SEVERE INJURY OR EVEN DEATH.

THE ONLY AREA TO BE OCCUPIED IS THE COCKPIT AND BRIDGE DECK WHEN THE BOAT IS OPERATING. NEVER ALLOW PASSENGERS TO BE ON THE FORWARD DECK OR THE SWIM PLATFORM WHILE THE ENGINES ARE RUNNING.

Stainless Steel Bow Roller

The bow roller assembly is mounted to the deck at the bow and allows the anchor to be operated and stored at the roller. A stainless plate on the hull below the anchor helps to prevent damage from the anchor banging the hull as it is hauled into the roller assembly.

The roller is designed for a Danforth Style or Delta plow anchor. The anchor line is stored in the rope locker and routed out the locker through the windlass to the roller and connected to the anchor chain. A cleat or chain binder is provided on the deck near the roller to secure the anchor. Always make sure the anchor is properly secured when it is in the stored position on the bow roller.

Anchor Rope Locker

The anchor rope locker is in the bow of the boat and accessed through a hatch in the deck. The anchor line is always stored in the rope locker. The rope locker is not designed for anchor storage and Monterey recommends that extra anchors be stored in a storage compartment as far aft as possible such as below the aft sun island or cockpit lounge seat. If an anchor is stored in the rope locker, it must be properly secured to prevent it from bouncing in the locker and causing damage to the hull or anchor locker.

The anchor locker is drained by thru-hull fittings in the hull sides near the bottom of the locker. It is very important to check the drains frequently to make sure they are clean and free flowing.



*Anchor Locker Hatch, Optional Spot Light,
Anchor and Bow Roller*



A LOOSE ANCHOR IN THE ROPE LOCKER WILL BOUNCE AND CAN DAMAGE THE BOAT. THE ANCHOR MUST BE POSITIONED SO IT DOES NOT REST AGAINST THE HULL SIDES AND BE PROPERLY SECURED AT ALL TIMES WHEN IT IS STORED IN THE ROPE LOCKER. DAMAGE RESULTING FROM THE ANCHOR BOUNCING IN THE ROPE LOCKER IS NOT COVERED BY THE MONTEREY WARRANTY.

Periodically remove the anchor line from the rope locker, rinse it with fresh water and allow it to dry in the sun. Cleaning the anchor line regularly will reduce odors in the rope locker and increase the life of the line.

The line should also be inspected for abrasions or signs of deterioration. Replace the line if it shows any sign of damage or deterioration. If anchor lines need to be replaced, it is important to replace the anchor line with a new line of the type recommended or supplied by the windlass manufacturer.



Rope Locker Hatch, Windlass, Chain Binder and Anchor Line Cleat

Windlass

The windlass is mounted to the deck near the rear of the anchor roller assembly above the rope locker. The anchor is stored on the roller assembly and is raised and lowered by the windlass. The anchor line is stored in the rope locker and routed out through the windlass to the anchor chain.

The anchor is lowered by releasing the anchor from the cleat or chain binder near the roller and operating a "DOWN" control at the helm, or the foot switch at the bow. The windlass control switch is activated and protected by a "push to



*Windlass, Chain Binder, Windlass Deck Switches
and Optional Spot Light*

reset" breaker in the helm switch breaker panel. The main circuit for the windlass is protected by a heavy duty circuit breaker near the engine compartment breaker panel.

After the anchor is set, the windlass must not be left to take the entire force from the anchor line. Boats lying to their anchor in a high swell or heavy weather conditions will snub on the line. This can cause slippage or apply excessive loads to the windlass. The line should be made fast to a bow cleat to relieve the load on the windlass.

The anchor is hauled in by releasing the line from the bow cleat and operating the "UP" control at the helm or the foot switch on the deck near the windlass. Once the anchor is retrieved, independently secure the anchor to the cleat or chain binder to prevent it from being accidentally released. This is especially important while the boat is under way.

The windlass manufacturer provides an owner's manual with its product. It is extremely important that you read the manual and become familiar with the proper care and operation of the windlass.



A WINDLASS MUST BE USED WITH CARE. IT IS EXTREMELY IMPORTANT THAT YOU READ THE OWNER'S MANUAL AND BECOME FAMILIAR WITH THE SAFETY INSTRUCTIONS AND PROPER OPERATION OF THE WINDLASS BEFORE USING IT WITH YOUR BOAT. ALWAYS ENSURE THAT LIMBS, FINGERS, HAIR AND CLOTHING ARE KEPT CLEAR OF THE WINDLASS AND ANCHOR LINE DURING OPERATION.



DO NOT USE A WINDLASS AS A SOLE MEANS OF SECURING AN ANCHOR IN THE BOW PULPIT. ALWAYS SECURE THE ANCHOR LINE TO A CLEAT OR CHAIN BINDER BEFORE OPERATING YOUR BOAT.

Windshield

Your boat is equipped with a stainless steel windshield with tinted glass and windshield wipers. The front and side wing panels are tempered safety glass. The windshield wipers should only be used when the windshield is wet. The windshield glass can be scratched by activating the wipers when there is dried salt or dirt on the windshield.

Ventilation through the windshield is provided by an opening center panel that is opened and



Windshield

closed by an electric actuator controlled by the Windshield Vent switch in the helm. Refer to the Ventilation chapter for instructions on operating the windshield vent.

The stainless steel windshield frame is polished. Polished stainless steel is very durable and provides excellent resistance to the corrosive effects of saltwater, however it must be maintained properly and certain precautions must be observed when mounting snaps or hardware to the windshield.

The windshield should be washed after each use with soap and water to keep it clean. Saltwater allowed to remain on the windshield frame will eventually begin to attack the stainless and cause rust stains, usually around fasteners and hardware mounted to the windshield. Snaps or any hardware mounted to the windshield must be properly sealed and isolated with caulk or a Teflon sealer to prevent salty moisture and galvanic corrosion from damaging the stainless frame. Poor maintenance or improperly mounted hardware and snaps can void the warranty on the windshield.

Refer to the Routine Maintenance chapter for more information on the care and maintenance of stainless steel.

Sun Lounge Cushion

A removable sun lounge cushion is located on the deck. The cushion is secured to the deck by a special slide track on the forward end of the cushion and snaps on the rear. The cushion should be removed and stored in the cabin whenever the boat is not being used and installed before each cruise.

The cushion is installed by sliding the male slide track on the forward end of the cushion into the female slide track on the deck. Center the cushion and secure the rear with the snaps. Make sure

the cushion is properly installed prior to leaving the dock or mooring. The cushion is large and somewhat awkward, making it difficult to install once the boat is underway. If it is not secured properly, the cushion could be caught by the wind and blown overboard or into the cockpit, causing damage to the boat or injury to passengers.

The sun lounge cushion is intended to be used only when the boat is at the dock or at anchor. It should never be used while cruising.



PASSENGERS RIDING ON THE DECK WHILE CRUISING RESTRICT THE OPERATOR'S VISIBILITY AND COULD BE THROWN OVERBOARD BY WAVE ACTION OR AN UNEXPECTED MANEUVER FROM THE HELM. THIS IS A FREQUENT CAUSE OF ACCIDENTS. NEVER ALLOW PASSENGERS TO RIDE ON THE DECK WHILE THE BOAT IS CRUISING.



Sun Lounge Cushion, Skylight, Deck Grab Rails and Deck Hatches

9.2 **Hull** **Swim Platform**

Your boat is equipped with an integral, fiberglass swim platform located in the stern of the boat. An optional teak inlay enhances the appearance of the boat and provides an excellent nonskid surface.

It is important to clean and oil the teak periodically with a commercial teak cleaner and oil, typically once or twice a year. Be careful to follow the manufacturer's directions exactly as some cleaners and oils may damage surrounding gelcoat, vinyl or aluminum. Use only a stiff brush, stainless wool, a "scotchbrite pad" or bronze wool for cleaning teak.

Never use steel wool on a boat as the bits of steel will get into the pores of the wood and gelcoat and cause rust stains.

Note: Avoid varnishing teak platforms. Varnish will not adhere well to teak and will make the surface very slippery when it is wet.

A telescoping boarding ladder is recessed into the swim platform under a special hatch. To use the ladder, make sure the engines are off and open the hatch in the middle of the swim platform. Rotate the ladder out of the recess to the down position. Pull the ladder out to the open position.



Swim Platform and Ladder



*Transom Storage Compartment, Shore Connectors
Ladder and Transom Door*

The ladder must be retracted and folded into the recess before starting the engines.



MOVING PROPELLERS ARE DANGEROUS. THEY CAN CAUSE DEATH, LOSS OF LIMBS, OR OTHER SEVERE INJURY. DO NOT USE THE SWIM PLATFORM OR SWIM LADDER WHILE THE ENGINES ARE RUNNING. STOP THE ENGINES IF DIVERS OR SWIMMERS ARE ATTEMPTING TO BOARD. ALWAYS PROPERLY STORE THE LADDER BEFORE STARTING THE ENGINES.

Transom Storage Compartment and Shore Connectors

There is a storage compartment just forward of the swim platform, below the rear of the sun island. An equipment compartment on the port side of the transom provides protection for the shore connections for the 120-volt AC system, TV, telephone and shore water which are located in this compartment. A large cut out in each door for the equipment compartment allows the doors to be closed with the shore cords and hoses are attached to the utilities at the dock. The doors protect the inlet plugs from the elements and should be closed and latched at all times. They should only be open when making the connection to shore utilities.

The compartment below the sun island provides storage for the shore cords, water hoses, and fenders. It is drained by gravity to the engine hatch drain system. Gas charged springs on the storage compartment hatch help lift the hatch and support it when it is in the open position. A lift to release latch secures the hatch when it is closed and a LED light comes on when it is open.



DO NOT STORE FUEL OR FLAMMABLE LIQUIDS IN THE TRANSM STORAGE COMPARTMENT. VENTILATION WAS NOT PROVIDED FOR EXPLOSIVE VAPORS.

Trim Tabs

The trim actuators are mounted to the hull at the transom. The trim tabs are an important part of the control systems. Please refer to the Helm Control Systems chapter for detailed information on the trim tabs.



Trim Tab, Transom Anode and Optional Underwater Light



Optional Underwater Light

Underwater Lights (Optional)

Your boat may be equipped with optional underwater lights mount in the transom. The underwater lights must only be used when the boat is in the water and the lights are submerged.



DO NOT OPERATE LIGHTS OUT OF THE WATER. OPERATING THE LIGHTS WHEN THE BOAT IS OUT OF THE WATER CAN CAUSE EXCESSIVE TEMPERATURE BUILDUP IN THE FIXTURE RESULTING IN DAMAGE TO SEALS OR POSSIBLE FAILURE OF THE SEAL BETWEEN THE LIGHT HOUSING AND HULL.

9.3 Cockpit

General

Some of the hatches and doors in the cockpit are secured with special flush mounted, twist lock latches with handles that store flush in the latch. Others are secured with push to close latches. Gas charged springs are used on some hatches that help raise the hatches and hold them in the open position.

The latch handles on the twist lock latches can be stored in the open or secured positions. There is a red dot in the handle that indicates that the latch is in the open position and it is not secure. Always make sure the hatches are closed with the latches in the secured position before operating the boat above idle speed.



Unlatched



Latched



IN CERTAIN CONDITIONS, OPEN EXTERIOR DOORS AND HATCHES THAT ARE NOT SECURED PROPERLY CAN SLAM CLOSED UNEXPECTEDLY AND CAUSE INJURY TO PASSENGERS OR DAMAGE TO THE BOAT. MOST DOORS AND HATCHES ARE EQUIPPED WITH SPECIAL FASTENERS, HATCH LIFTERS, OR SNAPS AND/OR STRAPS, TO SECURE THEM IN THE OPEN POSITION. ALWAYS MAKE SURE THAT THESE HATCHES AND DOORS ARE PROPERLY SECURED WHENEVER THEY ARE IN THE OPEN POSITION.



Transom Door

Transom Door

A transom door is incorporated into the rear of the cockpit. The door is secured automatically in the open or closed position by a special notched hinge. Lifting the door releases it and allows the door to be moved to the full open or closed position where the weight of the door causes it to drop into the notch securing it in that position. When closing the transom door, make sure it has dropped completely into the notch to prevent it from opening accidentally.

The transom door should be opened only when the boat is not in motion. The door must be secured in either the full open or full closed position. Never leave the transom door unsecured.

Note: Periodically inspect the transom door fittings for wear, damage, or loose fit. Any problems should be inspected and corrected immediately.



OPERATING THE BOAT UNDER POWER WITH THE TRANSOM DOOR OPEN MAY ALLOW PERSONS TO FALL OVERBOARD AND INTO BOAT PROPELLERS OR TO BE LOST IN OPEN WATER. ALWAYS CHECK TO MAKE SURE THE TRANSOM DOOR IS PROPERLY CLOSED AND SECURED BEFORE STARTING THE ENGINES AND NEVER OPERATE THE BOAT UNDER POWER WITH THE TRANSOM DOOR OPEN.

Engine Access

Access to the engines is provided by a day hatch, located in the center of the cockpit, and by raising the cockpit deck and stern sun island above the engine room. The cockpit deck and sun island is hinged at the rear and raised by an electric hatch lifter activated by a switch in the helm switch panel. The deck section and sun island is designed to raise high enough to provide adequate access to service the components in the engine compartment. Always make sure the cockpit deck is completely closed and the day hatch is closed and properly latched before operating the boat.

Wet bar

The wet bar is equipped with a sink, optional electric grill, cup holders, a refrigerator or optional ice maker and a storage area. The counter top and sink cover is made of Karadon. A grab rail on the wet bar provides a hand hold when moving about the cockpit.

The sink is plumbed to the fresh water system and is drained by gravity to a thru hull fitting in the hull side above the waterline. To use the sink, open the hinged the Karadon lid. Then rotate the faucet to the operating position and make sure the Water Pump breaker in the cabin DC breaker panel is on. The faucet works like faucets in your home when the fresh water system is activated. Always lower the faucet to the stored position and close the lid when the sink is not being used.

The ice maker or refrigerator and storage compartment doors are secured in the closed position with push to close latches that are flush to door. To open, pull the latch handle to release the latch. To close, push the door until the latch catches. Periodically clean and lubricate the latches to protect them from corrosion and keep them operating properly.

The storage compartment below the sink is equipped with special racks that are used to securely store the wet bar counter top and the lid for the optional grill. There is also room for dunnage in this compartment. Another storage compartment located below the sink is equipped with a waste basket secured with a special strap and room for dunnage.

Cockpit Refrigerator and Optional Ice Maker

An AC/DC refrigerator or optional ice maker is mounted in the forward section of the wet bar. The ice maker operates on AC power only. A switch located just below the ice maker door turns the unit on or off. The ice maker door has a special latch to secure the door while under way. Make sure the door is properly secured whenever the boat is moving. The fresh water system supplies the water for the ice maker. Make sure the Water Pump breaker is activated and there is water in the fresh water system before turning on the ice maker. Refer to the ice maker owner's manual for additional operating and maintenance instructions.

The optional dual voltage refrigerator will operate on 120-volt AC or 12-volt DC power. The refrigerator switches to 12-volt DC automatically when



Engine Hatch and Actuator



Wet Bar and Ice Maker



Dual Voltage Cockpit Refrigerator

the AC power is disconnected and the Refrigerator breaker is activated on the cabin DC panel. When 120-volt AC current is provided by the Refrigerator circuit breaker on the 120-volt panel, the refrigerator automatically switches to AC power.

Care should be exercised while operating the refrigerator on 12-volt power without the engines running. It draws a substantial amount of current and can severely drain the house battery through extended use. The refrigerator door has a special latch to secure the door while under way. Make sure the door is properly secured whenever the boat is moving.

Refer to the refrigerator or ice maker owner's manual for additional operating and maintenance instructions.

Electric Grill (Optional)

An electric, stainless steel grill can be installed in the wet bar as optional equipment. The grill operates on AC power only. It is recessed into the counter top below a removable Karadon cover that is flush to the counter top. A micro switch in the recess for the cover is activated by the weight of the cover. The micro switch prevents the grill from operating when the lid is in place. A special rack in the compartment below the grill secures the Karadon cover when the grill is in use. The lid for the grill is removable and stored in another special rack in the storage compartment when it is not in use and the Karadon lid is in place.

To use the grill, make sure the Electric Grill breaker in cabin AC panel is on. Remove the Karadon cover and properly store it in the rack in the compartment below the grill. Attach the removable lid to the hinge fittings on the grill. The rear hinge on the lid has a pin that slides into the female receiver in the grill. The forward hinge is secured with a removable pin. ***Make sure the handle on the L-shaped removable hinge pin is facing toward the grill when it is installed in the hinge. If the pin is installed with the handle facing away from the grill, the cover will be damaged by the pin when it is opened. Use the touch control on the grill to activate the burner and control the temperature.***

After cooking, be sure the burner is turned off and allowed to cool before removing the lid and installing the Karadon cover. Never place the cover over the grill while it is hot. Once the grill is cool, the grill lid can be removed and properly stored in the storage rack. Turn the Electric Grill



Cockpit Lounge Seat and Engine Day Hatch



Sun Island



*Grill with Lid Attached
Hinge Pin Handle Facing Toward Grill*

breaker in the cabin AC panel off and place the Karadon lid in the recess above the grill. Make sure the lid sits properly in the recess so it will activate the micro switch that prevents the grill from operating with the lid in place.

Cockpit Lounge Seat

The cockpit lounge seat provides seating and the rear portion converts to a sun island. The sun island portion of the seat raises with cockpit deck to provide access to the engine compartment. There is storage below the forward seat cushion and additional storage below the forward sun island seat cushion above the engine compartment.

The backrest on the rear of the sun island seat has three positions. In the aft position, it is a back rest cushion for the lounge seat. In center position it converts the seat to a reverse facing sun lounge with backrest. In the forward position, it makes a full lay down sun lounge and enables the seat cushion to be opened to access the rear storage compartment in the sun island.

The backrest is moved by lifting the center of the back rest and moving it toward the desired position. When the backrest reaches the next position it will drop slightly and lock.

For the safety of your passengers, always make sure the stern sun lounge back rest is in the full aft, lounge backrest position whenever the engines are running or the boat is underway. The backrest secures the cockpit and lounge seat area and prevents someone from accidentally falling overboard when it is in the aft position. Never allow someone to be on the reverse facing sun island seat with the backrest in the center or forward position when the engines are running.

There is a concealed table in the cockpit lounge seat below the port seat cushion. To use the table, lift the front of the port seat cushion to raise the cushion and backrest. Gas hatch lifters help raise the cushion and hold the cushion and backrest in the open or closed position. Rotate the table and hinged pedestal out of the compartment to the up position. The table is hinged in the center and folded for storage. Leave the table folded and press down slightly to remove pressure on the spring loaded lock pin on the pedestal. Pull the lock pin out and release the down pressure on the table. A gas spring inside the pedestal will automatically raise the table to the up position. The spring loaded lock pin should lock the table in the full up position. Close the seat cushion, then fold the table open. ***Note that the seat cushion will hit the table as it closes if the table is not folded and in the raised, dining position.***



Table Folded



*Spring Loaded Lock Pin
on Table Pedestal*



Cockpit Table



Bridge Deck Lounge Seat

Bridge Deck Lounge seat

The lounge passenger seat is mounted on the port side of the bridge deck. There are backrest cushions on the forward and rear ends of the lounge to allow passengers to face forward or to the rear. Two cup holders are located next to the seat.

Helm Seat

The helm seat is equipped with a flip up bolster to provide more room between the seat and the helm. The bolster converts the seat to a leaning post style seat with a backrest and allows the operator to sit or stand at the helm. To convert the seat to a leaning post, lift the front of the seat cushion to raise the bolster and push it back above the seat cushion.

Arm rests on each side provide a more comfortable driving position and swing up into the backrest cushion to make it easier to enter and exit the helm area. The drink holder near the starboard side of the helm drains to the cockpit sole.

There is a storage compartment located below the seat. The compartment hatch is recessed and secured with a push to close latch.

Helm

The steering, engine controls, engine instruments and switches for exterior equipment and navigation lights are located on the helm station. The helm station is designed to provide good visibility, room for electronics and a more functional control station. An electrically activated vent panel in the windshield provides ventilation to the helm area and bridge deck. The vent is controlled by a switch in the helm switch panel.

The steering wheel and engine controls are located on the rear of the helm console. The helm switch panels are just forward of the helm and the engine ignition switches are located on a separate panel below the steering wheel. The circuit breakers for the helm activated accessories are located in a panel below the steering wheel.

Molded-in electronics storage is located in the center of the helm, forward of the steering wheel. Access to service the controls or to install or service electronics is provided through a removable access panel in the cabin.

A Raymarine BI Data that indicates depth, speed and water temperature is provided as standard equipment. Optional electronics packages that include a VHF radio, chart plotter, GPS and Radar may be installed with the Tri Data. Electronic Navigational equipment manufacturers provide detailed instruction manuals with their products. You should read them carefully and review the operation of the electronics with your dealer at the time of delivery.



Helm Seat



Helm

Cabin Doors

The sliding main cabin door is solid acrylic plastic glass and slides on a top and bottom track. Another sliding screen door slides on a track just inside the main door. The screen door is also made of acrylic plastic glass and has large screened in panels that keep bugs out and provide additional ventilation for the cabin. A lockable latch secures each door in the closed position. A special vinyl-covered latch near the bottom door tracks secures either door in the open position.

It is very important that the cabin doors are secured properly in the open or closed position. The cabin doors are heavy and if they are not properly latched, the door could slide when the boat rocks and pinch someone's fingers between the door and the bulkhead or damage the door and track.


When closing the door, make sure you push the door against the door jam with enough pressure

to allow the latch to secure the door. When either door is open, it must be properly secured with the latch near the bottom door track and to the starboard side of the companionway. To latch the door in the open position, open the door completely, then rotate the latch to lay on the track in front of the door preventing the open door from sliding as the boat rocks.

Acrylic glass scratches easily and can chip. Always make sure the vinyl-covered latch is in good condition. It should be changed whenever it shows signs of deterioration from the exposure to elements. Please refer to the Routine Maintenance chapter for information on the proper care and maintenance of acrylic plastic glass.



Main Cabin Door and Screen Door



NEVER LEAVE EITHER CABIN DOOR UNLATCHED. THE CABIN DOORS ARE HEAVY AND SLIDE EASILY. IF A DOOR IS LEFT UNLATCHED, IT COULD SLIDE UNEXPECTEDLY AS THE BOAT ROCKS, DAMAGING THE DOOR OR CAUSING AN INJURY TO A PASSENGER. ALWAYS MAKE SURE THE DOORS ARE PROPERLY LATCHED IN THE OPEN OR CLOSED POSITION.

SECURE THE DOORS WHEN CRUISING. DO NOT SIT STAND OR PLACE HEAVY OBJECTS ON THE DOOR.

KEEP THE MAIN CABIN DOOR CLOSED WHEN ENGINES OR GENERATOR ARE RUNNING.



Cabin Door Latched in the Open Position

9.4 Hardtop and Enclosure

The hard top consists of an integrated fiberglass top and arch that is bolted to the deck. There is a grab rail on each side of the arch to provide hand holds while moving along the gunnels. Stereo speakers and courtesy lights are built into the headliner. The courtesy lights are activated by the Arch Lights switch in the helm switch panel.

The top is designed to accommodate radio antennas, radar antennas and navigation lights. A vent hatch in the forward brow provides additional ventilation and light for the bridge deck. The operation of the vent hatch is similar to the vent hatches in the cabin. Refer to the Ventilation Systems chapter for information on operating the vent hatch.

The hard top is not designed to support the additional weight of items like a life raft. Radar and



Hardtop with Enclosure Zippers Installed

electronics antennas must be mounted in locations on the top designed for these antennas. Do not mount any antennas or equipment to the brow area forward or aft of the arch mounting locations. The hard top is not designed to support the weight of accessories in these areas and could be damaged. The arch legs are the wire chases for lights and antennas mounted to the top.

The warranty for the hardtop will be void if the top is modified in any way or heavy accessories like life rafts are mounted to the top. Additionally, if items like radar antennas, spotlights and other accessories are mounted in the wrong location, the warranty could be void. If you intend to add equipment or make modifications to the hard top, you should contact Monterey Customer Service to make sure the equipment you would like to add or the intended modification will not void the warranty on the top.

The side curtains, front clear connector and drop curtain are custom made to each boat at the factory. To install the curtains, slide the zippers for the front clear connector and side curtains into the slide tracks on the forward brow of the hardtop and forward side of the arch legs. Attach the front clear connector to the zipper at the front of the top and snap it to the top of the windshield frame beginning with the center snaps. The clear connector will have to be stretched just enough

to pull out the wrinkles to reach the snaps on the windshield.

Once the clear connector is completely installed, the side curtains can be put on. Attach the side curtains into the zippers on the sides of the top, the zippers on the front connector and then the zippers on the arch legs. Finally, snap the curtains to the windshield beginning with the forward snaps. The side curtains will have to be stretched slightly to pull out the wrinkles and reach the snaps.

Slide the zipper for the drop curtain to the slide tracks on the rear brow of the hardtop and the rear of the arch legs. Attach the drop curtain to the zipper on the rear brow of the hard top and then to the zippers on the rear of the hardtop legs. Snap the drop curtain to the deck and cockpit to complete the installation.

Note: Cold weather can make the clear vinyl material on the curtains stiff and difficult to stretch to the snaps. This can be particularly difficult with new canvas that has been stored off the boat. Laying the curtains on a soft surface in the sun for 30 minutes during the heat of the day will make installing them much easier in cold weather.

INTERIOR EQUIPMENT

10.1 Head Compartments and Marine Toilets

Aft Head Compartment

The aft head compartment is equipped with a sink with a hot and cold faucet. The sink faucet is equipped with a removable shower head. The shower head is equipped with a valve that allows the shower water to be turned on and off without affecting the temperature to conserve water while showering. The shower sump pump is always activated whenever the house battery switch is on. A teak seat over the toilet that is held open or closed with a gas spring is provided to make showering more comfortable. There also is a shower curtain that goes in front of the head door. Make sure the shower seat is down and the curtain is pulled across the head door before activating the shower.



Aft Head Sink and Retractable Shower Head

There is storage in the mirror above the vanity and behind the doors under the sink. Ventilation is provided by air conditioning and exhaust blower ducts. There is also a 12-volt overhead light and 120-volt G.F.I. duplex outlet. The light and exhaust blower are activated by switches near the door.

Forward Head Compartment

The forward head compartment is equipped with a sink with a hot and cold faucet. There is separate shower with a removable shower head. A door stop with a built in automatic latch secures the shower door in the open position and a push to latch secures the door when it is closed. The shower head is equipped with a valve that allows the shower water to be turned on and off without affecting the temperature to conserve water while showering. The shower sump pump is always activated whenever the house battery switch is on.

There is storage behind the mirrors above the vanity and behind the door below the sink. Ventilation is provided by an overhead opening hatch, and air conditioning and exhaust blower ducts. There is also 12-volt overhead lights and 120-volt G.F.I. duplex outlet. The lights and exhaust blower are activated by switches near the sink.



Forward Head Compartment

Marine Head System

Your boat is equipped with a VacuFlush marine head system in each head compartment as standard equipment. VacuFlush systems use a small amount of water (one pint to one quart) and vacuum which is generated by the 12-volt vacuum pumps to flush. Each toilet is connected to the pressurized fresh water system. Using fresh water results in less odor in the head compartments.

To use the toilet, make sure both Head System breakers and the Water Pump breaker on the cabin DC panel are on. Then add water to wet the bowl by depressing the foot activated flush lever slightly on the aft head or the pressing the "Add Water" switch in the head control panel for the forward head until the desired water level is reached. Flush the toilet in the aft head by activating the flush lever all the way for approximately three seconds or until contents clear the bowl. Flush the toilet in the forward head by pressing the "Flush" switch in the head control panel for approximately three seconds or until the contents clear the bowl. A sharp popping noise is normal when the vacuum seal is broken and flushing action begins. It is also normal for a small amount of water to remain in the bowl after flushing.

The waste is transferred into the holding tank where it remains until it is pumped out by a waste dumping station or the optional overboard macerator discharge system. The waste moves through a one-inch opening in the toilet base. Incoming air fragments the waste as it passes through the base opening. This process eliminates the need for macerators or mechanical motors in the toilet base.

The vacuum generator for each toilet is mounted on the holding tank and contains stored vacuum. System vacuum is monitored by a vacuum switch which is located on each vacuum generator tank. When the switch senses a drop in vacuum in the system, it automatically signals the pump to energize and bring the vacuum back to operating level. This process is normally completed in less than two minutes.

It is normal for the stored vacuum to leak down slightly between flushes, causing the vacuum pump to run for a short period. The pump should not run more than once every three hours after the last flush for recharging the system. A holding tank fluid level monitor is located in each head compartment near the toilet. The macerator pump out switch is located in the fluid level



*Aft Compartment Sealand Head with
Foot Activated Fill and Flush Lever*



Forward Compartment Sealand Head



Forward Sealand Head Electric Control

monitor panel in the forward head compartment. Please refer to the toilet manufacturer owner's manual for more information on the operation of the marine head system.

Holding Tank and Optional Macerator Discharge Pump


The holding tank and vacuum generators are located in the engine compartment. The macerator pump is located on the holding tank and discharges waste to a thru-hull fitting in the bilge, near the holding tank.

When the tank is full, the tank monitors will show full and the vacuum pumps will not run. The tank must either be pumped out by an approved waste dumping station through the waste deck fitting in the stern or be pumped overboard with the optional macerator discharge pump, when legal to do so.

To operate the macerator discharge pump, open the sea cock at the overboard discharge thru-hull fitting located in the engine compartment. Then activate the momentary macerator switch located in the fluid level monitor panel in the forward head compartment. Monitor the fluid level until the tank is emptied. Release the switch and close the discharge ball valve when pumping is complete.

Note: The macerator discharge pump can only be run dry for a couple of seconds. Allowing the macerator pump to run after the holding tank is empty will cause damage to the pump.

Note: The overboard macerator discharge pump option for the waste holding tank is not available with the grey water system.



Maintenance

The marine toilets should be cleaned and inspected for leaks regularly. Monitor the cycle time of the vacuum pumps. If a pump cycles more than once every two or three hours or runs longer than three minutes after a flush, there may be a leak



Holding Tank, Vacuum Pump and Overboard Macerator Pump



Holding Tank and Vacuum Pumps



Holding Tank Overboard Discharge Thru-Hull Fitting

in the system or the vacuum pump may require service.

Always make sure to leave enough water in the bowl to cover the flush valve and bowl seal. Periodically, lubricate the seal with Teflon grease. This will help keep the seal soft and pliable.

The holding tank should be pumped out and flushed as needed. Periodically add chemical to the aft head to help control odor and to chemically break down the waste. The macerator and vacuum pumps should be sprayed with a metal protector periodically to reduce corrosion. See the head manufacturer owner's manual for additional operating and maintenance information.

The vent hose for the holding tank is equipped with a charcoal filter to reduce odor from the holding tank. The filter is located in the engine compartment near the holding tank. It should be changed once a year or if the holding tank has become overfilled, which will plug the filter and could cause damage to the waste system.

Note: The head system must be properly winterized before winter lay-up. See the manufacturer owner's manual for additional operating and maintenance information.



Galley



*Cabin Door and Drawer
Latch Closed*



*Cabin Door and Drawer
Latch Open*

10.2 Galley and Sink

The galley is equipped with storage and a fresh water sink with hot and cold faucets. Water is supplied to the sink by a 12-volt pump located in the engine room. When activated by the Water Pump breaker in the cabin DC panel, the water system will operate much like the water system in a home. An automatic pressure sensor keeps the system pressurized. The sink drains overboard or to the optional grey water holding system through the cabin sink drain system. See the Fresh Water System chapter for more information on operating the fresh water system.

Daylight and fresh air is provided to this area by an opening port window above the galley sink. Additional lighting is provided by 12-volt lights above the galley.

The sink counter tops are made of Karadon. Storage cabinets, drawers and the refrigerator are located below the sink and counter top. A microwave/convection oven and additional storage are in the cabinets above. A coffee maker and dish

rack are built into the overhead cabinet next to the oven. A slide out waste basket is built into one of the cabinets below the sink.

Cabinet Door and Drawer Latches


The cabinet doors and drawers in the cabin are secured with dual action, push to lock latches. To open a drawer or cabinet door, push on the latch knob. The knob is spring loaded and will pop out one inch, providing a finger hold and releasing the dead bolt on the latch mechanism. A slight pull is required to release the friction latch and open the door. The cabinet doors and drawers will be held closed by the friction latches while at anchor or at the dock. To close and secure, make sure the door is completely closed and push the knob in. The knob will stay in and the locking mechanism will be activated.

The knobs should be pushed in to activate the positive lock dead bolts whenever the boat is underway.

Stove

The galley is equipped with a dual burner electric stove recessed into the counter top below a Karadon cover. A micro switch in the recess for the stove cover prevents the stove from activating while the cover is in place. To activate the stove, remove the cover and make sure the Stove breaker in the AC breaker panel is on. Make sure there is nothing but pots or pans on the stove and active the desired burner using the touch controls on the stove. A manual for the stove is included with your boat. It is extremely important that you read the manual and become familiar with the proper care and operation of the stove before attempting to use it.

After cooking, be sure the burners are turned off. Always be sure the burners are off and allowed to cool before placing anything on the stove. A warning light in the stove indicates the cook top surface is hot when it is lit. Do not install the stove cover or place anything on the cook top while the warning light is lit.



Stove



Refrigerator

Refrigerator (AC/DC)

A dual voltage, side by side refrigerator/freezer is supplied as standard equipment and is mounted in the galley below the oven. This unit will operate on 120-volt AC or 12-volt DC power. The refrigerator switches to 12-volt DC automatically when the AC power is disconnected and the Refrigerator breaker is activated on the cabin DC panel. When 120-volt AC current is provided by the Refrigerator circuit breaker on the 120-volt panel, the refrigerator automatically switches to AC power.

Care should be exercised while operating the refrigerator on 12-volt power without the engines running. It draws a substantial amount of current and can severely drain the house battery bank through extended use. The refrigerator and freezer doors have a special latch to secure the door while under way. Make sure the doors are properly secured whenever the boat is moving. Refer to the refrigerator owner's manual for additional operating and maintenance instructions.



Microwave/convection Oven

Microwave/Convection Oven

A microwave/convection oven has heating elements that allow it to function as a conventional convection oven or a microwave oven. It operates on AC power and is protected and activated by the Microwave breaker in the AC breaker panel. Please refer to the manufacturer's owner's manual for detailed information on the oven installed in your boat.

10.3 Main Salon

Lounge Seat and Dinette Table

The dinette is on the starboard side of the cabin. It is equipped with a table and a lounge seat. A drink holder and tray for the entertainment and home theater remote controls folds out of the center of the lounge backrest. There is also a 12-volt DC outlet and AC G.F.I. outlet in the fold out panel. Storage cabinets and lockers are located above the lounge.

The cabin AC/DC breaker panel is built into the cabinet at the rear of the lounge seat. A CD player, stereo, satellite radio, LED flashlight and storage is built into the cabinet on the starboard side of the cabin, above the lounge seat. The TV/home theater components and DVD player are located aft the lounge seat. The stereo is activated by the Stereo breaker in the DC electrical panel and the TV and home theater components are activated by the Home Theater breaker in the AC panel.

The table is mounted on portable pedestal assembly. To prevent damage to the table and cabin, the table and pedestal assembly must be properly stowed in the storage compartment before each cruise. This is particularly important when the boat is run offshore or in heavy seas. To stow the table, remove the table from the pedestal and set it on the lounge seat. Remove the pedestal from the base and stow the pedestal base and table in the compartment below the V-berth.

The dinette converts to a double berth. To convert the dinette to a berth, lift the front of the seat cushion and slide it toward the center of the cabin until it stops. Swing the support leg to the down position. To return the berth to a lounge seat, lift the end of the berth and swing the leg up. Then push the seat in until it folds into the lounge position.

Daylight and fresh air is provided to this area by opening port windows and by an overhead opening



Lounge Seat and Table



Dinette Table Storage Below V-Berth



Lounge Converted to Berth

hatch. Additional lighting is provided by 12-volt lights on either end of the dinette.

Cabin Light Switches

Most of the cabin lights are controlled by switches on the cabin walls. Other lights have switches on the light fixture. Some of the lights are controlled by electronic dimmer switches. Pressing and holding the top of the switch will turn the lights on and make them brighter. Pressing and holding the bottom of the switches will dim the lights or turn them off.

TV and Entertainment Center

The optional TV, CD/DVD player and stereo is built into the cabinets in the main lounge. The stereo is activated by a breaker in the DC electrical panel and the TV is activated by the entertainment breaker on the AC panel.



Typical Wall Switch with GFI Outlet

Central Vacuum

The central vacuum, hose and accessories are located in a compartment below the forward cushion of the lounge seat. The vacuum is activated by the Central Vacuum breaker in the AC panel. The outlet for the hose is on the front of the lounge seat. Refer to the manufacturer's owner's manual for more information on the operation and maintenance of the central vacuum cleaner.

Wine Chiller

A wine chiller is located below the cabin steps. It is activated by the Stbd Outlets breaker. Refer to the wine chiller owner's manual for information on the operation of the wine chiller.



Home Theater

Carbon Monoxide Detectors

Carbon monoxide (CO) detectors are installed in each stateroom and in the main cabin. If excess carbon monoxide fumes are detected, an audible beeping will sound indicating the presence of the toxic gas.

A by-product of combustion, carbon monoxide is invisible, tasteless, odorless, and is produced by all engines, heating and cooking appliances. The most common sources of CO on boats are the engines, auxiliary generators and propane or butane stoves. These produce large amounts of CO and should never be operated while sleeping.

Please read the owner's manual supplied by the detector manufacturer for operation instructions and additional information regarding the hazards of carbon monoxide gas. Also read more about carbon monoxide, carbon monoxide detectors,



Central Vacuum

and proper ventilation in the Ventilation Systems and Safety Equipment chapters in this manual. This is especially essential since your boat is equipped with a generator. If you did not receive a manual for your carbon monoxide detectors, please contact the Monterey Boats Customer Service Department.



ACTIVATION OF THE CARBON MONOXIDE DETECTOR INDICATES THE PRESENCE OF CARBON MONOXIDE (CO) WHICH CAN BE FATAL. EVACUATE THE CABIN IMMEDIATELY. DO A HEAD COUNT TO CHECK THAT ALL PERSONS ARE ACCOUNTED FOR. DO NOT REENTER THE CABIN UNTIL IT HAS BEEN AIRED OUT AND THE PROBLEM FOUND AND CORRECTED.

10.4 Air Conditioners

The air conditioning units are the reverse cycle type and operate on AC power. They are equipped with reverse cycle heat and can be operated as a cooling or heating unit. There is a forward air conditioner with ducts for the main salon, forward head compartment and master stateroom. Another aft air conditioner with ducts cools the aft stateroom, aft head compartment and the galley. The forward air conditioning unit is located below the V-berth in the master stateroom and is activated and protected by the Fwd AC breaker in the AC panel. The rear air conditioning unit is located below the forward berth in the aft cabin. It is protected by the Aft AC breaker in the 120-volt AC breaker panel.

To operate, make sure the thru-hull valve for the air conditioner raw water supply pump, located in the engine compartment, is on. Turn the Fwd AC and Aft AC breakers in the AC breaker panel to the "ON" position. The air conditioning or heat then will be controlled by the electronic control panels in the aft and forward Staterooms. When activated, water should continuously flow from the overboard thru-hull in the hull side.

The air conditioning system produces heat when it is operated in the reverse cycle mode. The ability of the units to produce heat is affected by the temperature of the seawater. As the seawater temperature lowers, the air conditioner's ability to produce warm air decreases. When the seawater temperature drops below 40 - 45 degrees, the air conditioner will not be able to produce heat. You should not operate the air conditioner to produce heat when the water temperature is below 40 degrees.



Aft Stateroom CO Detector



Typical Air Conditioning Control

Each air conditioning unit creates condensation that drips into the pan at the base of the unit. A hose attached to the pan drains the water to the sump system. The sump system is automatic and is activated whenever the house battery is connected. It is normal for some water to be in the pan whenever the air conditioner has been used. The condensation pans should be checked periodically to make sure it is draining properly.

The drain hoses, condensation pans and sump should be flushed clean if they become restricted by mold or debris. If the drain becomes plugged, the condensation pan will overflow into the V-berth

or aft stateroom storage compartment and could make the cabin floor wet.

You should always keep the cabin door closed when operating the air conditioner. If the cabin door is left open, it could cause the air conditioner units to run continuously and not cycle enough to defrost the coils on the condenser. This could cause the coils to develop enough ice to reduce the unit's ability to cool the boat.

The intake line for the pump that supplies sea water to cool both units is equipped with a sea strainer that must be checked for debris frequently and cleaned as necessary. Refer to the Raw Water System chapter and for information on the air conditioning pump and cleaning the sea strainer.

You also should refer to the air conditioner owner's manual for additional operating and maintenance instructions.

Note: Air conditioners use surface water as a cooling medium. The boat must be in the water and the raw water supply system must be properly activated prior to use. After a certain amount of time without water flow, the air conditioning unit will automatically power down. Always check for proper water flow out of the air conditioning pump discharge thru-hull when the air conditioner is operating.



Aft Stateroom Air Conditioner Below Forward Berth



Master Stateroom

10.5 Master Stateroom

The master stateroom is located in the bow area, forward of the main salon. The stateroom has a large berth set against the forward bulkhead with two storage drawers built into the aft end of the berth. Additional storage compartments, storage for the dinette table and the forward air conditioning unit is located in compartments below the mattress. Access to the forward bilge and optional bow thruster is also provided through hatches the storage compartments below the V-berth. A carbon monoxide detector and an LCD television mounted to the aft bulkhead is standard equipment. A door between the master stateroom and main salon provides privacy. The door is equipped with a door stop and latch that secures the door in the open position. Always make sure the door is latched in the open or closed position when the boat is away from the dock.



*Master Stateroom TV, Air Conditioner Control Panel
Light Switches, Stereo Control and GFI Outlet*

Hanging lockers are located on both sides of the stateroom door. Additional storage is located in storage compartments built into the rear of the hanging lockers. The light in the lockers is automatically activated when the door is opened and turned off when the door is closed.

Daylight and fresh air is provided to this area by an overhead opening hatch and two opening port windows. The hatch is equipped with a retractable screen and sunshade. Additional lighting is provided by recessed 12-volt lights in the headliner that are controlled by a wall switch near the door to the salon and two lights with switches on the light fixtures mounted on the forward bulkhead. Refer to the Ventilation System chapter for more information on operating the hatches, screens and shades.

10.6 Aft Stateroom

The aft stateroom is located aft of the main salon. It is equipped with twin berths, storage compartments, storage drawers, vanity mirror, and head compartment. Access for the aft air conditioner is located below a removable panel in the forward berth. The freshwater tank is below the aft berth. A carbon monoxide detector is standard and an LCD television mounted to the wall is optional.

A storage compartment with drawers and a vanity mirror is located on the port side of the aft stateroom between the door and the head compartment. There is also a storage in drawers below the forward berth and in the night stand between the berths. A removable filler cushion converts the berths to a single queen sized berth.

A hinged access panel in the starboard cabin wall provides access to service electronics and rigging components. It is opened by pulling on the bottom of the access panel. Gas springs hold the access panel in the open position.

Daylight and fresh air is provided to this area by an opening port window. Additional lighting is provided by recessed lights in the headliner and two reading lights, one above each berth, that are controlled by a wall switch near the door to the salon and switches on the light fixtures.

A sliding pocket door provides privacy for the aft stateroom. An automatic, lockable push to close latch secures the door in the closed position. A sliding latch at the bottom of the door secures it when it is open. Always make sure the door is



Aft Stateroom



Aft Berth Vanity



*Aft Compartment Door Latched in Open Position
Latch at the Bottom of the Door*

secured in the open or closed position whenever the boat is away from the dock. The door moves easily and if it is not properly latched, the rocking motion of the boat will cause the door to slide back and forth which could damage the door and door track.

10.7 Entertainment System

Your standard system contains:

LG Home Entertainment system (AC power only)

LG 26" HDTV (AC power only)

Kenwood MR400 Stereo (DC power only)

Sirius Satellite Radio (North America only, AC power only)

MP3 auxiliary input port (at helm, N/A if CD changer is ordered)

Ipod input (on LG Home Entertainment system)

Options include:

Raymarine ST37 DirecTV satellite system (North America only)

Kenwood CD Changer

Video Upgrade (Additional 15" TV in forward stateroom and aft stateroom, additional DVD player, DC power only)

Your entertainment systems are divided into 3 primary zones, the forward stateroom, cockpit, and salon.

Forward Stateroom

The speakers in the forward stateroom are controlled by the Kenwood MR400 stereo system. They are the "forward" speakers in the system and the cockpit speakers are the "rear" speakers. A remote control is provided in the starboard hanging locker wall to control the system. From here, you may listen to the radio, satellite radio, CD, or MP3 input.

Note that the Kenwood system operates the speakers in the cockpit as well, so if you are listening at night or in a quiet environment, you should move the fader to full forward and turn off the subwoofer.

Note: The following instructions apply to the TV's in both the forward stateroom and aft stateroom. Both TV's are connected to the dockside cable, over-the-air antenna, DVD player, and satellite TV (if installed).

To provide power to the TV's and DVD player, turn on the Fwd/Aft TV/DVD breaker on the DC panel.



Aft Stateroom Access to Equipment Compartment



Stereo, CD Changer, Satellite System and DVD Player



Main Salon Home Theater

To watch dockside cable or over-the-air antenna, select A (dockside cable) or B (over-the-air) on the A/B switch and select CATV on the TV input.

To watch a DVD, insert a DVD in the player, and select Composite on the TV input.

To watch satellite TV, turn on the satellite TV system, and select Component on the TV input.

Cockpit

To provide power to the stereo, turn on the stereo breaker on the DC panel.

The speakers in the cockpit are also controlled by the Kenwood MR400 stereo system. They are the "rear" speakers in the system. If you are listening in the cockpit and would like the forward stateroom to be quiet, you should move the fader to full rear. The remote controls at the helm and in the port hardtop wing operate the same as the remote in forward stateroom.

Salon

To provide power to the home entertainment system and 26" HDTV, turn on the Home Theatre breaker on the AC panel.

Note: To provide power to the satellite TV system, both the Home Theatre breaker on the AC panel AND the Fwd/Aft TV/DVD breaker on the DC panel must be turned on. This is because the ACU (Antenna Control Unit) is powered by DC and the satellite receiver is powered by AC.

Your home entertainment options in the salon are quite numerous. You may listen/watch the radio, iPod, MP3 player, USB device, CD, DVD, satellite TV (North America only), dockside cable, or over-the-air antenna.

To listen to the radio

Press the tuner button on the remote and select your preferred radio station.

To listen to MP3 player:

Connect your MP3 player to the Aux In port on the front of the home entertainment system using the appropriate 8mm cable (not supplied). Press the Aux button on your remote until AV2 is selected.

To listen to USB device:

Plug a compatible USB memory device into the USB port on the front of the entertainment system. Press the USB button on your remote. Use the on



Remote Stereo Control



Cockpit MP3 Port

screen display for more detailed control over the music selections available on your MP3 device.

To listen to a CD:

Place a CD in the tray of your home entertainment system and press play.

To watch a DVD:

Select HDMI 1 on your TV. Place a DVD in the tray of your home entertainment system. Use the on screen display and the remote control to select the features of the DVD.

To watch satellite TV (if installed):

Turn the satellite TV system on and select HDMI 2 on your TV. Press the Aux button on your remote until Optical In is selected.

To watch dockside cable TV:

Press the "A" button on the A/B switcher. Press the Input button on your TV remote until CATV

is selected. If you wish to listen to the sound on your home entertainment system in addition to or instead of your TV, select AV1.

To watch over-the-air (antenna) TV: Press the "B" button on the A/B switcher. Press the Input button on your TV remote until CATV is selected. If you wish to listen to the sound on your home entertainment system in addition to or instead of your TV, select AV1.

10.8 Cabin Floors and Woodwork

Cabin Floors

The galley floor is Lonseal vinyl with teak image and texture. It is important to avoid tracking sand and dirt on the cabin floor and steps. Sand and dirt acts like sand paper and will eventually sand off the finish in the traffic areas.

The wood floors and steps can be vacuumed and cleaned with a mixture of water and Murphy's Oil Soap. Wipe dry with a clean towel.

The carpeted areas are cleaned and maintained in the same fashion as the carpeting in your home.

Walls, Cabinets and Trim

The hardwood used for the wall trim moldings is finished with a high quality urethane varnish.



Cabin Floor and Steps

The walls themselves and the cabinet doors are made of a laminated, simulated wood that requires no maintenance. The walls and molding can be routinely cleaned with a damp cloth. For heavy duty cleaning, use a mixture of water and Murphy's Oil Soap or white vinegar and water to clean the wood or laminate and wipe it dry with a clean towel. Apply a furniture polish to add luster and help to preserve the finish.

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

SAFETY EQUIPMENT

11.1 General

Your boat and inboard engines have been equipped with safety equipment designed to enhance the safe operation of the boat and to meet U.S. Coast Guard safety standards. The Coast Guard or state, county, and municipal law enforcement agencies require certain additional accessory safety equipment on each boat. This equipment varies according to length and type of boat and type of propulsion. The accessory equipment typically required by the Coast Guard is described in this chapter. Some local laws require additional equipment. It is important to obtain "Federal Requirements And Safety Tips for Recreational Boats," published by the Coast Guard, and copies of state and local laws, to make sure you have the required equipment for your boating area.

Your boat is equipped with engine alarms, an automatic fire extinguishing system and cabin monitoring equipment. These systems are designed to increase your boating safety by alerting you to potentially serious problems in the primary power systems, the engine compartment, and the cabin. Alarm systems are not intended to lessen or replace good maintenance and precruise procedures.

This chapter also describes safety related equipment that could be installed on your boat. This equipment will vary depending on the type of engines and other options installed by you or your dealer.

11.2 Engine Alarms

Your boat is equipped with engine alarms that monitor water temperature and oil pressure. The alarms are equipped with a buzzer and/or a light located in the helm. The alarm will sound if the water temperature reaches 205 degrees F. or the oil pressure drops below 6 P.S.I.

If there is a problem with one of these systems, it will sound an alarm until the problem is found and resolved.



Throwable Device and Personal PFD

If the alarms sound:

- Immediately throttle the engines back to idle.
- Shift the transmissions to neutral.
- Monitor the engine gauges to determine the cause of the problem.
- If necessary, shut off the engines and investigate until the cause of the problem is found.

11.3 Neutral Safety Switch

Every control system has a neutral safety switch incorporated into it. This device prohibits the engines from being started while the shift lever is in any position other than the neutral position. If the engines will not start, slight movement of the shift levers may be necessary to locate the neutral position and disengage the safety cutout switch. Control or cable adjustments may be required to correct this condition should it persist. See your Monterey dealer for necessary control and cable adjustments. Please refer to the Helm Control Systems chapter for more information on the neutral safety switch.

11.4 Required Safety Equipment

Besides the equipment installed on your boat by Monterey, certain other equipment is required by the U.S. Coast Guard to help ensure passenger safety. Items like a sea anchor, working anchor, extra dock lines, flare pistol, life vests, a line permanently secured to your ring buoy, etc., could at some time save your passengers' lives, or save your boat from damage. Refer to the "Federal Requirements And Safety Tips For Recreational Boats" pamphlet for a more detailed description of the required equipment. You also can contact the U.S. Coast Guard Boating Safety Hotline, 800-368-5647, for information on boat safety courses and brochures listing the Federal equipment requirements. Also, check your local and state regulations.

The Coast Guard Auxiliary offers a "Courtesy Examination." This inspection will help ensure that your boat is equipped with all of the necessary safety equipment. The following is a list of the accessory equipment required on your boat by the U.S. Coast Guard:

Personal Flotation Devices (PFDs)

PFDs must be Coast Guard approved, in good and serviceable condition, and of appropriate size for the intended user. Wearable PFDs must be readily accessible, meaning you must be able to put them on in a reasonable amount of time in an emergency. Though not required, the Coast Guard emphasizes that PFDs should be worn at all times when the vessel is underway. Throwable devices must be immediately available for use. All Monterey boats must be equipped with at least one Type I, II or III PFD for each person on board, plus one throwable device (Type IV).

Visual Distress Signals

All boats used on coastal waters, the Great Lakes, territorial seas, and those waters connected directly to them, must be equipped with Coast Guard approved visual distress signals. These signals are either Pyrotechnic or Non-Pyrotechnic devices.

Pyrotechnic Visual Distress Signals:

Pyrotechnic visual distress signals must be Coast Guard approved, in serviceable condition, and readily accessible. They are marked with a date showing the service life, which must not have expired. A minimum of three are required. Some pyrotechnic signals meet both day and night use requirements. They should be stored in a cool, dry location. They include:

- Pyrotechnic red flares, hand held or aerial.
- Pyrotechnic orange smoke, hand-held or floating.
- Launchers for aerial red meteors or parachute flares.



PYROTECHNICS ARE UNIVERSALLY RECOGNIZED AS EXCELLENT DISTRESS SIGNALS. HOWEVER, THERE IS POTENTIAL FOR INJURY AND PROPERTY DAMAGE IF NOT PROPERLY HANDLED. THESE DEVICES PRODUCE A VERY HOT FLAME AND THE RESIDUE CAN CAUSE BURNS AND IGNITE FLAMMABLE MATERIAL. PISTOL LAUNCHED AND HAND-HELD PARACHUTE FLARES AND METEORS HAVE MANY CHARACTERISTICS OF A FIREARM AND MUST BE HANDLED WITH CAUTION. IN SOME STATES THEY ARE CONSIDERED A FIREARM AND PROHIBITED FROM USE. ALWAYS BE EXTREMELY CAREFUL AND FOLLOW THE MANUFACTURER'S INSTRUCTIONS EXACTLY WHEN USING PYROTECHNIC DISTRESS SIGNALS.

Non-Pyrotechnic Devices

Non-Pyrotechnic visual distress signals must be in serviceable condition, readily accessible, and certified by the manufacturer as complying with U.S. Coast Guard requirements. They include:

- **Orange Distress Flag (Day use only)**
The distress flag is a day signal only. It must be at least 3 x 3 feet with a black square and ball on an orange background. It is most distinctive when attached and waved from a paddle or boat hook.
- **Electric Distress Light (Night use only)**
The electric distress light is accepted for night use only and must automatically flash the international SOS distress signal. Under "Inland Navigation Rules," a high intensity white light flashing at regular intervals from 50-70 times per minute is considered a distress signal.

Sound Signaling Devices

The navigation rules require sound signals to be made under certain circumstances. Recreational vessels also are required to sound fog signals during periods of reduced visibility. Therefore, you must have some means of making an efficient sound signal.

Navigation Lights

Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility (fog, rain, haze, etc.) Navigation lights are intended to keep other vessels informed of your presence and course. Your boat is equipped with navigation lights required by the U.S. Coast Guard at the time of manufacture. It is up to you to make sure they are operational and turned on when required.

Fire Extinguishers

This boat is required to have four (4) USCG type B1 fire extinguishers. They are to be located at the helm, galley, forward stateroom and aft stateroom. Coast Guard approved fire extinguishers are hand-portable with a B-I classification and have a specific marine type mounting bracket. It is recommended that the extinguishers be mounted in a readily accessible position.



Fire extinguishers require regular inspections to ensure that:

- Seals & tamper indicators are not broken or missing.
- Pressure gauges or indicators read in the operable range.
- There is no obvious physical damage, corrosion, leakage or clogged nozzles.

Refer to the "Federal Requirements And Safety Tips For Recreational Boats" pamphlet or contact the U.S. Coast Guard Boating Safety Hotline, 1-800-368-5647, for information on the type and size fire extinguisher required for your boat.

Please refer to the information provided by the fire extinguisher manufacturer for instructions on the proper maintenance and use of your fire extinguisher.



INFORMATION FOR AGENT FE-241 AND FE-227 FIRE EXTINGUISHERS IS PROVIDED BY THE MANUFACTURER. IT IS ESSENTIAL THAT YOU READ THE INFORMATION CAREFULLY AND COMPLETELY UNDERSTAND THE SYSTEM, IN THEORY AND OPERATION, BEFORE USING YOUR BOAT.

Bilge and Fuel Fires

Fuel compartment and bilge fires are very dangerous because of the presence of gasoline or diesel fuel in the various components of the fuel system and the possibility for explosion. You must make the decision to fight the fire or abandon the boat. If the fire cannot be extinguished quickly or it is too intense to fight, abandoning the boat may be your only option.

If you find yourself in this situation, make sure all passengers have a life preserver on, go over the side and swim well upwind of the boat. This will keep you and your passengers well clear of any burning fuel that could be released and spread on the water as the boat burns or in the event of an explosion. When clear of the danger, check about and account for all those who were aboard with you. Give whatever assistance you can to anyone in need or in the water without a buoyant device. Keep everyone together in a group for morale and to aid rescue operations.



ALL TYPES OF FUEL CAN EXPLODE. IN THE EVENT OF A FUEL COMPARTMENT OR BILGE FIRE, YOU MUST MAKE THE DIFFICULT DECISION TO FIGHT THE FIRE OR ABANDON THE BOAT. YOU MUST CONSIDER YOUR SAFETY, THE SAFETY OF YOUR PASSENGERS, THE INTENSITY OF THE FIRE AND THE POSSIBILITY OF AN EXPLOSION IN YOUR DECISION.



IN THE EVENT OF A FIRE IN THE GENERATOR:

- TO KEEP THE FLAMES CONTAINED, DO NOT OPEN THE SOUND SHIELD.
- SHUT DOWN ENGINES, GENERATORS AND BLOWERS.
- CONTINUOUSLY DISCHARGE THE ENTIRE CONTENTS OF A PORTABLE FIRE EXTINGUISHER THROUGH THE FIRE PORT IN THE SOUND SHIELD IMMEDIATELY.

11.5 Automatic Fire Extinguishing System

The engine compartment is equipped with an automatic fire extinguishing system. The equipment has been chosen and located to provide sufficient volume and coverage of the entire engine compartment area. While the system ensures excellent bilge fire protection, it does not eliminate the U.S. Coast Guard requirement for hand held fire extinguishers. The automatic fire extinguishing system is automatically activated when the tem-

perature in the engine compartment reaches a specific temperature, usually around 165° F.

The boat is equipped with an indicator light at the helm. Under normal circumstances, whenever the ignition key is turned on, the green indicator light will glow. This indicates that the system is operating and ready for activation if necessary. If the indicator light does not glow when the ignition switch is turned on, either the system has discharged or there is a problem that should be corrected before using the boat.

The green light on the fire extinguisher/override control panel will go off, the red light will glow and an alarm will sound if activation should occur during the operation of the boat. You may also hear a rushing air sound as the extinguishing agent discharges.

There is an engine cut out circuit that automatically shuts down the engines and generator when the system is activated. A system override switch enables the operator to override the shutdown circuit and restart the engines. The cut out circuit is necessary because diesel engines will consume the fire extinguishing agent if they are allowed to run. If the engines continue to run, they should immediately be shut down manually, provided it is safe to do so. The fire extinguishing agent will shut down gasoline engines which can be restarted once the fire extinguishing agent has dissipated from the engine compartment.

When sufficient time has elapsed for the fire to be extinguished and a flashback is no longer possible, find and fix the problem, then the override switch can be moved to the "OVERRIDE" position and the engines can be restarted.



DIESEL ENGINES WILL CONSUME EXTINGUISHING AGENT. IF THE SYSTEM DISCHARGES THE ENGINES DON'T SHUT DOWN AUTOMATICALLY, THEY MUST BE IMMEDIATELY SHUT DOWN MANUALLY. IF A DIESEL ENGINE IS ALLOWED TO RUN IN THIS SITUATION, IT WILL CONSUME THE EXTINGUISHING AGENT AND FLASH BACK COULD RESULT.



Typical Automatic Fire Extinguishing System in the Engine Compartment



Override Switch and Fire Extinguisher Indicator Lights



IF ACTIVATION SHOULD OCCUR, IMMEDIATELY SHUT DOWN ALL ENGINES. TURN OFF ALL ELECTRICAL SYSTEMS, POWERED VENTILATION AND EXTINGUISH ALL SMOKING MATERIALS. DO NOT OPEN THE ENGINE COMPARTMENT HATCH IMMEDIATELY!! THIS FEEDS OXYGEN TO THE FIRE AND FLASH BACK COULD RESULT. ALLOW THE EXTINGUISHING AGENT TO SOAK THE ENGINE COMPARTMENT FOR AT LEAST 15 MINUTES AND WAIT FOR HOT METALS OR FUELS TO COOL BEFORE CAUTIOUSLY INSPECTING FOR CAUSE OR DAMAGE. HAVE AN APPROVED PORTABLE FIRE EXTINGUISHER AT HAND AND READY FOR USE. DO NOT BREATHE FUMES OR VAPORS CAUSED BY THE FIRE!!



THE OWNER'S MANUAL PROVIDED BY THE FIRE EXTINGUISHING SYSTEM MANUFACTURER SHOULD BE INCLUDED WITH YOUR BOAT. IT IS ESSENTIAL THAT YOU READ THE INFORMATION CAREFULLY AND COMPLETELY UNDERSTAND THE SYSTEM IN THEORY AND OPERATION BEFORE USING YOUR BOAT. IF YOU DID NOT RECEIVE THE FIRE EXTINGUISHING SYSTEM OWNER'S MANUAL, PLEASE CONTACT YOUR DEALER OR THE MONTEREY CUSTOMER SERVICE DEPARTMENT.

11.6 Carbon Monoxide Monitoring System



CARBON MONOXIDE IS COLORLESS, ODORLESS AND DANGEROUS. ALL ENGINES, GENERATORS AND FUEL BURNING APPLIANCES EXHAUST CARBON MONOXIDE (CO). DIRECT AND PROLONGED EXPOSURE TO CO WILL CAUSE BRAIN DAMAGE OR DEATH. SIGNS OF EXPOSURE TO CO INCLUDE NAUSEA, DIZZINESS AND DROWSINESS.

Carbon monoxide (CO) detectors are installed in the cabin as standard equipment and warns the occupants of dangerous accumulations of carbon monoxide gas. If excess carbon monoxide fumes are detected, the detectors will sound an alarm indicating the presence of the toxic gas.

Should a very high level of carbon monoxide exist, the alarm will sound in a few minutes. However, if small quantities of CO are present or high levels are short-lived, the alarm will accumulate the information and determine when an alarm level has been reached. The carbon monoxide detector is automatically activated whenever the house battery switch is "ON". The power light on the carbon monoxide detector should be lit to indicate that the carbon monoxide detector is activated. **Always make sure the house battery switch is "ON" and the power light on the carbon monoxide detector is lit whenever the cabin is occupied.**

A by product of combustion, carbon monoxide (CO) is invisible, tasteless, odorless, and is produced by all engines, heating and cooking appliances. The most common sources of CO on boats are the engines, auxiliary generators and propane or butane stoves. These produce large amounts of CO and should never be operated while sleeping.

A slight buildup of carbon monoxide over several hours causes headache, nausea and other symptoms that are similar to food poisoning, motion sickness or flu. High concentrations can be fatal within minutes. Many cases of carbon monoxide poisoning indicate that while victims are aware they are not well, they become so disoriented they are unable to save themselves by either exiting the area or calling for help. Also, young children, elderly persons, and pets may be the first affected.

Drug or alcohol use increases the effect of CO exposure. Individuals with cardiac or respiratory conditions are very susceptible to the dangers of carbon monoxide. CO poisoning is especially dangerous during sleep when victims are unaware of any side effects. The following are symptoms which may signal exposure to CO: (1) Headache (2) Tightness of chest or hyperventilation (3) Flushed face (4) Nausea (5) Drowsiness (6) Fatigue or Weakness (7) Inattention or confusion (8) Lack of normal coordination.

Persons who have been exposed to carbon monoxide should be moved into fresh air immediately. Have the victim breathe deeply and seek immediate medical attention. To learn more about CO poisoning, contact your local health authorities.


Low levels of carbon monoxide over an extended period of time can be just as lethal as high doses over a short period. Therefore, low levels of carbon monoxide can cause the alarm to sound before the occupants of the boat notice any symptoms of carbon monoxide poisoning. CO detectors are very reliable and rarely sound false alarms. If the alarm sounds, always assume the hazard is real and move persons who have been exposed to carbon monoxide into fresh air immediately. Never disable the CO detector because you think the alarm may be false. Always contact the detector manufacturer or your local fire department for assistance in finding and correcting the situation.

Remember, carbon monoxide detectors do not guarantee that CO poisoning will not occur. Do not use the CO detector as a replacement for ordinary precautions or periodic inspections of equipment. Never rely on alarm systems to save your life, common sense is still prudent and necessary.

Please read the owner's manual supplied by the CO detector manufacturer and included with this manual, for operation instructions and additional information regarding the hazards of carbon monoxide.

oxide gas. Refer to the Ventilation chapter for information on ventilating your boat properly while underway and other precautions while at anchor or in a slip. This is especially essential if your boat is equipped with the optional generator.

Many manufacturers of carbon monoxide detectors offer a testing and recertification program. We recommend that you contact the manufacturer of your carbon monoxide detector and have it tested and recertified periodically.



11.7 First Aid

It is the operator's responsibility to be familiar with the proper first-aid procedures and be able to care for minor injuries or illnesses of your passengers. In an emergency, you could be far from professional medical assistance. We strongly recommend that you be prepared by receiving training in basic first aid and CPR. This can be done through classes given by the Red Cross or your local hospital.



Your boat also should be equipped with at least a simple marine first-aid kit and a first-aid manual. The marine first-aid kit should be designed for the marine environment and be well supplied. It should be accessible and each person on board should be aware of its location. As supplies are used, replace them promptly. Some common drugs and antiseptics may lose their strength or become unstable as they age. Ask a medical professional about the supplies you should carry and the safe shelf life of prescription drugs or other medical supplies that may be in your first-aid kit. Replace questionably old supplies whether they have been used or not.

In many emergency situations, the Coast Guard can provide assistance in obtaining medical advice

for treatment of serious injuries or illness. If you are within VHF range of a Coast Guard Station, make the initial contact on channel 16 and follow their instructions.

11.8 Additional Safety Equipment

Besides meeting the legal requirements, prudent boaters carry additional safety equipment. This is particularly important if you operate your boat offshore. You should consider the following items, depending on how you use your boat.

Satellite EPIRBs

EPIRBs (Emergency Position Indicating Radio Beacon) operate as part of a worldwide distress system. When activated, EPIRBs will send distress code homing beacons that allow Coast Guard aircraft to identify and find them quickly. The satellites that receive and relay EPIRB signals are operated by the National Oceanic and Atmospheric Administration (NOAA) in the United States. The EPIRB should be mounted and registered according to the instructions provided with the beacon, so that the beacon's unique distress code can be used to quickly identify the boat and owner.

Marine Radio






A marine radio is the most effective method of receiving information and requesting assistance. VHF marine radios are used near shore and single sideband radios are used for long range communication.

There are specific frequencies to use in an emergency. The VHF emergency channel is 16 in the United States. You should read the owners manual for your radio and know how to use it in an emergency or for normal operation. If you hear a distress call you should assist or monitor the situation until help is provided.



Additional Equipment to Consider:

VHF Radio	Life Raft
Spare Anchor	Fenders
Heaving Line	Mirror
First Aid Kit	Tool Kit
Flashlight & Batteries	Anchor
Search	light
Boat Hook	Sunburn Lotion
Mooring Lines	Ring Buoy
Binoculars	Whistle or Horn
Extra Clothing	Portable Radio
Chart and Compass	Marine Hardware
Food & Water	Spare Keys
Sunglasses	Spare Parts
Spare Propeller	

11.9 Caution and Warning Labels



Located on Dash



THIS PAGE WAS LEFT BLANK
INTENTIONALLY

OPERATION

12.1 General

Before you start the engines on your Monterey, you should have become familiar with the various component systems and their operation and have performed a "Precruise System Check." A thorough understanding of the component systems and their operation is essential to the proper operation of the boat. This manual and the associated manufacturers' information is provided to enhance your knowledge of your boat. Please read them carefully.

Your boat must have the necessary safety equipment on board and be in compliance with the U.S. Coast Guard, local and state safety regulations. There should be one Personal Flotation Device (PFD) for each person. Non swimmers and small children should wear PFDs at all times. You should know and understand the "Rules of the Road" and have had an experienced operator brief you on the general operation of your new boat. At least one other person should be instructed on the proper operation of the boat in case the operator is suddenly incapacitated.

The operator is responsible for his safety and the safety of his passengers. When boarding or loading the boat, always step onto the boat, never jump. All passengers should be properly seated whenever the boat is operated above idle speed. Your passengers should not be allowed to sit on the seat backs, gunnels, bows, or transoms whenever the boat is underway. The passengers also should be seated to properly balance the load and must not obstruct the operator's view, particularly to the front.

Overloading and improper distribution of weight can cause the boat to become unstable and are significant causes of accidents. Know the weight capacity and horsepower rating of your boat. Do not overload or overpower your boat.

You should be aware of your limitations and the limitations of your boat in different situations or sea conditions. No boat is indestructible, no matter how well it is constructed. Any boat can be severely damaged if it is operated in a manner that exceeds its design limitations. If the ride is hard on you and your passengers, it is hard on the boat as well. Always modify the boat speed

in accordance with the sea conditions, boat traffic and weather conditions.

Remember, it is the operator's responsibility to use good common sense and sound judgment in loading and operating the boat.

12.2 Rules of the Road

As in driving an automobile, there are a few rules you must know for safe boating operation. The following information describes the basic navigation rules and action to be taken by vessels in a crossing, meeting or overtaking situations while operating in inland waters. These are basic examples and not intended to teach all the rules of navigation. For further information consult the "Navigation Rules" or contact the Coast Guard, Coast Guard Auxiliary, Department of Natural Resources, or your local boat club. These organizations sponsor courses in boat handling, including rules of the road. We strongly recommend such courses. Books or videos on this subject also are available from your local library.

Note: Sailboats not under power, paddle boats, vessels unable to maneuver, vessels engaged in commercial fishing and other vessels without power have the right of way over motor powered boats. You must stay clear or pass to the stern of these vessels. Sailboats under power are considered motor boats.

Crossing Situations

When two motor boats are crossing, the boat on the right has the right of way. The boat with the right of way should maintain its course and speed. The other vessel should slow down and permit it to pass. The boats should sound the appropriate signals.

Meeting Head-On or Nearly-So Situations

When two motor boats are approaching each other head-on or nearly head-on, neither boat has the right of way. Both boats should reduce their speed and turn to the right so as to pass port side to port side, providing enough clearance for safe passage. The boats should sound the appropriate signals.

Overtaking Situations

When one motor boat is overtaking another motor boat, the boat that is being passed has the right of way. The overtaking boat must make the adjustments necessary to provide clearance for a safe passage of the other vessel. The boats should sound the appropriate signals.

The General Prudential Rule

In obeying the Rules of the Road, due regard must be given to all dangers of navigation and collision, and to any special circumstances, including the limitations of the vessels, which may justify a departure from the rules that is necessary to avoid immediate danger or a collision.


Night Operation

Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility such as fog, rain, haze, etc. When operating your boat at night you should:

- Make sure your navigation lights are on and working properly. Navigation lights warn others of your position and course and the position and course of other vessels.
- All navigation rules apply. If the bow light of another vessel shows red, you should give way to that vessel, if it shows green, you have the right of way.
- Slow down and never operate at high speeds when operating at night, stay clear of all boats and use good common sense. Always be ready to slow down or steer clear of other vessels, even if you have the right-of-way.
- Avoid bright lights that can destroy night vision, making it difficult to see navigation lights and the lights of other boats. You and your passengers should keep a sharp lookout for hazards, other boats and navigational aids.

Navigation Aids

Aids to navigation are placed along coasts and navigable waters as guides to mark safe water and to assist mariners in determining their position in relation to land and hidden dangers. Each aid to navigation is used to provide specific information. You should be familiar with these and any other markers used in your boating area.




Navigation Aids Chart

REMEMBER THESE RULES

1. OVERTAKING - PASSING: Boat being passed has the right-of-way. KEEP CLEAR.
2. MEETING HEAD ON: Keep to the right.
3. CROSSING: Boat on right has the right-of-way. Slow down and permit boat to pass.

← PORT

Yield
right-of-way
to boats
in your
DANGER
ZONE!



STARBOARD →

DANGER
ZONE
(Dead ahead
to 2 points
abaft your
starboard
beam)

STORM WARNINGS



RED FLAG
Small craft
(winds to
33 knots)



2 RED FLAGS
Gale
(winds up to
47 knots)



SQUARE
RED FLAG
BLACK BOX
(Storm)



2 SQUARE
RED FLAGS
BLACK BOX
(Hurricane)

WHISTLE SIGNALS

ONE LONG BLAST: Warning signal

(Coming out of slip)

ONE SHORT BLAST: Pass on my port side

TWO SHORT BLASTS: Pass on my starboard side

THREE SHORT BLASTS: Engine(s) in reverse

FOUR OR MORE BLASTS: Danger signal

BRIDGE SIGNALS

SOUND

VESSEL: Open

BRIDGE: OK

No

VESSEL: Replies:

RADIO: VHF CH. 13

VISUAL

VESSEL: Open

BRIDGE: OK

No

DAY
(Flag)

NIGHT
(Lights)

Same

or

Same

LATERAL AIDS AS SEEN ENTERING FROM SEAWARD

PORT SIDE ODD NUMBERED AIDS


GREEN LIGHT ONLY

FLASHING


OCCULTING

QUICK FLASHING

ISOPHASE



LIGHTED BUOY



CAN



SG

DAYMARK

SAFE WATER MID-CHANNELS OR FAIRWAYS NO NUMBERS — MAY BE LETTERED

WHITE LIGHT ONLY MORSE CODE

Mo (A)

Mo (A)

Mo (A)

Mo (A)

Mo (A)

Mo (A)




SPHERICAL



Mo (A)



MR




LIGHTED
AND OR SOUND

PREFERRED CHANNEL

NO NUMBERS — MAY BE LETTERED


COMPOSITE GROUP FLASHING (2 + 1)

Mo (A) Mo (A) Mo (A) Mo (A) Mo (A) Mo (A)



GR 'C'

FI (2 + 1)




CAN



JG

DAYMARK

LIGHTED



RG 'B'

FI (2 + 1)



CAN



JR

DAYMARK

STARBOARD SIDE EVEN NUMBERED AIDS


RED LIGHT ONLY

FLASHING


OCCULTING

QUICK FLASHING

ISOPHASE



LIGHTED BUOY



CAN



TR

DAYMARK

Note: Storms and wave action can cause buoys to move. You should not rely on buoys alone to determine your position.

12.3 Pre-Cruise Check

Before Starting the Engines:

- Check the weather forecast and sea conditions before leaving the dock. Decide if the planned cruise can be made safely.
- Be sure all required documents are on board.
- Be sure all necessary safety equipment is on board and operative. This should include items like the running lights, spotlight, life saving devices, etc. Please refer to the Safety Equipment chapter for additional information on safety equipment.
- Make sure you have signal kits and flare guns aboard, and they are current and in good operating condition.
- Be sure you have sufficient water and other provisions for the planned cruise.
- Leave a written message listing details of your planned cruise with a close friend ashore (Float Plan). The float plan should include a description of your boat, where you intend to cruise, and a schedule of when you expect to arrive in the cruising area, and when you expect to return. Keep the person informed of any changes in your plan to prevent false alarms. This information will tell authorities where to look and the type of boat to look for in the event you fail to arrive.
- Check the amount of fuel on board. Observe the "rule of thirds:" one third of the fuel for the trip out, one third to return and one third in reserve. An additional 15% may be consumed in rough seas.
- The engine fuel filters should be checked for leaks or corrosion.
- Turn the battery switches on.
- Check the bilge water level. Look for other signs of potential problems. Monitor for the scent of fuel fumes.
- Test the automatic and manual bilge pump switches to make sure the system is working properly.
- Turn on the bilge blowers. Check the blower output and operate four (4) minutes before starting the engine. The blowers also should be activated when operating below cruising speed and when operating the generator.
- Have a tool kit aboard. The kit should include the following basic tools:

Spark plug wrench	Hammer
Spark plug gap gauge	Electrician's tape
Screwdrivers	Offset screwdrivers
Lubricating oil	Pliers
Jackknife	Adjustable wrench
Basic 3/8" ratchet set	Vise grip pliers
Hex key set	Needle nose pliers
Wire crimping tool	Wire connector Set
End wrench set	Medium slip-joint pliers
Diagonal cutting pliers	DC electrical test light



THERE MUST BE AT LEAST ONE PERSONAL FLOTATION DEVICE ON BOARD FOR EVERY PERSON ON BOARD AND ONE THROW-OUT FLOTATION DEVICE. CHECK THE U.S. COAST GUARD STANDARDS FOR THE CORRECT TYPE OF DEVICE FOR YOUR BOAT.

- Have the following spare parts on board:

Extra light bulbs	Spark plugs
Fuses and	circuit breakers
Main 12-volt fuses	Assorted stainless screws
Assorted stainless bolts	Flashlight and batteries
Drain plugs	Engine oil
Transmission oil	Propellers
Propeller nuts	Fuel filters
Fuel hose and clamps	Wire ties
Engine cooling pump	Hydraulic oil
Impeller Kit	Assorted hose
Clamps	Rags
Steering fluid	Pump & alternator belts
- Make sure all fire extinguishers are in position and in good operating condition.

12.4 Operating Your Boat

After Starting the Engines:

- Check the engine gauges. Make sure they are reading normally.
- Visibly check the engines to be sure there are no apparent water, fuel or oil leaks.
- Check the operation of the engine cooling systems by monitoring the temperature gauges frequently until the engine temperature stabilizes at normal operating temperature.
- Check the steering and engine controls for proper operation.
- Make sure all lines, cables, anchors, etc. for securing a boat are on board and in good condition. All lines should be coiled, secured and off the decks when underway.
- Have a safe cruise and enjoy yourself.

Remember:

When you operate a boat, you accept the responsibility for the boat, for the safety of passengers and for others out enjoying the water.

- Alcohol and any drugs can severely reduce your reaction time and affect your better judgement.
- Alcohol severely reduces the ability to react to several different signals at once.
- Alcohol makes it difficult to correctly judge speed and distance, or track moving objects.
- Alcohol reduces night vision, and the ability to distinguish red from green.



YOU SHOULD NEVER OPERATE YOUR BOAT WHILE UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.

- Make sure one other person on the boat is instructed in the operation of the boat.
- Make sure the boat is operated in compliance with all state and local laws governing the use of a boat.



DO NOT OPERATE THE BOAT UNLESS IT IS COMPLETELY ASSEMBLED. KEEP ALL FASTENERS TIGHT. KEEP ADJUSTMENTS ACCORDING TO SPECIFICATIONS.

- Always operate the blowers when operating the boat below cruising speed or when the generator is running to help cool the engine compartment and remove dangerous fumes.
- Avoid sea conditions that are beyond the skill and experience of you and your crew. Learn to understand weather patterns and indications for change. You should monitor NOAA weather broadcasts before leaving port and periodically while boating. If the weather deteriorates or a storm approaches, seek shelter in a safe harbor.
- Use caution during periods of reduced visibility due to weather or operation conditions. Reduce speed and designate a passenger to be a lookout for other boats, obstacles and navigational markers until you reach port or conditions improve.
- Your Monterey is a heavy boat that will produce a large wake at certain speeds. You are responsible for damage and injury caused by your boat's wake. Always observe no wake zones and be aware that your wake can endanger small vessels and their passengers. Always be courteous and slow down to reduce your wake when passing smaller boats.
- Before operating the boat for the first time, read the engine break-in procedures. The break-in procedures are found in the owner's manual for the engines. The manual is in the literature packet.
- As different types of engines are used to power the boat, have the dealer describe the operating procedures for your boat. For more instructions on "How To Operate The Boat," make sure you read the instructions given to you in the owner's manual for the engines you have selected.

Note: For more instructions on safety, equipment and boat handling, enroll in one of the several free boating courses offered. For information on the courses offered in your area, call the "Boating Course Hotline," 1-800-368-5647.

Note: If the running gear hits an underwater object, stop the engines. Inspect the propulsion system for damage. If the system is damaged, contact your dealer for a complete inspection and repair of the unit.

To stop the boat, follow this procedure:

- Allow the engines to drop to the idle speed.
- Make sure the shifting levers are in the neutral position.

Note: If the engines have been run at high speed for a long period of time, allow the engines to cool down by running the engines in the idle position for 3 to 5 minutes.

- Turn the ignition keys to the "OFF" position.
- Raise the trim tabs to the full up position.

After Operation:

- If operating in saltwater, wash the boat and all equipment with soap and water.
- Check the bilge area for debris and excess water.
- Fill the fuel tanks to near full to reduce condensation. Allow enough room in the tanks for the fuel to expand without being forced out through the vent.
- Turn off all electrical equipment except the automatic bilge pumps.
- If you are going to leave the boat for a long period of time, put the battery main switches in the "OFF" position and close all sea cocks.
- Make sure the boat is securely moored.



TO PREVENT DAMAGE TO THE BOAT, CLOSE ALL SEA COCKS BEFORE LEAVING THE BOAT.

12.5 Docking, Anchoring and Mooring

Docking and Dock Lines

Maneuvering the boat near the dock and securing the boat requires skill and techniques that are unique to the water and wind conditions and the layout of the dock. If possible, position a crew member at the bow and stern to man the lines and assist in docking operations. While maneuvering close to the dock, consideration must be giving to the wind and current. You should anticipate the effect these forces will have on the boat and use them to help put the boat where you want it. It is important to practice in open water using an imaginary dock enough to develop a sense for the way your boat handles in a variety of docking scenarios. You must be able to foresee the possibilities and have solutions in mind before problems occur.

Approaching a dock or backing into a slip in high winds or strong currents requires a considerable amount of skill. If you are new to boat handling, you should take lessons from an experienced pilot to learn how to maneuver your boat in tight quarters in less than ideal conditions. You should also practice away from the dock during windy conditions.

Dock lines are generally twisted or braided nylon. Nylon is strong and stretches to absorb shock. It also has a long life and is soft and easy on the hands. The line's size will vary with the size of the boat. Typically a 30 to 40 foot boat will use 5/8-inch line and a 20 to 30 foot boat will use 1/2-inch line. The number of lines and their configuration will vary depending on the dock, the range of the tide, and many other factors. Usually a combination of bow, stern and spring lines is used to secure the boat.

Maneuvering to the Dock

Approach the dock slowly at a 30 to 40 degree angle. Whenever possible, approach against the wind or current. Turn the drives straight & shift to neutral when you feel you have enough momentum to reach the dock. Use reverse on the engines while turning the steering wheel toward the dock to slow the boat and pull the stern toward the dock as the boat approaches. Straighten the drives and use the engines to stop the boat if it is still moving forward against the pilings. If you executed your approach properly, the boat will lightly touch the pilings at the same time the forward momentum is stopped. Have the dock lines ready and secure the boat as soon as it stops. Use fenders to protect the boat while

it is docked. Keep the engines running until the lines are secured.

Backing into a Slip

Approach the slip with the stern against the wind or current and the drives straight ahead. Use the engines and turn the steering wheel to maneuver the boat into alignment with the slip. Reverse the engines and slowly back into the slip. Shift from reverse to neutral frequently to prevent the boat from gaining too much speed. Move the stern right and left by shifting the engines in and out of gear or turning the wheel. When nearly in the slip all the way, straighten the drives and shift to forward to stop. Keep the engines running until the lines are secured.


Securing Dock Lines

Securing a boat that is tied along side the dock typically requires a bow and stern line and two spring lines. The bow and stern lines are usually secured to the dock at a 40° angle aft of the stern cleat and forward of the bow cleat. The after bow spring line is secured to the dock at a 40° angle aft of the after bow spring cleat. The forward quarter spring line is secured to the dock at a 40° angle forward of the stern cleat or the stern spring cleat. The spring lines keep the boat square to the dock and reduce fore and aft movement while allowing the boat to move up and down with the tide.


Securing a boat in a slip is somewhat different. It typically requires two bow lines secured to pilings on each side of the bow, two stern lines secured to the dock and two spring lines that prevent the boat from hitting the dock. The bow lines are typically secured with enough slack to allow the boat to ride the tide. The stern lines are crossed. One line runs from the port aft boat cleat to the starboard dock cleat and the other line runs from the starboard aft boat cleat to the port cleat on the dock. The stern lines center the boat, control the forward motion, and allow the boat to ride the tide. Two forward quarter spring lines typically are secured to the stern cleats and to mid ship pilings or cleats. The spring lines keep the boat from backing into the dock while allowing it to ride the tide.

Leaving the Dock

Always start the engines and let them warm up for several minutes before releasing the lines. Boats steer from the stern and it is important that you achieve enough clearance at the stern to maneuver the boat as quickly as possible. Push the stern off and maneuver such that you get stern



Securing The Boat Along Side A Dock (Typical)



Securing The Boat In A Slip (Typical)

clearance quickly. Proceed slowly until well clear of the dock and other boats.

Mooring


Approach the mooring heading into the wind or current. Shift to neutral when you have just enough headway to reach the buoy. Position a crew member on the bow to retrieve the mooring with a boat hook and secure the line. Keep the engines running until the line is secured.

Leaving a Mooring

Start the engines and let them warm up for several minutes before releasing the mooring line. The boat will already be headed into the wind, so move it forward enough to loosen the line and untie it. Back the boat away from the mooring until you can see the buoy. Move the boat slowly away from the mooring.

Anchoring

Make sure the bitter end of the anchor line is attached to boat before dropping the anchor. Bring the bow into the wind or current and put the engine in neutral. When the vessel comes to a stop,



lower the anchor over the bow. Pay out anchor line so that it is at least 5 to 7 times the depth of the water and

secure the line to a cleat. Use caution to avoid getting your feet or hands tangled in the line. Additional scope of 10 times the depth may be required for storm conditions. Check landmarks on shore to make sure the anchor is not dragging. If it is dragging, you will have to start all over. It is prudent to use two anchors if you are anchoring overnight or in rough weather.

Releasing the Anchor

Release the anchor by driving the boat slowly to the point where the anchor line becomes vertical. It should release when you pass that point. If the anchor doesn't release right away, stop the boat directly above the anchor and tie the line to the cleat as tight as possible. The up and down movement of the boat will usually loosen the anchor within a minute. Make sure you secure the anchor and properly stow the line before operating the boat.



NEVER ANCHOR THE BOAT BY THE STERN. THE STERN OF THE BOAT IS VULNERABLE TO SWAMPING FROM WAVE ACTION AND WIND AND CURRENT WILL PUT MORE STRESS ON THE ANCHOR WHEN IT IS ATTACHED TO THE STERN. ONLY ANCHOR THE BOAT BY THE BOW

12.6 Controls, Steering, or Propulsion System Failure:

If the propulsion, control or steering system fails while you are operating the boat, bring both throttles to idle and shift to neutral. Decide whether you need to put out the anchor to prevent the boat from drifting or to hold the bow into the seas. Investigate and correct the problem if you can. Turn the engines off before going into the engine compartment to make repairs. If you are unable to correct the problem, call for help.

If only one engine has failed, you can usually run home on the other engine. Be careful not to apply too much power to the engine that is running. When only one engine is used to power a twin engine boat, that engine is over propped and can be overloaded if too much throttle is applied. You should contact your dealer or the engine manu-

facturer for the maximum power settings when running on one engine.

12.7 Collision

If your boat is involved in a collision with another boat, dock, piling or a sandbar, your first priority is to check your passengers for injuries and administer first aid if necessary. Once your passengers situations are stabilized, thoroughly inspect the boat for damage. Check below decks for leaks and the control systems for proper operation. Plug all leaks or make the necessary repairs to the control systems before proceeding slowly and carefully to port. Request assistance if necessary. Haul the boat and make a thorough inspection of the hull and running gear for damage.

12.8 Grounding, Towing and Rendering Assistance

The law requires the owner or operator of a vessel to render assistance to any individual or vessel in distress, as long as his vessel is not endangered in the process.

If the boat should become disabled, or if another craft that is disabled requires assistance, great care must be taken. The stress applied to a boat during towing may become excessive. Excessive stress can damage the structure of the boat and create a safety hazard for those aboard.

Freeing a grounded vessel, or towing a boat that is disabled, requires specialized equipment and knowledge. Line failure and structural damage caused by improper towing have resulted in fatal injuries. Because of this, we strongly suggest that these activities be left to those who have the equipment and knowledge, e.g., the U.S. Coast Guard or a commercial towing company, to safely accomplish the towing task.



THE MOORING CLEATS ON MONTEREY BOATS ARE NOT DESIGNED OR INTENDED TO BE USED FOR TOWING PURPOSES. THESE CLEATS ARE SPECIFICALLY DESIGNED AS MOORING CLEATS FOR SECURING THE BOAT TO A DOCK, PIER, ETC. DO NOT USE THESE FITTINGS FOR TOWING OR ATTEMPTING TO FREE A GROUNDED VESSEL.



WHEN TOWING OPERATIONS ARE UNDERWAY, HAVE EVERYONE ABOARD BOTH VESSELS STAY CLEAR OF THE TOW LINE AND SURROUNDING AREA. A TOW LINE THAT SHOULD BREAK WHILE UNDER STRESS CAN BE VERY DANGEROUS, AND COULD CAUSE SERIOUS INJURY OR DEATH.



RUNNING AGROUND CAN CAUSE SERIOUS INJURY TO PASSENGERS AND DAMAGE TO A BOAT AND ITS UNDERWATER GEAR. IF YOUR BOAT SHOULD BECOME GROUNDED, DISTRIBUTE PERSONAL FLOTATION DEVICES AND INSPECT THE BOAT FOR POSSIBLE DAMAGE. THOROUGHLY INSPECT THE BILGE AREA FOR SIGNS OF LEAKAGE. AN EXPERIENCED SERVICE FACILITY SHOULD CHECK YOUR UNDERWATER GEAR AT THE FIRST OPPORTUNITY. DO NOT CONTINUE TO USE YOUR BOAT IF THE CONDITION OF THE UNDERWATER EQUIPMENT IS QUESTIONABLE.

12.9 Flooding or Capsizing

Boats can become unstable if they become flooded or completely swamped. You must always be aware of the position of the boat to the seas and the amount of water in the bilge. Water entering the boat through the transom door or over the stern gunnels can usually be corrected by turning the boat into the waves. If the bilge is flooding because of a hole in the hull or a defective hose, you may be able to plug it with rags, close the thru-hull valve or assist the pumps by bailing with buckets. Put a mayday call in to the Coast Guard or nearby boats and distribute life jackets as soon as you discover your boat is in trouble.

If the boat becomes swamped and capsizes, you and your passengers should stay with the boat as long as you can. It is much easier for the Coast Guard, aircraft, or other boats to spot, than people in the water. If your boat is equipped with an EPIRB, make sure it is activated. When activated, EPIRBs will send distress code homing beacons that allow Coast Guard aircraft to identify your boat and find you quickly.

12.10 Fishing

Fishing can be very exciting and distracting for the operator when the action gets intense. You must always be conscious of the fact that your primary responsibility is the safe operation of your boat and the safety of your passengers and other boats in the area.

You must always make sure the helm is properly manned and is never left unattended while trolling. If you are fishing in an area that is crowded with other fishing boats, it may be difficult to follow the rules of the road. This situation can become especially difficult when most boats are trolling. Being courteous and exercising good common sense is essential. Avoid trying to assert your right of way and concentrate on staying clear and preventing tangled or cut lines and other unpleasant encounters with other boats. Also keep in mind that fishing line wrapped around a propeller shaft can damage the strut bearing.

12.11 Man Overboard

If someone falls overboard, you must be prepared to react quickly, particularly when you are offshore. The following procedures will help you in recovering a person that has fallen overboard.

- Immediately stop the boat and sound a man overboard alarm and have all passengers point to the person in the water.
- Circle around quickly and throw a cushion or life jacket to the person, if possible, and another to use as a marker.
- Keep the person on the driver side of the boat so you can keep him in sight at all times.
- Make sure to approach the person from the downwind side and maneuver the boat so the propellers are well clear of the person in the water.
- Turn off the engines when the person is alongside and use a ring buoy with a line attached, a paddle or boat hook to assist him to the boat. Make sure you don't hit him with the ring buoy or the boat.
- Pull the person to the boat and assist him on board.
- Check the person for injuries and administer first aid if necessary. If the injuries are serious, call for help. Refer to the Safety Equipment chapter for more information on first aid and requesting emergency medical assistance.



MOVING PROPELLERS ARE DANGEROUS. THEY CAN CAUSE DEATH, LOSS OF LIMBS, OR OTHER SEVERE INJURY. DO NOT USE THE SWIM PLATFORM OR SWIM LADDER WHILE THE ENGINE(S) ARE RUNNING. STOP THE ENGINE(S) IF DIVERS OR SWIMMERS ARE ATTEMPTING TO BOARD. ALWAYS PROPERLY STORE THE LADDER BEFORE STARTING THE ENGINE(S).

12.12 Trash Disposal

The discharge of plastic trash or trash mixed with plastic is illegal anywhere in the marine environment. U.S. Coast Guard regulations also restrict the dumping of other forms of garbage. Regional, State, and local restrictions on garbage discharges also may apply.

Responsible boaters store refuse in bags and dispose of it properly on shore. You should make sure your passengers are aware of the local waste laws and the trash management procedure on your boat. Refer to the placard mounted on your

boat for more specific information regarding solid waste disposal.

12.13 Transporting Your Boat

Your Monterey is a large boat and should only be trailered by professionals that have the knowledge and equipment to move large boats without causing damage.

Please contact your dealer or the Monterey Boats Customer Service Department if you are planning to transport your boat and have any questions in regard to the proper equipment and support for the hull.



BOATS HAVE BEEN DAMAGED BY TRAILERS THAT DON'T PROPERLY SUPPORT THE HULL. ALWAYS MAKE SURE THE TRAILER BUNKS AND PADS ARE ADJUSTED SO THEY ARE NOT PUTTING EXCESSIVE PRESSURE ON THE LIFTING STRAKES AND ARE PROVIDING ENOUGH SUPPORT FOR THE HULL. HULL DAMAGE RESULTING FROM IMPROPER TRAILER SUPPORT IS NOT COVERED BY THE MONTEREY WARRANTY.

It is illegal for any vessel to dump plastic trash ANYWHERE in the ocean or navigable waters of the United States. Annex V of the MARPOL TREATY is an International Law for a cleaner, safer marine environment. Violation of these requirements is a Class D felony and may result in civil penalty up to a \$25,000 fine and imprisonment.

U.S. Lakes, Rivers, Bays sounds and 3 miles from shore	3 to 12 miles	12 to 25 miles	Outside 25 miles
ILLEGAL TO DUMP Plastic & Garbage	ILLEGAL TO DUMP Plastic	ILLEGAL TO DUMP Plastic	ILLEGAL TO DUMP Plastic
Paper, Metal, Rags, Crockery, Glass, Dunnage, Food	Dunnage, lining & packing materials that float, also if not ground to less than one inch	Dunnage, lining & packing materials that float	

Regional state and local regulations may further restrict the disposal of garbage. The discharge of all garbage into the Great Lakes or their connecting or tributary waters is prohibited.

Typical Trash Placard (MARPOL Treaty)

NOTE THAT THE PLACARD IS SHIPPED LOOSE WITH THE BOAT TO BE MOUNTED BY THE DEALER OR BOAT OWNER

ROUTINE MAINTENANCE

13.1 Exterior Hull and Deck

Hull Cleaning-Below The Water Line

When the boat is removed from the water, clean the outer bottom surface immediately. Algae, grass, dirt and other marine growth is easier to remove while the hull is still wet. Use a pressure cleaner or a hard bristle brush to clean the surface.

Bottom Painting

Your Monterey hull is manufactured using state-of-the-art materials and processes. A layer of super tough, Ashland "AME" Resin with high density and superior adhesion properties provides an exceptionally effective barrier to osmotic blistering.

Osmosis is caused by a chemical reaction between water and substances in the hull laminate below the waterline. If water breaches the exterior gelcoat and barrier layer, it can react with the chemical components in the laminate creating acidic substances. These substances create pressure behind the gelcoat which causes blisters.



SANDBLASTING THE HULL BOTTOM WILL DAMAGE THE FIBERGLASS. BOTTOM PAINT CAN BE APPLIED OVER A DEWAXED AND SANDED GELCOAT SURFACE OR OVER A DEWAXED SURFACE PRIMED WITH A SANDLESS PRIMER. THE INSTRUCTIONS AND RECOMMENDATIONS OF THE ANTIFOULING PAINT MANUFACTURERS SHOULD BE FOLLOWED EXACTLY.



BOTTOM PAINT SHOULD BE APPLIED ONLY BY QUALIFIED MARINE PROFESSIONALS IN A BOAT YARD OR DEALERSHIP THAT SPECIALIZES IN THEIR APPLICATION. USE ONLY STANDARD, HIGH QUALITY ANTIFOULING PAINTS FROM NAME BRAND MANUFACTURERS SUCH AS INTERLUX AND PETTIT.

Most bottom paints require some maintenance. Proper maintenance is especially important when the boat is in saltwater and not used for extended periods or after dry storage. If the hull bottom has been painted with antifouling paint, contact your dealer for the recommended maintenance procedures.

Sacrificial Anodes

Sacrificial anodes are installed on the inboard engines' freshwater cooling system and on the transom. The transom anodes are connected to the bonding system and protect the metal drives, thru-hull fittings and other underwater hardware that is bonded.

The anodes are less noble than copper based alloys, aluminum and stainless steel. They will deteriorate first, protecting the more noble engine and underwater hardware against galvanic corrosion. Anodes should be checked monthly and changed when they are 75% of their original size. When replacing the anodes, make sure the contact surfaces are clean, shiny metal and free of paint and corrosion. Never paint over the anode. The bonding system should be inspected by a qualified marine electrician once a year to make sure all connections are sound and there is continuity throughout the system.

Boats stored in saltwater will normally need to have the anodes replaced every 6 months to one year. Anodes requiring replacement more frequently may indicate a stray current problem within the boat or at the slip or marina. Anodes that do not need to be replaced after one year may not be providing the proper protection. Loose or low quality anodes could be the problem. There could also be a problem in the bonding system. Contact your dealer for the proper size and type of anodes to be used and the specific installation procedure.

Fiberglass Gelcoat Surfaces

The smooth, beautiful skin of the fiberglass hull is made of gelcoat. Gelcoat is a strong but thin (though thicker than automotive paint) layer of colored resin. The best way to keep the gelcoat skin on your boat in top condition is through regular maintenance. The following guidelines will help keep gelcoat looking good for years to come.

DO'S

- Keep the gelcoat surface out of direct sunlight or covered when it is not in use.
- Wash gelcoat frequently (daily in salt or polluted environments) with mild detergent and



Transom Anodes

plenty of fresh water. Remove any stains quickly. Gelcoat is microscopically porous, so long term staining may become permanent.

- Regularly (monthly in salt or polluted environments) wax gelcoat surfaces with marine grade wax recommended for fiberglass finishes. The washing and waxing of your boat will have the same beneficial effects as they have on an automobile finish. The wax will fill minute scratches and pores thus helping to prevent soiling and will extend the life of the gelcoat.

DON'TS

- Do not use plastic or other nonporous (non-breathable) materials to cover gelcoat surfaces. Trapped moisture from condensation can cause gelcoat damage. Shrink wrap storage covers must be properly ventilated, including hull sides.
- Do not use abrasives, bleaches, ammonia, acids or harsh detergents. See your dealer for special marine formulations. Harsh abrasive and chemical cleaners are not recommended because they can damage or dull the gelcoat, reducing its life and making it more susceptible to stains.
- NEVER apply wax or buffing compound to a gelcoat surface in direct sunlight.

- Do not attempt to remove stains and scratches. Chalking, stains, and minor scratches can be removed in most cases with careful rubbing and polishing with appropriate chemicals and is best done by a professional - see your dealer.

After the boat is exposed to the direct sunlight for a period of time, the color in the gelcoat tends to fade, dull or chalk. A heavier buffing is required to bring the gelcoat back to its original luster. For power cleaning use a light cleaner. To clean the boat by hand, use a heavier automotive cleaner. Before cleaning the surfaces, read the instructions given with the cleaner. After cleaning the surfaces, apply wax and polish all fiberglass surfaces except the nonskid areas.

If the fiberglass should become damaged and need repair, contact your dealer for an authorized repair person to make the repairs.



DO NOT WAX NONSKID AREAS AS THIS COULD MAKE THEM SLIPPERY AND CONSEQUENTLY INCREASE THE POSSIBILITY OF INJURY.

APPLY NO-SLIP TAPE OR STEP PLATES ON SURFACES WHICH ARE WALKED ON. WAXED GELCOAT SURFACES ARE EXTREMELY SLIPPERY, ESPECIALLY WHEN WET.

Stainless Steel Hardware

Marine grade stainless steel components such as hardware, cleats, eyes and rails offer superior corrosion resistance. When properly maintained, stainless steel will not rust or stain, even in harsh saltwater environments. However, if not maintained, stainless steel can rust, discolor or even corrode. The following guidelines will help keep stainless steel looking good for years to come.

DO'S

- Clean stainless steel frequently (daily in salt or polluted environments) with mild soap and plenty of water. Any cleaner safe for use on glass is usually safe for stainless.
- Remove rust spots (especially around welds) immediately with a brass, silver or chrome cleaner. Irreversible pitting will develop under rust allowed to remain on stainless for any period of time.
- Remove rust stains on gelcoat. See dealer for recommended product.
- Protect stainless with waxes or polishes suitable for marine use.

DON'TS

- Do not use coarse abrasives like sandpaper or steel wool which may actually cause rusting.
- Do not use acids or bleaches which may etch the naturally occurring protective coating.
- Do not leave stainless steel in contact with iron, steel or other metals which cause contamination leading to rust or corrosion.

Gemlux Stainless Steel Hardware

Most of the stainless steel hardware on your boat is made of Gemlux, polished stainless steel. In order to ensure that your Gemlux stainless steel maintains its beautiful finish, it is critical that your care for it properly.



YOUR STAINLESS STEEL CAN BE DAMAGED BY EXPOSURE TO ACIDS AND OTHER CORROSIVE AGENTS FOUND IN MANY CLEANING PRODUCTS. A PARTIAL LIST OF ADDITIVES THAT MAY CAUSE STAINING AND A WEAKENING OF THE FINISH IS PROVIDED BELOW. USE OF THESE AND OTHER SIMILAR SOLUTIONS TO CLEAN YOUR BOAT CAN CAUSE YOUR STAINLESS STEEL TO BLEED AND WILL VOID YOUR WARRANTY.

Chlorsuphonic Acid	Sodium Hypochlorite
Ferrous Iodide	Sulphuric Acid
Hydrobromic Acid	Muriatic Acid
Iodine	On & Off Cleaner
Sodium Chlorite	Rust StainsAway
Sulphur Chloride	Ferrous Chloride
Bleach	Hydrochloric Acid
Comet	Hydrofluoric Acid
EZ-ON EZ-OFF Cleaner	Sodium Bifluoride
Ferric Chloride	Stannic Chloride
Fluorine	SnoBol
Hydrofluosilicic Acid	Soft Scrub
Silver Chloride	Marine Spray Nine

When using the boat in saltwater, the hardware should be washed with soap and water after each use. Frequent cleaning of your of your stainless steel with soap, water and Gemlux Cleaning Wax will help maintain the finish. Always rinse the metal thoroughly with clean water and dry completely. Clean soft cloths or pads should be used. The use of steel wool pads or other highly abrasive brushes or sponges are not recommended and will damage the surface.

Contamination of the surface by chemicals, dirt or other material hinders the passivation process and traps corrosive agents, thus reducing corrosion protection. If your stainless is exposed to such chemicals it should be re-passivated with Gemlux Passivation solution.

For purchase information on the Gemlux Cleaning Wax or Gemlux Passivation Solution, please contact Gemlux at: Phone: 888-436-5891 Fax: 904-269-5905 or on the web at www.gemlux.com

GEMLUX MAINTENANCE INSTRUCTIONS

Job	Cleaning Agents	Method	Comments
Routine Cleaning	Soap and Water	Apply with a sponge or soft cloth. Dry area completely.	Once your stainless is free of discoloration and/or bleeding, spray GEMLUX Passivation Solution directly onto stainless. Allow to cure for 30-60 seconds. Rinse with fresh water and dry the area. This solution will help re-passivate the stainless steel.
Stubborn stains, discoloration or bleeding	GEMLUX Cleaning Wax	Apply with soft, dry cloth.	



UNDER NO CIRCUMSTANCES SHOULD ANY ABRASIVE MATERIALS SUCH AS SANDPAPER, BRONZE WOOL, OR STEEL WOOL BE USED ON STAINLESS STEEL. DAMAGE TO THE HARDWARE WILL RESULT.

Anodized Aluminum Surfaces

Anodized aluminum should be washed periodically with soap and water to keep it clean. If the boat is used in saltwater or polluted water, the aluminum should be washed with soap and water after each use. Saltwater allowed to remain on anodized aluminum will penetrate the anodized coating and attack the aluminum.



ONE DRAWBACK TO METAL PROTECTORS IS THAT THEY CAN MAKE THE METAL SLIPPERY. THEREFORE, METAL PROTECTORS SHOULD NOT BE USED ON TOWER LADDERS, STEERING WHEELS AND OTHER AREAS WHERE A GOOD GRIP AND SURE FOOTING IS IMPORTANT.

Stains can be removed from anodized aluminum with a metal polish or fine polishing compound. To minimize corrosion, use a caulking compound or Teflon based sealer to bed hardware and fasteners mounted to aluminum fabrications. If the anodized coating is badly scratched it can be touched up with paint. With proper care, anodized aluminum will provide many years of service.

Powder Coated Aluminum

Powder coated aluminum should be washed periodically with soap and water to keep it clean. If the boat is used in saltwater or polluted water, the aluminum should be washed with soap and water after each use. Saltwater allowed to remain on powder coated aluminum will penetrate the coating and attack the aluminum, usually around fasteners and hardware mounted to the aluminum.

Once a month check for damaged powder coating and corrosion around fasteners and hardware. Nicked or badly scratched powder coating can be sanded and touched up with enamel paint. Corrosion around fasteners will have to be sanded, then touched up with paint. The fasteners will require fiber washers and sealing with caulk or a Teflon based sealer to isolate the fastener from the aluminum and prevent damage to the paint or powder coating when the fastener is installed. Periodically applying automotive or boat wax to the powder coating will provide additional protection from the harsh effects of saltwater.

Always repair scratches, nicks and corroded areas in powder coating as soon as possible. Corrosion left unaddressed will lift the powder coating allowing moisture to travel between the power coating and the aluminum causing the corrosion to spread below the coating and damage the aluminum.

If excessive chipping and peeling occurs, it could be an indication of an electrical fault in the boat or aluminum fabrication. You should contact a qualified marine electrician to inspect your boat immediately and correct the problem if you suspect that your boat may have a fault in the aluminum frame. You should also contact Monterey Boats Customer Service.

Note: Boats that are towed behind larger vessels require special attention to the aluminum hardware. The salt spray, salty steam, and chemicals in exhaust gases are particularly corrosive and will eventually penetrate and damage the surface of anodized or powder coated aluminum. It is imperative that the boat and the aluminum are cleaned thoroughly at the completion of each trip or at the end of each day on long cruises to reduce accelerated deterioration of the anodizing or powder coating and premature corrosion to the aluminum.

Chrome Hardware

Use a good chrome cleaner and polish on all chrome hardware.

Acrylic Plastic Glass

Acrylics and Plexiglas have properties that make them ideal for the marine environment. Components such as cabin doors and deck hatches need special care to prevent scratches and other damage. The following guidelines will help keep acrylics and Plexiglas looking good for years to come.

DO'S

- Wash your hatches, windshield connector, side curtains and other clear plastic pieces, as well as other acrylic components on your boat with a mild soap and plenty of lukewarm water.
- Use a clean, soft cloth, applying only light pressure.
- Rinse with clear water and dry by blotting with a damp cloth or chamois.
- Grease, oil or tar may be removed with a good grade of hexane, aliphatic naphtha or kerosene. These solvents may be obtained at a paint or hardware store and should be used in accordance with the manufacturer's recommendations.

- To maintain a high-luster finish on your acrylics, we recommend that after properly cleaning, apply Meguiar's™ Mirror Glaze #10 with a soft towel. Note: If slight scratches appear on acrylics, use Meguiar's™ Mirror Glaze #17

Note: Clear plastic (Isinglass) is subject to ultraviolet (sunlight) degradation over time. It may turn yellow-brown (a burnt appearance) and get brittle.

Two things that can accelerate this degradation are:

1. Direct contact with aluminum or stainless steel frames. Use "Standoffs."
2. In salt water areas, dried salt crystals on the plastic will amplify sunlight. Wash after each use and/or windy days.

DON'T'S

- Do not subject acrylic material to high temperatures when polishing.
- Do not use glass cleaning sprays, cleaners containing ammonia, scouring compounds, or solvents like acetone, alcohol, gasoline, benzene, carbon tetrachloride or lacquer thinner.
- Do not use masking tapes, duct tapes or packing tapes on your acrylic materials.
- Do not drill holes in your acrylic materials without proper drill bits (special bits are used in acrylic material to avoid damage).

13.2 Upholstery, Canvas and Enclosures

Marine Interior Vinyl Upholstery

The vinyl upholstery used on the headliner and some cushions in the cabin should be cleaned periodically with soap and water. Any stain, spill or soiling should be cleaned up promptly to prevent the possibility of permanent staining. When cleaning, always rub gently. Avoid using products containing ammonia, powdered abrasive cleaners, steel wool, strong solvents, acetone and lacquer solvents or other harsh chemicals as they can cause permanent damage or shorten the life of vinyl. Never use steam heat, heat guns or hair dryers on vinyl.

Stronger cleaners, detergents and solvents may be effective in stain removal, but can cause either

immediate damage or slow deterioration. Lotions, sun tan oil, waxes and polishes, etc., contain oils and dyes that can cause stiffening and staining of vinyl.

The following are typical stains and cleaning tips for marine vinyl:

- **For normal cleaning** – In general most common stains can be cleaned using warm, soapy water and clear water rinses. Moderate scrubbing with a medium bristle nylon brush will help to loosen soiling material from the depressions of embossed surfaces. For stubborn stains, use commercially available mild detergents in accordance with manufacturers instructions.

Full strength rubbing alcohol or mineral spirits may be tried cautiously as a last resort on very stubborn stains, if the above suggestions do not work. Indiscriminate use of any solvent or solvent containing cleaner can severely damage or discolor vinyl.

Certain stains may become permanently set unless they are removed immediately. The procedure for the removal of more severe staining agents are outlined below.

- **Ballpoint Ink, Permanent Marker** – Ink spots will stain vinyl permanently. Immediate wiping with rubbing alcohol in a well-ventilated area will remove much of the stain.
- **Oil based paint** – The use of turpentine in a well ventilated area will remove any fresh paint. Dried paint must be moistened carefully with a semisolid gel-type stripper so that the softened paint can be gently scraped away. Rinse with soap and water.



DIRECT CONTACT WITH PAINT STRIPPERS WILL REMOVE THE PRINT PATTERN FROM VINYL. PAINT STRIPPERS ARE VERY CORROSIVE. TAKE CARE TO AVOID SKIN CONTACT BY WEARING PROTECTION.

- **Latex paint** – Fresh paint can be wiped off with a damp cloth. Hot soapy water will normally remove dried latex.
- **Tar, Asphalt** – Remove immediately as prolonged contact will result in a permanent stain. Use a cloth lightly dampened with mineral spirits and rub the stain gently, working from

the outer edge of the stain towards the center in order to prevent spreading. Rinse with soap and water.

- **Crayon, mustard, ketchup** – Sponge with mild soap and water. For stubborn stains that may have set, use a cloth soaked in diluted mild detergent with gentle rubbing. Any remaining stain should be washed with diluted bleach. Rinse repeatedly with clean water.
- **Chewing gum** – Scrape off as much as possible with a dull knife. Rubbing with an ice cube will assist and make it easier to remove when scraping. The remaining gum should then be removed in a well ventilated area using a cloth saturated with mineral spirits. Use light rubbing. Rinse thoroughly with clean water.
- **Lipstick, grease, oil, eye shadow, shoe polish** – Apply a small quantity of mineral spirits by means of a cloth with gentle rubbing. Take care not to spread the stain by smearing it beyond its original source. No time should be lost in removing shoe polish as it contains a dye that will cause permanent staining. Rinse thoroughly with water.
- **Candy, ice cream, coffee, tea, fruit stains, liquor, wine, suntan lotion, soft drinks** – Use clear lukewarm water and a sponge repeatedly. Any loose material should be gently scraped with a dull knife. Any soiled area remaining after drying should be gently rubbed with a cloth spotted with a mild detergent solution. Rinse thoroughly with clean water.
- **Blood, leaf residue** - Sponge the area with a clean cloth soaked in cool water. If stubborn stains remain, use household ammonia and rinse repeatedly with a clean, wet cloth. Do not use hot water or soapsuds, as this will set the stain.
- **Bird excreta, nausea stains** - Sponge the area with soapy water containing diluted bleach until the stain is removed. Rinse thoroughly with water.
- **Urine Stains** – Sponge with soapy water containing a small amount of household ammonia. Rinse thoroughly with clean water.

- **Surface mildew** – Wash with diluted bleach using a soft nylon brush for stubborn growth. Rinse repeatedly with clean cold water.

The following are typical stains and cleaning tips for interior marine vinyl:

- **Dry soil, dust and dirt, dried on dirt** - Remove with a soft cloth. Wash with a soft cloth or nylon brush dampened with water.
- **Variations in surface gloss** - Wipe with a water dampened soft cloth and allow to air dry.
- **Stubborn dirt** - Wash with a soft cloth or soft nylon brush dampened with Ivory Soap® and water. Rinse with clean water.
- **Stubborn spots and stains** - Spray with Tannery Car Care Cleaner® and rub with a soft cloth. Rinse with clean water.
- **Liquid spills** - Wipe immediately with a clean absorbent cloth. Rinse with clean water.
- **Food grease and oily stains** - Spray immediately using either Fantastik Cleaner® or Tannery Car Care Cleaner®, wiping with a soft cloth. Take care not to extend the area of contamination beyond its original boundary. Rinse with clean water.

Additional Warnings for Vinyl Fabrics

- Detergents should not be used on a regular or repeated basis for normal cleaning.
- Powdered abrasives, cleaners containing abrasives, steel wool and industrial strength cleaners are not recommended for vinyl.
- Any lacquer solvent will cause immediate, irreparable damage to the vinyl.
- Wax should never be used on any vinyl upholstery, as it will cause premature embrittlement and cracking.
- Dilute chlorine bleach before using. Never use at full strength.
- If flammable solvents such as alcohol, turpentine or varsol are used for cleaning, then only small quantities should be employed in a well ventilated area. Exercise proper care by advising any personnel in the area and keep

away from any ignition source. Always wear protective gloves.

Marine Interior Fabrics

Spot clean only with water based shampoo or foam upholstery cleaner. Pretest a small, inconspicuous area before proceeding. Do not over wet. Do not use solvents to spot clean. Pile fabrics may require brushing with a nonmetallic, stiff bristle brush to restore appearance.

Note: Water extraction or steam cleaning is not a recommended cleaning method. Cushion covers should not be removed and laundered.

To prevent overall soiling, frequent vacuuming or light brushing with a nonmetallic, stiff bristle brush to remove dust and grime is recommended. When cleaning a spill, blot immediately to remove spilled material. Clean spot or stains from the outside to the middle of the affected area to prevent circling.

Use a professional furniture cleaning service when an overall soiled condition has been reached.

Marine Exterior Vinyl Upholstery with PreFixx® Coating

Monterey Boats uses OMNOVA white, smoother and embossed pleated vinyl material with PreFixx top coating. All other accent embossed white and colored vinyl requires different care and maintenance.

PreFixx Cleaning Instructions

PreFixx is engineered so that upholstery can be cleaned again and again without showing signs of wear. With easy cleanability, proven stain and abrasion resistance, PreFixx protective finish can reduce maintenance costs and frequent reupholstery.

Durability

Creates a barrier that resists stains from penetrating to the surface of the vinyl for proven, long-lasting protection. With laboratory-tested stain resistance and improved wear properties, Bolta-Soft® upholstery treated with PreFixx protective finish can retain a "like-new" appearance longer.

Easy Maintenance

Enables most common stains like dirt and smudges to wipe off easily. Many difficult stains like ball-point ink also can be cleaned with active solvents,

such as nail polish remover, without damaging the PreFixx protective finish (when recommended cleaning instructions are followed).

Normal Care and Cleaning

Remove ordinary dirt and smudges with a mild soap and water solution and a clean, soft cloth or towel. Dry with a soft, lint-free cloth or towel.



THE USE OF VINYL "CONDITIONERS" OR "PROTECTANTS" IS NOT RECOMMENDED AND SHOULD BE AVOIDED ON VINYL UPHOLSTERY TREATED WITH PREFIXX PROTECTIVE FINISH.

Special Cleaning Problems

Although BoltaSoft upholstery treated with Pre-Fixx protective finish is resistant to most common stains, the dyes and pigments in some staining agents have the ability to create a permanent stain if not treated properly. To clean difficult stains from upholstery treated with PreFixx protective finish, locate the staining agent in lists below and follow its recommended cleaning method. For best results, treat all stains immediately.

Cleaning Tip: To determine the method and type of cleaners, the source of the stain should be identified.

Staining Agents: Baby oil, ketchup, chocolate, motor oil, olive oil, grape juice, urine, blood, hair oil tonic, tea, coffee and betadine. Use Method 1.

Staining Agents: Eye shadow, crayon and grease. Use Method 1. If stains remain, use Method 2.

Staining Agents: Tobacco tar (nicotine) permanent felt tip marker, yellow mustard, lipstick, ballpoint pen and spray paint. Use Method 1. If stains remain, use Method 2. For stubborn stains still remaining, use Method 3.

The recommended cleaners used in Cleaning Methods 1,2 and 3 are progressively more aggressive. Often, it is better to begin with the least aggressive cleaner and move the next strongest only if the stain remains. NEVER EXCEED a staining agent's recommended cleaner or cleaning method, however.

Method 1

Use one of the following cleaners with a soft cloth or damp sponge. Rinse area with fresh water, and then dry with a clean, lint-free cloth.

- Formula 409® All-Purpose Spray Cleaner
- Fantastik® Spray Cleaner

Method 2

Use a solvent-type cleaner, such as rubbing alcohol (isopropyl alcohol). Rinse cleaned area with fresh water, and then dry with a clean, lint-free cloth.

Method 3

Use a strong, active solvent cleaner diluted in water (70% water/30% solvent cleaner), such as nail polish remover (acetone/water). Clean with a soft cloth or damp sponge. Stain should be removed with less than six (6) rubs. If the stain persists after six rubs, the stain has set and probably cannot be removed. Rinse cleaned area with fresh water, and then dry with a clean, lint-free cloth.



SOME SOLVENTS ARE HIGHLY FLAMMABLE. EXERCISE PROPER CARE IN CLEANING AND NOTIFY PERSONNEL IN AREA OF DANGER. WEAR RUBBER GLOVES DURING ALL CLEANING ACTIVITIES. USE CAUTION IN CLEANING AROUND BUTTONS, STITCHING AND WOODEN OR DECORATIVE TRIM, SINCE THESE SOLVENTS COULD SERIOUSLY DAMAGE SUCH AREAS.

Exterior Carpet

Exterior carpet manufactured by Syntec® Industries is produced with a special blend of resilient fibers to withstand traffic and retain its beauty.

Carpets manufactured by Syntec are inherently stain-resistant. To keep your carpet at its best, we recommend regular vacuuming for general cleaning, soap and water for hard-to-remove spots and an approved cleaner for deep cleansing and to revitalize the carpet.

Stain Removal

If a spill does occur, it can easily be removed by following the stain removal chart. All stains should be removed as soon as possible, as this enhances the ability to remove the stain.

CARPET STAIN REMOVAL INSTRUCTIONS

<p>Miscellaneous Stains</p> <p>Coffee, Tea, Coke, Dye, Fruit Juice, Ice Cream, Motor Oil, Clay, Grease, Blood, Catsup, Chocolate, Milk, Rust, Latex Paint, Water Colors, Berry Stains, Egg, Salad Dressing, Wine, Furniture Polish, Fish Formula, Mayonnaise or urine.</p>	<p>Removal Process</p> <p>Apply warm water and household detergent in minimal amounts to the stained area. Sponge or scrape until stain is removed and wash thoroughly with clean water.</p>
<p>Persistent Stains</p> <p>Chewing Gum, Crayon, Ink, Wax, Lipstick, Tar Polish or Oil Paint.</p>	<p>Removal Process</p> <p>Apply warm water and household detergent. Work well into the stained area, then flush with warm water.</p>

Note: Most stains should be removed easily from Olefin fibers. If the stain persists, the cleaning procedure should be repeated to ensure stain removal. Remember, the sooner the stain removal process begins, the easier the stain will be to remove. Under no circumstances should any solvent normally associated with the dry cleaning of apparel (perchloroethylene, carbon tetrachloride, etc,) be utilized, as permanent damage to the fiber will result.

Canvas and Side Curtains

The enclosure for the hardtop and other covers on your boat is made of acrylic materials. To gain longer life and top performance from canvas, including windshield connector, side and aft curtains, bow and cockpit covers, drop curtain, aft curtain and cockpit covers, we recommend the following:

- The canvas and clear plastic are not designed to withstand long periods of time exposed to the elements as a protective cover at dock side or when your boat is in storage. A full, properly fitted, light-colored, mooring transportation or storage cover should be used for these purposes.
- If canvas gets wet during use, remove side curtains and open the windshield vent so seams can dry out. The air circulation will allow all canvas to dry and prevent the growth of mildew. **Never store wet or damp canvas.**
- Occasionally set up all canvas and curtains and hose down with fresh water to remove accumulated soot and dirt. Sweep or brush the underside of the canvas to prevent the accumulation of dirt and mildew.
- The outer canvas surfaces can be cleaned with a soft scrub brush and either automotive convertible top cleaners or household cleaners suitable for use on acrylic surfaces. The underside of the canvas may be periodically sprayed with a spray disinfectant to prevent the growth of mildew.
- Do not store or your boat under trees. Tree sap is very corrosive to canvas and can also be harmful to gelcoat and vinyl interiors.
- Adjust top bows to eliminate pockets in which rain water can accumulate. The weight of this accumulated water can collapse the top or bag the canvas.
- Zippers and snaps should never be forced. Occasionally lubricate with silicone/Teflon grease.
- When trailering, dismantle, roll or fold and securely stow all canvas to prevent damage. Monterey recommends purchasing a transportation cover to keep your boat clean on the road. Your Monterey Dealer will assist you in finding a suitable cover (not available from Monterey Boats).
- Do not allow petroleum products or bug sprays to come in contact with canvas.

Note: Your Monterey boat is basically and open vehicle. Therefore, in spite of well-designed and well-fitting canvas enclosures, your boat is not water-proof. We have made every effort to design these enclosures to conform with the boat, but a certain amount of leakage may occur, especially at the seam lines. After cleaning with soap and water, allow seams to thoroughly dry. A sealant can be applied on the seams to somewhat close the needle holes according to the manufacturer's instructions.

- Side curtains and clear connectors can be cleaned with mild soap and water. They should not be allowed to become badly soiled. Dirt, oil, mildew, and cleaning agents containing ammonia, will shorten the life of the vinyl that is used for clear curtains. After cleaning the curtains and allowing them to dry, apply a non-lemon furniture polish or an acrylic glass and clear plastic protector to extend the life of the curtains. Vinyl curtains should be stored either rolled or flat, without folds or creases. Folding the curtains will make permanent creases that could cause the vinyl to crack.

Note: Do not use any polish containing lemon scents or lemon. The lemon juice will attack the vinyl and shorten its life.



NEVER TRAILER YOUR BOAT WITH THE CANVAS ENCLOSURE (INCLUDING SIDE CURTAINS, AFT CURTAIN, WINDSHIELD CONNECTOR, BOW COVER AND COCKPIT COVER) UP. MONTEREY BOATS' CANVAS IS NOT DESIGNED TO WITHSTAND THE HIGH WIND LOADS OF TRAILERING. SEVERE WIND DAMAGE CAN OCCUR SUCH AS TORN MATERIAL, FASTENER PULL-OUT AND FRAME DISTORTION. DAMAGE CAUSED BY TRAILERING IS NOT COVERED UNDER THE LIMITED WARRANTY.

DO NOT OPERATE ENGINES, FUEL CONSUMING HEATERS OR BURNERS WITH THE CANVAS ENCLOSURES CLOSED. THE COCKPIT MUST BE OPEN FOR LEGAL VENTILATION AND TO PREVENT THE POSSIBLE ACCUMULATION OF CARBON MONOXIDE FUMES, WHICH COULD BE LETHAL.



CARBON MONOXIDE IS A LETHAL, TOXIC GAS THAT IS COLORLESS AND ODORLESS. IT IS A DANGEROUS GAS THAT WILL CAUSE DEATH IN CERTAIN LEVELS.

13.3 Cabin Interior

The cabin interior can be cleaned just like you would clean a home interior. The wood floors and steps can be vacuumed and cleaned with a mixture of water and Murphy's Oil Soap or white vinegar and water. Wipe the wood dry with a clean towel. To preserve the cherry and teak woodwork, use furniture polish with wax. To maintain the carpeting, use a vacuum cleaner.

Because air and sunlight are very good cleansers, periodically put cushions, sleeping bags, etc. on deck, in the sun and fresh air to dry and air out. If cushions or equipment get wet with saltwater, remove and use clean, fresh water to rinse off the salt crystals. Salt retains moisture and will cause damage. Dry thoroughly and reinstall.

Vinyl headliner material should be cleaned periodically as explained in the previous section. Avoid using products containing ammonia, bleach, or harsh chemicals as they can shorten the life of vinyl.

If you leave the boat for a long period of time, put all cushions on their sides, open all interior cabin and locker doors, and hang a commercially available mildew protector in the cabin.



ALWAYS READ THE LABEL CAREFULLY ON MILDEW PROTECTORS. REMOVE THE PROTECTOR AND ALLOW THE CABIN TO VENTILATE COMPLETELY BEFORE USING THE CABIN.

Karadon Surfaces

A mild liquid detergent and water or ammonia-based cleaners will remove most dirt and stains from Karadon. For heavy cleaning, oil, and grease, use Fantastik® spray cleaner. Rinse with a clean cloth moistened with fresh water. Wipe dry with a clean cloth.

In most cases, Karadon can be repaired if accidentally damaged. Minor damage, including scratches, general or chemical stains, scorches or burns,

and minor impact marks, can be repaired with a light abrasive cleanser and a Scotch-Brite® pad. For heavier damage, light sanding and machine buffing may be necessary so contact your dealer or a professional.

- Avoid exposing Karadon to strong chemicals, such as paint removers, oven cleaners, etc. If contact occurs, quickly flush the surface with water.
- Remove nail polish with a non acetone-based polish remover and flush with water.
- Do not cut directly on Karadon counter tops.

13.4 Bilge and Engine Compartment

To keep the bilge clean and fresh, use a commercial bilge cleaner regularly. Follow the directions carefully. The engines and engine room should be kept clean and free of oil accumulation and debris. All exposed pumps and metal components, including the engines and drive gear, should be sprayed periodically with a protector to reduce the corrosive effects of the high humidity always present in these areas.

Maintenance intervals are outlined in the engine owner's manuals. Their recommendations should be followed exactly.

Periodically check the bilge pumps for proper operation and clean debris from the strainers and float switches. Inspect all hoses, clamps and thru-hulls for leaks and tightness on a regular basis and operate all thru-hull valves at least once a month to keep them operating properly.

A flow of air into the bilge is provided by vents located in the deck near the engine compartment. Periodic inspection and cleaning of the ventilation ducts is necessary to ensure adequate air circulation.

Engines

Proper engine maintenance is essential to the proper performance and reliability of your inboard engines. Maintenance schedules and procedures are outlined in your engine owner's manual. They should be followed exactly.

Proper engine operation requires a good supply of clean, dry fuel. Improper marina fuel storage techniques, limited boat usage, etc. can cause the fuel to become contaminated.

The age of fuel can affect engine performance. Chemical changes occur as the fuel ages that can cause deposits and reduce the cetane rating of the fuel. Severely degraded fuel can damage the engine and boat fuel tank and lines. Therefore, if your boat is not being run enough to require at least one full tank of fresh fuel a month, a fuel additive should be added to protect it from degradation. Your dealer or the engine manufacturer can provide additional information on fuel degradation and fuel stabilizers recommended for your engine.

Generator

The engine maintenance required on the generator is similar in many ways to the main engines. The engine incorporates a pressure-type lubrication system and a fresh water cooled engine block which is thermostatically controlled. The most important factors to the generator's longevity are proper ventilation and maintenance of the fuel system, ignition system, cooling system, lubrication system and the AC alternator.

Maintenance schedules and procedures are outlined in your generator owner's manual. They should be followed exactly.

Note: The generator charges the house batteries just enough to compensate for the DC electrical current the engine requires to operate. Therefore, it is important to activate the battery charger to maintain the house and engine batteries whenever the generator is running.

13.5 Drainage System

It is essential that the following items be done periodically to maintain proper drainage of your boat:

- Clean the cockpit drains with a hose to remove debris that can block water drainage.
- Frequently test the automatic bilge pump switches for proper operation. This is accomplished by lifting the float switch until the pump is activated. You can also use a garden hose to flood the bilge until the water level is high enough to activate the pump.
- Flush all gravity drains with fresh water to keep them clean and free flowing.

- Operate the thru-hull valves once a month and service as required.

Note: All drains and pumps must be properly winterized before winter lay-up.



NEVER USE HARSH CHEMICAL DRAIN CLEANERS IN MARINE DRAIN SYSTEMS. PERMANENT DAMAGE TO THE HOSES AND FITTINGS MAY RESULT.

SEASONAL MAINTENANCE

14.1 Lay-up and Storage

Before Hauling:

- Pump out the head and holding tank. Flush the holding tank using clean water and a deodorizer. Pump out the cleaning solution.
- The fuel tanks should be left nearly full to reduce condensation that can accumulate in the fuel tank. Allow enough room in the tank for the fuel to expand without leaking out the vents.
- The age of fuel can affect engine performance. Chemical changes occur as the fuel ages that can cause deposits and reduce the octane rating of the fuel. Severely degraded fuel can damage the engine and boat fuel tank and lines. Therefore, if your boat is not being run enough to require at least one full tank of fresh fuel a month, a fuel additive should be added to protect it from degradation. Operate the boat for at least 15 minutes after adding the additive to allow the treated fuel to reach the engine.
- Algae can grow in the accumulated water in diesel fuel tanks. This condition is most prevalent in warm climates. Adding a high quality diesel fuel additive containing an algaecide may be required to control algae during storage in your area.

Your dealer or the engine manufacturer can provide additional information on fuel degradation and fuel additives recommended for your engine. For more recommendations for your specific area, check with your dealer.

- Drain water from the fresh water system.
- Consult the engine owner's manual for detailed information on preparing the engines for storage.

Lifting

It is essential that care be used when lifting your boat. Make sure the spreader bar at each sling is at least as long as the distance across the widest point of the boat that the sling will surround. Put the slings in position. Refer to the Slings Locations picture in this section for the correct position of the lifting slings. There are also sling tags on the side deck. The fore and aft slings should be tied together to prevent the slings from sliding on the hull.

The bow should always be slightly higher than the stern while lifting the boat. This will allow the water to drain from the engine exhaust system and prevent water from surging over the risers and into the engine.



Sling Locations



BOATS HAVE BEEN DAMAGED FROM IMPROPER LIFTING AND TRANSPORTING WITH FORK LIFTS. THE FORKS PLACE EXTREME PRESSURE POINTS ON THE HULL AND COULD CAUSE SERIOUS STRUCTURAL DAMAGE.

SEVERE GELCOAT CRAZING OR MORE SERIOUS HULL DAMAGE CAN OCCUR DURING HAULING AND LAUNCHING IF PRESSURE IS CREATED ON THE GUNWALES (SHEER) BY THE SLINGS. SPREADERS ARE NOT REQUIRED IF BELTS ARE NOT CREATING PRESSURE (CABLE DRUMS FURTHER APART THAN BEAM OF BOAT). FLAT, WIDE BELTING SLINGS AND SPREADERS LONG ENOUGH TO KEEP PRESSURE FROM THE GUNWALES ARE ESSENTIAL. DO NOT ALLOW ANYONE TO HAUL YOUR BOAT WHEN THE SPREADERS ON THE LIFT ARE NOT WIDE ENOUGH TO TAKE THE PRESSURE OFF THE GUNWALES.



IMPROPER LIFTING AND HANDLING WITH A FORK LIFT, CRANE OR TRAVEL LIFT CAN CAUSE SEVERE HULL AND DECK DAMAGE THAT WILL VOID THE MONTEREY WARRANTY.



BOATS HAVE BEEN DAMAGED BY IMPROPER BLOCKING AND CRADLES THAT DON'T PROPERLY SUPPORT THE HULL. ALWAYS MAKE SURE THE BLOCKS, BUNKS AND PADS ARE ADJUSTED SO THEY ARE NOT PUTTING PRESSURE ON THE LIFTING STRAKES AND ARE PROVIDING ENOUGH SUPPORT FOR THE HULL. YOU SHOULD ALLOW ONLY EXPERIENCED PROFESSIONAL BOAT YARD PERSONNEL TO LIFT, BLOCK OR CRADLE YOUR BOAT. HULL DAMAGE RESULTING FROM IMPROPER CRADLE AND BLOCKING SUPPORT WILL VOID THE MONTEREY HULL WARRANTY.

Supporting The Boat For Storage

A well-made cradle or proper blocking is the best support for your boat during storage.

When supporting the boat with blocking:

- Make sure the boat is blocked on a level surface and the bow is high enough so that water will drain from the bilge, cockpit and exhaust system.
- Make sure the keel is supported with large, solid wood blocks in at least three points.
- Use at least three heavy duty jacks on each side of the hull and make sure the boat is level from side to side. The jacks must be on a solid surface like packed gravel, concrete or pavement. All of the supports must be set up properly to prevent the boat from shifting while it is in storage.

When storing the boat on a cradle:

- Make sure the cradle is well supported and placed on a level surface with the bow high enough so that water will drain from the bilge, cockpit and exhaust system.
- The cradle must be in the proper fore and aft position to properly support the hull. When the cradle is designed properly and in the correct location, the bunks should match the bottom of the hull and should not be putting pressure on the lifting strakes.

Preparing The Boat For Storage

- Remove the bilge drain plug.



Proper Cradle Support

- Thoroughly wash the fiberglass exterior, especially the antifouling portion of the bottom. Remove as much marine growth as possible. Lightly wax the exterior fiberglass components.
- Remove all oxidation from the exterior hardware, and apply a light film of moisture displacing lubricant.
- Remove propellers and grease the propeller shafts using light waterproof grease.
- Remove the batteries and store in a cool place. Clean using clear, clean water. Be sure the batteries have sufficient water and clean terminals. Keep the batteries charged and safe from freezing throughout the storage period.

Note: Refer to the Electrical System chapter for information on the maintenance of the AC and DC electrical systems.

- Coat all faucets and exposed electrical components in the cabin and cockpit with a protecting oil.
- Clean out, totally drain and completely dry the sinks, refrigerators and ice maker.
- Thoroughly clean the interior of the boat. Vacuum all carpets and dry clean drapes and upholstery.
- Remove cushions, open the ice maker and refrigerator doors and as many locker doors as possible. Leaving as many of these areas open as possible will improve the boat's ventilation during the storage period.

Note: It is recommended that a mildew preventer be hung in the boat's cabin before it is closed for storage.

- Clean the exterior upholstery with a good vinyl cleaner and dry thoroughly. Spray the weather covers and boat upholstery with a spray disinfectant. Enclosed areas such as the refrigerator, ice maker, shower basin, storage locker areas, etc. also should be sprayed with this disinfectant.

14.2 Winterizing Fresh Water System

The entire fresh water system must be completely drained. Disconnect all hoses, check valves, etc. and blow all the water from the system. Make sure the water heater and fresh water tank are completely drained. Use only very low air pressure when doing this to prevent possible system damage. Because of the check valve mechanism built in the pump, blowing the lines will not remove the water from the fresh water pump. Remove the inlet and outlet hoses on the pump. Turn the pump on and allow it to pump out any remaining water (about a cupful). A recommended alternative to the above-mentioned procedure is the use of commercially available non toxic, fresh water system antifreeze. After draining the potable water tank, lines and water heater, pour the antifreeze mixture into the fresh water tank, prime and operate the pump until the mixture flows from all fresh water faucets. Be sure to open all hot and cold water faucets, including the fresh water shower in the cockpit and the faucet in the wet bar. Make sure antifreeze has flowed through all of the fresh water drains and the ice maker supply line.

The shower drain water sump system must be properly winterized. Clean debris from the drain and sump and flush for several minutes with fresh clean water. After the system is clean, pump the drain sumps as dry as possible. Then pour a potable water antifreeze mixture into the shower drains until antifreeze has been pumped through the entire system and out of the thru-hull. Follow the same procedure for the optional grey water sump system. Pour the antifreeze for the grey water sump into the cabin sink drains until antifreeze has been pumped through the entire system and out of the thru-hull.

For additional information refer to the Fresh Water System chapter. Also, refer to the ice maker owner's manual for information on winterizing the ice maker.

Engine and Generator Raw Water Systems

Drain all of the sea strainers, heat exchangers and raw water supply and discharge lines for the engine and generator raw water supply pumps. Make sure all seawater has drained from the exhaust system. Some, but not all, engine mufflers could have a drain plug that must be removed to properly drain the muffler. Once this is accomplished, pour a non toxic marine engine antifreeze mixture into a large pail and put the engine raw

water intake lines into the solution. Run each engine one at a time until the antifreeze solution is visible at the drive unit exhaust port, then shut the engine off.

Note: Properly winterize the engines and fuel system by following the engine manufacturer's winterizing procedures located in your engine owner's manuals or contact a Monterey dealer.

Refer to the Raw Water System chapter for additional information on the raw water system.

Marine Toilets

The marine toilets must be properly winterized by following the manufacturer's winterizing instructions in the marine toilet owner's manual. The fresh water supply will be winterized with the fresh water system. Drain the discharge hoses completely by turning off the fresh water supply so the bowl stays dry and flushing the toilet several times. The head holding tank and macerator discharge pump must be pumped dry and three gallons of potable water antifreeze poured into the tank through the deck waste pump out fitting. After the antifreeze has been added to the holding tank, open the overboard discharge valve and activate the macerator pump until the antifreeze solution is visible at the discharge thru-hull.

Note: Make sure you follow the marine toilet manufacturer's winterizing instructions exactly.

Air Conditioners

Disconnect and drain the seawater pump intake and discharge hoses. Remove all water from the sea strainer and thru-hull fitting. Allow all water to drain from the system. Once this is accomplished, pour a non toxic marine engine antifreeze mixture into a pail and put the air conditioning sea water intake line into the solution. Run both the air conditioning units until the antifreeze solution is visible at the air conditioning sea water discharge thru-hull fitting on the hull side, then shut the air conditioning units off. This will ensure that there is no trapped seawater in the system that could freeze and cause damage to the system.

The air conditioner components must be properly winterized by following winterizing procedure in the manufacturer's owner's manual.

The drain sump system must be properly winterized. Clean debris from the drain and sump and flush for several minutes with fresh clean water. After the system is clean, pump the drain sump as dry as possible. Then pour a potable water antifreeze mixture into each air conditioning drain pan until antifreeze has been pumped through the entire system and out of the thru-hull. The air conditioning system and cabin fresh water showers share the same sump system.

Note: The air conditioning, engine control system, head, and steering systems have specific lay up requirements. Please refer to their owner's manuals for recommended winterizing procedures.

Bilge

Coat all metal components, wire busses, and connector plugs in the bilge with a protecting oil. It is also important to protect all strainers, sea cocks and steering components. The bilge pumps and bilge pump lines must be completely free of water and dried out when the boat is laid up for the winter in climates where freezing occurs. Compartments in the bilge that will not drain completely should be pumped out and then sponged until completely free of water. Dry the hull bilge and self-bailing cockpit troughs. Water freezing in these areas could cause damage.

Special Notes Prior To Winter Storage

If the boat will be in outside storage, properly support a storage cover and secure it over the boat. It is best to have a frame built over the boat to support the canvas. It should be a few inches wider than the boat so the canvas will clear the rails and allow passage of air. If this cover is fastened too tightly there will be inadequate ventilation and this can lead to mildew, moisture accumulation, etc. It is essential to fasten the canvas down securely so that the wind cannot remove it or cause chafing of the hull superstructure. Do not store the boat in a damp storage enclosure. Excessive dampness can cause electrical problems, corrosion, and excessive mildew.

Whenever possible, do not use the enclosure curtains in place of the winter storage cover. The life of these curtains may be significantly shortened if exposed to harsh weather elements for long periods.



PLACING AN ELECTRIC OR FUEL BURNING HEATING UNIT IN THE BILGE AREA CAN BE POTENTIALLY HAZARDOUS AND IS NOT RECOMMENDED.

Proper storage is very important to prevent serious damage to the boat. If the boat is to be stored indoors, make sure the building has enough ventilation. It is very important that there is enough ventilation both inside the boat and around the boat.

Note: If the boat is to be stored indoors or outdoors, open all drawers, clothes lockers, cabinets, and doors a little. If possible, remove the upholstery, mattresses, clothing, and rugs. Then hang a commercially available mildew protector in the cabin.

14.3 Recommissioning



DO NOT OPERATE THE BOAT UNLESS IT IS COMPLETELY ASSEMBLED. KEEP ALL FASTENERS TIGHT. KEEP ADJUSTMENTS ACCORDING TO SPECIFICATIONS.

Note: It is important and recommended that the fitting out procedure for the marine gear be done by a qualified marine technician. Read the engine owner's manual for the recommended procedure.



MAKE SURE THE MUFFLER ON THE GENERATOR HAS NOT BEEN DAMAGED DURING WINTER STORAGE AND THAT THE DRAIN PLUGS ARE INSTALLED AND PROPERLY TIGHTENED. LOOSE OR MISSING DRAIN PLUGS AND DAMAGED OR LEAKING MUFFLERS OR EXHAUST HOSES WILL ALLOW CARBON MONOXIDE, ENGINE GASES, AND WATER INTO THE BILGE CREATING A POTENTIALLY HAZARDOUS CONDITION.

Note: Not all mufflers are equipped with drain plugs.

Reactivating The Boat After Storage:

- Apply a fresh coat of bottom paint on the hull and drives.
- Inspect both drives and thru-hull fittings.
- Install the propellers. Refer to the IPS owner's manual for information on installing propellers.
- Install the drain plug in the hull.
- Charge and install the batteries.
- Check the engines for damage and follow the manufacturer's instructions for recommissioning.
- Check the engine mounting bolts to make sure they are tight.
- Perform all routine maintenance.
- Check all hose clamps for tightness.
- Pump the antifreeze from the fresh and raw water systems and flush several times with fresh water. Make sure all antifreeze is flushed from the water heater and it is filled with fresh water before it is activated.
- Check and lubricate the steering system.
- Clean and wash the boat.
- Install all upholstery, cushions and canvas.
- Check the fluid levels in the engines, generator and drives.

After Launching:

- Carefully check the engines and all water systems for leaks. Operate each system one at a time checking for leaks and proper operation.
- Check the bilge pump automatic and manual switches.
- Prime the fuel system and start the engines.

- Carefully monitor the gauges and check for leakage and abnormal noises. Monitor the temperature gauges closely until they stabilize at normal operating temperature to ensure that the cooling pumps are operating properly.
- Operate the boat at slow speeds until the engine temperature stabilizes and all systems are operating normally.

GENERAL MAINTENANCE SCHEDULE
AND LOG

MAINTENANCE	Each Use	Weekly	Monthly	Each Season	Yearly	As Needed
Clean hull below the waterline				X		
Bottom paint hull					X	X
Check sacrificial anodes			X			
Wash boat, canvas and hardware	X		X			
Wax exterior gelcoat				X		X
Polish & protect clear curtains				X	X	
Clean and protect hardware						X
Polish and protect acrylic plastic glass				X		
Clean cabin & interior upholstery						X
Clean exterior upholstery		X				X
Service and inspect cabin accessories				X		
Spray metal bilge pumps and components with a protector			X			
Clean bilge				X		X
Check bilge and engine components for leaks	X		X			
Check & clean raw water strainers	X					X
Engine alignment					X	
Inspect steering and control systems	X					
Service steering and control systems				X		
Inspect fuel system for leaks	X					
Inspect & service fuel system				X		X
Inspect and protect electrical components, wire & battery connectors				X		
Check battery electrolyte & service			X			
Test and inspect AC electrical system & shore power cord				X		
Inspect water systems for leaks				X		
Check blower operation & safety equipment	X					
Check neutral safety switches	X					

[illegible]



MONTEREY

[illegible]

FLOAT PLAN

Monterey Boats recommends filling out a float plan each time you use your boat for an offshore day trip or a long cruise. Leave this information with a responsible person ashore, like a close friend or relative that you know well.

1. Name of person reporting and telephone number.

2. Description of boat.

Type _____ Color _____ Trim _____

Registration No. _____ Length _____

Name _____ Make _____ Other Info _____

3. Engine type _____ H.P. _____

No. of Engines _____ Fuel Capacity _____

4. Survival equipment: (Check as appropriate)

<input type="checkbox"/> PFDS	<input type="checkbox"/> Flares	<input type="checkbox"/> Mirror
<input type="checkbox"/> Smoke Signals	<input type="checkbox"/> Flashlight	<input type="checkbox"/> Food
<input type="checkbox"/> Paddles	<input type="checkbox"/> Water	<input type="checkbox"/> Others
<input type="checkbox"/> Anchor	<input type="checkbox"/> Raft or Dinghy	<input type="checkbox"/> EPIRB

5. Radio ☐ Yes ☐ No Type _____

6. Automobile license _____

Type _____ Trailer License _____

Color _____ and make of auto _____

7. Persons aboard _____

Name _____ Age _____ Address & telephone No. _____

8. Do any of the persons aboard have a medical problem?

☐ Yes ☐ No If yes, what? _____

9. Trip Expectations: Leave at _____

From _____ Going to _____

Expect to return by _____ (time)

and no later than _____

10. Any other pertinent info. _____

11. If not returned by _____ (time)
call the COAST GUARD, or (Local authority) _____

12. Telephone Numbers.

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

DEPARTMENT OF TRANSPORTATION U.S. COAST GUARD CG-3865 (Rev. 9/95)		BOATING ACCIDENT REPORT		FORM APPROVED OMB NO. 2115-0010	
		STATE ASSIGNED CASE NO. _____			
THE OPERATOR/OWNER OF A VESSEL USED FOR RECREATIONAL PURPOSES IS REQUIRED TO FILE A REPORT IN WRITING WHENEVER AN ACCIDENT RESULTS IN: LOSS OF LIFE OR DISAPPEARANCE FROM A VESSEL; AN INJURY WHICH REQUIRES MEDICAL TREATMENT BEYOND FIRST AID; OR PROPERTY DAMAGE IN EXCESS OF \$2000 OR COMPLETE LOSS OF THE VESSEL. REPORTS IN DEATH AND INJURY CASES MUST BE SUBMITTED WITHIN 48 HOURS. REPORTS IN OTHER CASES MUST BE SUBMITTED WITHIN 10 DAYS. REPORTS MUST BE SUBMITTED TO THE REPORTING AUTHORITY IN THE STATE WHERE THE ACCIDENT OCCURRED. THIS FORM IS PROVIDED TO ASSIST THE OPERATOR IN FILING THE REQUIRED WRITTEN REPORT.					
COMPLETE ALL BLOCKS (INDICATE THOSE NOT APPLICABLE BY "NA")					
ACCIDENT DATA					
DATE OF ACCIDENT		TIME AM PM	NAME OF BODY OF WATER		LOCATION (GIVE LOCATION PRECISELY)
NUMBER OF VESSELS INVOLVED	NEAREST CITY OR TOWN		COUNTY	STATE	ZIP CODE
WEATHER (CHECK ALL APPLICABLE) <input type="checkbox"/> CLEAR <input type="checkbox"/> RAIN <input type="checkbox"/> CLOUDY <input type="checkbox"/> SNOW <input type="checkbox"/> FOG <input type="checkbox"/> HAZY	WATER CONDITIONS <input type="checkbox"/> CALM (WAVES LESS THAN 6") <input type="checkbox"/> CHOPPY (WAVES 6" TO 2') <input type="checkbox"/> ROUGH (WAVES 2' TO 6') <input type="checkbox"/> VERY ROUGH (GREATER THAN 6') <input type="checkbox"/> STRONG CURRENT		TEMPERATURE (ESTIMATE) AIR _____ °F WATER _____ °F	WIND <input type="checkbox"/> NONE <input type="checkbox"/> LIGHT (0-6 MPH) <input type="checkbox"/> MODERATE (7-14 MPH) <input type="checkbox"/> STRONG (15-25 MPH) <input type="checkbox"/> STORM (OVER 25 MPH)	VISIBILITY DAY NIGHT <input type="checkbox"/> GOOD <input type="checkbox"/> <input type="checkbox"/> FAIR <input type="checkbox"/> <input type="checkbox"/> POOR <input type="checkbox"/>
NAME OF OPERATOR			OPERATOR ADDRESS		
OPERATOR TELEPHONE NUMBER ()	DATE OF BIRTH MO DAY YR	OPERATOR'S EXPERIENCE <input type="checkbox"/> NONE <input type="checkbox"/> UNDER 100 HOURS <input type="checkbox"/> > 100 HOURS		INSTRUCTION IN BOATING SAFETY <input type="checkbox"/> STATE COURSE <input type="checkbox"/> U.S. POWER SQUADRON <input type="checkbox"/> USCG AUXILIARY <input type="checkbox"/> AMERICAN RED CROSS <input type="checkbox"/> NONE	
<input type="checkbox"/> MALE <input type="checkbox"/> FEMALE					
NAME OF OWNER			OWNER ADDRESS		
OWNER TELEPHONE NUMBER ()	NUMBER OF PEOPLE ON BOARD	NUMBER OF PEOPLE BEING TOWED		RENTED BOAT? <input type="checkbox"/> YES <input type="checkbox"/> NO	
BOAT NO. 1 (THIS VESSEL)					
BOAT REGISTRATION OR DOCUMENTATION NUMBER		STATE	HULL IDENTIFICATION NUMBER		BOAT NAME
BOAT MANUFACTURER		LENGTH	MODEL		YEAR BUILT
TYPE OF BOAT <input type="checkbox"/> OPEN MOTORBOAT <input type="checkbox"/> CABIN MOTORBOAT <input type="checkbox"/> AUXILIARY SAIL <input type="checkbox"/> SAIL (ONLY) <input type="checkbox"/> ROWBOAT <input type="checkbox"/> CANOE/KAYAK <input type="checkbox"/> PERSONAL WATERCRAFT <input type="checkbox"/> PONTOON BOAT <input type="checkbox"/> HOUSEBOAT <input type="checkbox"/> OTHER (SPECIFY)	HULL MATERIAL <input type="checkbox"/> WOOD <input type="checkbox"/> ALUMINUM <input type="checkbox"/> STEEL <input type="checkbox"/> FIBERGLASS <input type="checkbox"/> RUBBER/VINYL/CANVAS <input type="checkbox"/> RIGID HULL INFLATABLE <input type="checkbox"/> OTHER (SPECIFY)	ENGINE <input type="checkbox"/> OUTBOARD <input type="checkbox"/> INBOARD <input type="checkbox"/> INBOARD-STERNDRIVE (I/O) <input type="checkbox"/> AIRBOAT	PROPULSION <input type="checkbox"/> PROPELLER <input type="checkbox"/> WATER JET <input type="checkbox"/> AIR THRUST <input type="checkbox"/> MANUAL <input type="checkbox"/> SAIL	PERSONAL FLOTATION DEVICES (PFDS): WAS BOAT ADEQUATELY EQUIPPED WITH COAST GUARD APPROVED PFDS? <input type="checkbox"/> YES <input type="checkbox"/> NO WERE PFDS ACCESSIBLE? <input type="checkbox"/> YES <input type="checkbox"/> NO	
		FUEL <input type="checkbox"/> GASOLINE <input type="checkbox"/> DIESEL <input type="checkbox"/> ELECTRIC	NUMBER OF ENGINES	FIRE EXTINGUISHERS ON BOARD? <input type="checkbox"/> YES <input type="checkbox"/> NO USED? <input type="checkbox"/> YES <input type="checkbox"/> NO	
		TOTAL HORSEPOWER		WHAT CONTRIBUTED TO ACCIDENT? (CHECK ALL APPLICABLE)	
OPERATION AT TIME OF ACCIDENT (CHECK ALL APPLICABLE) <input type="checkbox"/> CRUISING <input type="checkbox"/> CHANGING DIRECTION <input type="checkbox"/> CHANGING SPEED <input type="checkbox"/> DRIFTING <input type="checkbox"/> TOWING <input type="checkbox"/> BEING TOWED <input type="checkbox"/> ROWING/PADDLING <input type="checkbox"/> SAILING <input type="checkbox"/> LAUNCHING <input type="checkbox"/> DOCKING/UNDocking <input type="checkbox"/> AT ANCHOR <input type="checkbox"/> TIED TO DOCK/MOORED <input type="checkbox"/> OTHER (SPECIFY)	ACTIVITY AT TIME OF ACCIDENT (CHECK ANY IF APPLICABLE) <input type="checkbox"/> FISHING <input type="checkbox"/> TOURNAMENT <input type="checkbox"/> HUNTING <input type="checkbox"/> SWIMMING/DIVING <input type="checkbox"/> MAKING REPAIRS <input type="checkbox"/> WATERSKIING/TUBING/ETC. <input type="checkbox"/> RACING <input type="checkbox"/> WHITEWATER SPORTS <input type="checkbox"/> FUELING <input type="checkbox"/> STARTING ENGINE <input type="checkbox"/> NON-RECREATIONAL <input type="checkbox"/> OTHER (SPECIFY)	TYPE OF ACCIDENT <input type="checkbox"/> GROUNDING <input type="checkbox"/> CAPSIZING <input type="checkbox"/> FLOODING/SWAMPING <input type="checkbox"/> SINKING <input type="checkbox"/> FIRE OR EXPLOSION (FUEL) <input type="checkbox"/> FIRE OR EXPLOSION (OTHER) <input type="checkbox"/> SKIER MISHAP <input type="checkbox"/> COLLISION WITH VESSEL <input type="checkbox"/> COLLISION WITH FIXED OBJECT <input type="checkbox"/> COLLISION WITH FLOATING OBJ. <input type="checkbox"/> FALLS OVERBOARD <input type="checkbox"/> FALLS IN BOAT <input type="checkbox"/> STRUCK BY BOAT <input type="checkbox"/> STRUCK BY MOTOR/PROPELLER <input type="checkbox"/> STRUCK SUBMERGED OBJECT <input type="checkbox"/> OTHER (SPECIFY)		<input type="checkbox"/> WEATHER <input type="checkbox"/> EXCESSIVE SPEED <input type="checkbox"/> IMPROPER LOOKOUT <input type="checkbox"/> RESTRICTED VISION <input type="checkbox"/> OVERLOADING <input type="checkbox"/> IMPROPER LOADING <input type="checkbox"/> HAZARDOUS WATERS <input type="checkbox"/> ALCOHOL USE <input type="checkbox"/> DRUG USE <input type="checkbox"/> HULL FAILURE <input type="checkbox"/> MACHINERY FAILURE <input type="checkbox"/> EQUIPMENT FAILURE <input type="checkbox"/> OPERATOR INEXPERIENCE <input type="checkbox"/> OPERATOR INATTENTION <input type="checkbox"/> CONGESTED WATERS <input type="checkbox"/> PASSENGER/SKIER BEHAVIOR <input type="checkbox"/> DAM/LOCK <input type="checkbox"/> OTHER (SPECIFY)	
ESTIMATED SPEED <input type="checkbox"/> NONE <input type="checkbox"/> UNDER 10 MPH <input type="checkbox"/> 10 - 20 MPH <input type="checkbox"/> 21 - 40 MPH <input type="checkbox"/> OVER 40 MPH					
		<input type="checkbox"/> HIT AND RUN			

DECEASED (IF MORE THAN 2 FATALITIES, ATTACH ADDITIONAL FORMS)			
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH		WAS PFD WORN? <input type="checkbox"/> YES <input type="checkbox"/> NO	
<input type="checkbox"/> MALE <input type="checkbox"/> FEMALE	DEATH CAUSED BY <input type="checkbox"/> DROWNING <input type="checkbox"/> OTHER <input type="checkbox"/> DISAPPEARANCE		
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH		WAS PFD WORN? <input type="checkbox"/> YES <input type="checkbox"/> NO	
<input type="checkbox"/> MALE <input type="checkbox"/> FEMALE	DEATH CAUSED BY <input type="checkbox"/> DROWNING <input type="checkbox"/> OTHER <input type="checkbox"/> DISAPPEARANCE		
INJURED (IF MORE THAN 2 INJURIES, ATTACH ADDITIONAL FORMS)			
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH	MEDICAL TREATMENT BEYOND FIRST AID? <input type="checkbox"/> YES <input type="checkbox"/> NO	DESCRIBE INJURY	
	ADMITTED TO HOSPITAL? <input type="checkbox"/> YES <input type="checkbox"/> NO		
WAS PFD WORN? <input type="checkbox"/> YES <input type="checkbox"/> NO	PRIOR TO ACCIDENT? <input type="checkbox"/> YES <input type="checkbox"/> NO	AS A RESULT OF ACCIDENT? <input type="checkbox"/> YES <input type="checkbox"/> NO	
WAS IT INFLATABLE? <input type="checkbox"/> YES <input type="checkbox"/> NO			
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH	MEDICAL TREATMENT BEYOND FIRST AID? <input type="checkbox"/> YES <input type="checkbox"/> NO	DESCRIBE INJURY	
	ADMITTED TO HOSPITAL? <input type="checkbox"/> YES <input type="checkbox"/> NO		
WAS PFD WORN? <input type="checkbox"/> YES <input type="checkbox"/> NO	PRIOR TO ACCIDENT? <input type="checkbox"/> YES <input type="checkbox"/> NO	AS A RESULT OF ACCIDENT? <input type="checkbox"/> YES <input type="checkbox"/> NO	
WAS IT INFLATABLE? <input type="checkbox"/> YES <input type="checkbox"/> NO			
OTHER PEOPLE ABOARD THIS BOAT (IF MORE THAN 2 PEOPLE, ATTACH ADDITIONAL FORMS)			
NAME		ADDRESS	
DATE OF BIRTH	WAS PFD WORN? <input type="checkbox"/> YES <input type="checkbox"/> NO	PRIOR TO ACCIDENT? <input type="checkbox"/> YES <input type="checkbox"/> NO	
	AS A RESULT OF ACCIDENT <input type="checkbox"/> YES <input type="checkbox"/> NO	WAS IT INFLATABLE? <input type="checkbox"/> YES <input type="checkbox"/> NO	
NAME		ADDRESS	
DATE OF BIRTH	WAS PFD WORN? <input type="checkbox"/> YES <input type="checkbox"/> NO	PRIOR TO ACCIDENT? <input type="checkbox"/> YES <input type="checkbox"/> NO	
	AS A RESULT OF ACCIDENT <input type="checkbox"/> YES <input type="checkbox"/> NO	WAS IT INFLATABLE? <input type="checkbox"/> YES <input type="checkbox"/> NO	
BOAT NO. 2 (IF MORE THAN 2 VESSELS, ATTACH ADDITIONAL IDENTIFYING INFORMATION)			
NAME OF OPERATOR		OPERATOR ADDRESS	
OPERATOR TELEPHONE NUMBER ()		BOAT REGISTRATION OR DOCUMENTATION NUMBER STATE	
NAME OF OWNER		OWNER ADDRESS	
OWNER TELEPHONE NUMBER ()			
PROPERTY DAMAGE			
ESTIMATED AMOUNT: THIS BOAT AND CONTENTS: \$		OTHER BOAT(S) AND CONTENTS: \$	
		OTHER PROPERTY: \$	
DESCRIBE PROPERTY DAMAGED			
WITNESSES NOT ON THIS VESSEL			
NAME	ADDRESS	TELEPHONE NUMBER ()	
NAME	ADDRESS	TELEPHONE NUMBER ()	
PERSON COMPLETING REPORT			
NAME	ADDRESS	TELEPHONE NUMBER ()	
SIGNATURE	QUALIFICATION <input type="checkbox"/> OPERATOR <input type="checkbox"/> OWNER <input type="checkbox"/> INVESTIGATOR <input type="checkbox"/> OTHER	DATE SUBMITTED	
FOR AGENCY USE ONLY			
CAUSES BASED ON (CHECK ONE): <input type="checkbox"/> THIS REPORT <input type="checkbox"/> INVESTIGATION <input type="checkbox"/> INVESTIGATION AND THIS REPORT <input type="checkbox"/> OTHER			
NAME OF REVIEWING OFFICE	DATE RECEIVED	RECREATIONAL <input type="checkbox"/> NON-REPORTABLE <input type="checkbox"/>	
		COMMERCIAL <input type="checkbox"/>	
PRIMARY CAUSE		SECONDARY CAUSE	

ACCIDENT DESCRIPTION

DESCRIBE WHAT HAPPENED (SEQUENCE OF EVENTS. INCLUDE FAILURE OF EQUIPMENT. INCLUDE A DIAGRAM IF NEEDED. CONTINUE ON ADDITIONAL SHEETS IF NECESSARY. INCLUDE ANY INFORMATION REGARDING THE INVOLVEMENT OF ALCOHOL AN/OR DRUGS IN CAUSING OR CONTRIBUTING TO THE ACCIDENT. INCLUDE ANY DESCRIPTIVE INFORMATION ABOUT THE USE OF PFD'S.)

An agency may not conduct or sponsor and a person is not required to respond to an information collection, unless it displays a currently valid OMB Control Number. The Coast Guard estimates that the average burden for this report form is 30 minutes. You may submit any comments concerning the accuracy of this burden estimate or any suggestions for reducing the burden to: Commandant (G-OPB-1), U.S. Coast Guard, Washington, DC 20593-0001 or Office of Management and Budget, Paperwork Reduction Project (2115-0010), Washington, DC 20503.

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

GLOSSARY OF TERMS

Aft: In, near, or toward the stern of a boat.

Aground: A boat stuck on the bottom.

Amidships: In or toward the part of a boat midway between the bow and stern.

Anchor: A specially shaped heavy metal device designed to dig efficiently into the bottom under a body of water and hold a boat in place.

Anchorage: An area specifically designated by governmental authorities in which boats may anchor.

Ashore: On shore.

Astern: Behind the boat, to move backwards.

Athwartship: At right angles to the center line of the boat.

Barnacles: Small, hard-shelled marine animals which are found in salt water attached to pilings, docks and bottoms of boats.

Beam: The breadth of a boat usually measured at its widest part.

Bearing: The direction of an object from the boat, either relative to the boat's direction or to compass degrees.

Berth: A bunk or a bed on a boat.

Bilge: The bottom of the boat below the flooring.

Bilge Pump: A pump that removes water that collects in the bilge.

Boarding: Entering or climbing into a boat.

Boarding Ladder: Set of steps temporarily fitted over the side of a boat to assist persons coming aboard.

Boat Hook: Short shaft of wood or metal with a hook fitting at one end shaped to aid in extending one's reach from the side of the boat.

Bow: The front end of a boat's hull.

Bow Line: A line that leads forward from the bow of the boat.

Bow Rail: Knee high rails of solid tubing to aid in preventing people from falling overboard.

Bridge: The area from which a boat is steered and controlled.

Bridge Deck: A deck forward and usually above the cockpit deck.

Broach: When the boat is sideways to the seas and in danger of capsizing; a very dangerous situation that should be avoided.

Bulkhead: Vertical partition or wall separating compartments of a boat.

Cabin: Enclosed superstructure above the main deck level.

Capsize: When a boat lays on its side or turns over.

Chock: A deck fitting, usually of metal, with inward curving arms through which mooring or anchor lines are passed so as to lead them in the proper direction both on board and off the boat.

Cleat: A deck fitting, usually of metal with projecting arms used for securing anchor and mooring lines.

Closed Cooling System: A separate supply of fresh water that is used to cool the engine and circulates only within the engine.

Coaming: A vertical piece around the edges of cockpit, hatches, etc. to stop water on deck from running below.

Cockpit: An open space, usually in the aft deck, outside of the cabin.

Companionway: Opening in the deck of a boat to provide access below.

Compartment: The interior of a boat divided off by bulkheads.

Cradle: A framework designed to support a boat as she is hauled out or stored.

Cutlass Bearing: A rubber bearing in the strut that supports the propeller shaft.

Deck: The floor-like platform of a boat that covers the hull.

Displacement: The volume of water displaced by the hull. The displacement weight is the weight of this volume of water.

Draft: The depth of water a boat needs to float.

Dry Rot: A fungus attack on wood areas.

Dry-dock: A dock that can be pumped dry during boat construction or repair.

Electrical Ground: A connection between an electrical connector and the earth.

Engine Beds: Sturdy structural members running fore and aft on which the inboard engines are mounted.

EPIRB: Emergency Position Indicating Radio Beacon. Operates as a part of a worldwide satellite distress system.

Even Keel: When a boat floats properly as designed.

Fathom: A measure of depth. One Fathom = 6 feet.

Fender: A soft object of rubber or plastic used to protect the topsides from scarring and rubbing against a dock or another vessel.

Fend off: To push or hold the boat off from the dock or another boat.

Flying Bridge: A control station above the level of the deck or cabin.

Flukes: The broad portions of an anchor which dig into the ground.

Fore: Applies to the forward portions of a boat near the bow.

Foundering: When a boat fills with water and sinks.

Freeboard: The height from the waterline to the lowest part of the deck.

Galley: The kitchen of a boat.

Grab Rail: Hand hold fittings mounted on cabin tops or sides for personal safety when moving around the boat, both on deck and below.

Ground Tackle: A general term including anchors, lines, and other gear used in anchoring.

Grounds: A boat touches the bottom.

Gunwale: The upper edge of a boat's side.

Hand Rail: Rail mounted on the boat, for grabbing with your hand, to steady you while walking about the boat.

Harbor: An anchorage which provides reasonably good protection for a boat, with shelter from wind and sea.

Hatch: An opening in the deck with a door or lid to allow for access down into a compartment of a boat.

Head: A toilet on a boat.

Heat Exchanger: Used to transfer the heat that is picked up by the closed cooling system to the raw cooling water.

Helm: The steering and control area of a boat.

Hull: The part of the boat from the deck down.

Inboard: A boat with the engine mounted within the hull of the boat. Also refers to the center of the boat away from the sides.

Inboard/outboard: Also stern drive or I/O. A boat with an inboard engine attached to an outboard drive unit.

Keel: A plate or timber plate running lengthwise along the center of the bottom of a boat.

Knot: Unit of speed indicating nautical miles per hour. 1 knot = 1 nautical mile per hour (1.15 miles per hour). A nautical mile is equal to one minute of latitude: 6076 feet. Knots times 1.15 equals miles per hour. Miles per hour times .87 equals knots.

Lay-up: To decommission a boat for the winter (usually in northern climates).

Leeward: The direction toward which the wind is blowing.

Length On The Waterline (l.w.l.): A length measurement of a boat at the waterline from the stern to where the hull breaks the water near the bow.

Limber Hole: A passage cut into the lower edges of floors and frames next to the keel to allow bilge water to flow to the lowest point of the hull where it can be pumped overboard.

Line: The term used to describe a rope when it is on a boat.

Lists: A boat that inclines to port or starboard while afloat.

L.O.A.: Boat length overall.

Locker: A closet, chest or box aboard a boat.

Loran: An electronic navigational instrument which monitors the boat's position using signals emitted from pairs of transmitting stations.

Lunch hook: A small light weight anchor typically used instead of the working anchor. Normally used in calm waters with the boat attended.

Midships: The center of the boat.

Marina: A protected facility primarily for recreational small craft.

Marine Ways or Railways: Inclined planes at the water's edge onto which boats are hauled.

Moored: A boat secured with cables, lines or anchors.

Mooring: An anchor permanently embedded in the bottom of a harbor that is used to secure a boat.

Nautical Mile: A unit of measure equal to one minute of latitude. (6076 feet)

Nun Buoy: A red or red-striped buoy of conical shape.

Outboard: A boat designed for an engine to be mounted on the transom. Also a term that refers to objects away from the center line or beyond the hull sides of a boat.

Pad Eye: A deck fitting consisting of a metal eye permanently secured to the boat.

Pier: A structure which projects out from the shoreline.

Pile or Piling: A long column driven into the bottom to which a boat can be tied.

Pitching: The fore and aft rocking motion of a boat as the bow rises and falls.

Pitch: The measure of the angle of a propeller blade. Refers to the theoretical distance the boat travels with each revolution of the propeller.

P.F.D: Personal Flotation Device.

Port: The left side of the boat when facing the bow.

Porthole (port): The opening in the side of a boat to allow the admittance of light and air.

Propeller: A device having two or more blades that is attached to the engine and used for propelling a boat.

Propeller Shaft: Shaft which runs from the back of the engine gear box, aft, through the stuffing box, shaft log, struts, and onto which the propeller is attached.

Pyrotechnic Distress Signals: Distress signals that resemble the brilliant display of flares or fireworks.

Raw Water Cooled: Refers to an engine cooling system that draws seawater in through a hull fitting or engine drive unit, circulates the water in the engine, and then discharges it overboard.

Reduction Gear: Often combined with the reverse gear so that the propeller turns at a slower rate than the engine.

Reverse Gear: Changes the direction of rotation of the propeller to provide thrust in the opposite direction for stopping the boat or giving it stern-way.

Roll: A boat's sideways rotational motion in rough water.

Rope Locker: A locker, usually located in the bow of a boat, used for stowing the anchor line or chain.

Rubrail: Railing (often rubber or hard plastic) that runs along the boat's sheer to protect the hull when coming alongside docks, piers, or other boats.

Rudder: A moveable flat surface that is attached vertically at or near the stern for steering.

Sea anchor: An anchor that does not touch the bottom. Provides drag to hold the bow in the most favorable position in heavy seas.

Scupper: An opening in the hull side or transom of the boat through which water on deck or in the cockpit is drained overboard.

Sea cock: Safety valves installed just inside the thru-hull fittings and ahead of the piping or hose running from the fittings.

Shaft Log: Pipe through which the propeller shaft passes.

Sheer: The uppermost edge of the hull.

Sling: A strap which will hold the boat securely while being lifted, lowered, or carried.

Slip: A boat's berth between two pilings or piers.

Sole: The deck of a cockpit or interior cabin.

Spring Line: A line that leads from the bow aft or from the stern forward to prevent the boat from moving ahead or astern.

Starboard: The right side of a boat when facing the bow.

Steerageway: Sufficient speed to keep the boat responding to the rudder or drive unit.

Stem: The vertical portion of the hull at the bow.

Stern: The rear end of a boat.

Stow: To pack away neatly.

Stringer: Longitudinal members fastened inside the hull for additional structural strength.

Strut: Mounted to the hull which supports the propeller shaft in place.

Strut Bearing: See "cutlass bearing."

Stuffing Box: Prevents water from entering at the point where the propeller shaft passes through the shaft log.

Superstructure: Something built above the main deck level.

Swamps: When a boat fills with water from over the side.

Swimming Ladder: Much the same as the boarding ladder except that it extends down into the water.

Taffrail: Rail around the rear of the cockpit.

Thru-hull: A fitting used to pass fluids (usually water) through the hull surface, either above or below the waterline.

Topsides: The side skin of a boat between the waterline or chine and deck.

Transom: A flat stern at right angles to the keel.

Travel Lift: A machine used at boat yards to hoist boats out of and back into the water.

Trim: Refers to the boat's angle or the way it is balanced.

Trough: The area of water between the crests of waves and parallel to them.

Twin-Screw Craft: A boat with two propellers on two separate shafts.

Underway: When a boat moves through the water.

Wake: Disrupted water that a boat leaves astern as a result of its motion.

Wash: The flow of water that results from the action of the propeller or propellers.

Waterline: The plane of a boat where the surface of the water touches the hull when it is afloat on even keel.

Watertight Bulkhead: Bulkheads secured so tightly so as not to let water pass.

Wharf: A structure generally parallel to the shore.

Working Anchor: An anchor carried on a boat for most normal uses. Refers to the anchor used in typical anchoring situations.

Windlass: A winch used to raise and lower the anchor.

Windward: Toward the direction from which the wind is coming.

Yacht Basin: A protected facility primarily for recreational small craft.

Yaw: When a boat runs off her course to either side.

THIS PAGE WAS LEFT BLANK
INTENTIONALLY

TROUBLESHOOTING GUIDE

PROBLEM	CAUSE AND SOLUTION
CONTROL SYSTEMS	
Steering is slow to respond and engine RPM has been reduced.	<ul style="list-style-type: none"> • There is a problem with the electronic steering system at the helm, EVC module or at the one of the drives. Have the system serviced by a qualified marine technician.
An engine will not start with the shift control lever in neutral.	<ul style="list-style-type: none"> • The shift control lever is not in the neutral detent. Try moving the shift lever slightly. • The starter, ignition switch or an electrical component in the starter circuit is defective. Have the system serviced by a qualified technician. • There is a problem with the electronic control system at the helm control, EVC module or at the engine. Have the system serviced by a qualified marine technician.
The engine does not respond properly to the throttle control.	<ul style="list-style-type: none"> • The throttle control in the helm control is corroded and binding. Lubricate the control. • There is a problem with the electronic control system at the helm, EVC module or at the engine. Have the system serviced by a qualified marine technician.
The drive does not respond properly to the shift control.	<ul style="list-style-type: none"> • The shift control in the helm control is corroded and binding. Lubricate the control. • There is a problem with the electronic control system at the helm, EVC module or at the drive. Have the system serviced by a qualified marine technician.
PERFORMANCE PROBLEMS	
Boat is sluggish and has lost speed & RPM.	<ul style="list-style-type: none"> • The drives or hull may be fowled with marine growth. Clean marine growth from the drives and/or hull. • A Propeller may be damaged & need repair. • Weeds or line around the propellers. Clean propellers. • Boat is overloaded. Reduce load. • Check for excessive water in the bilge. Pump out bilge, then find & correct the problem. • One of the throttle is not responding properly and the engine is not getting full throttle. Have the throttle control checked by a qualified marine technician. • One or both of the engines is not producing adequate power. Have engines checked by a qualified technician.
The boat vibrates at cruising speeds.	<ul style="list-style-type: none"> • Propeller may be damaged & need repair. • A propeller shaft is bent. Repair or replace damaged components. • A drive is fouled by marine growth or rope. Clean running gear. • The engines are not at the same RPM. Synchronize throttles.

PROBLEM	CAUSE AND SOLUTION
ENGINE PROBLEMS	

An engine is running too hot.

- The raw water supply line to the pump is kinked. Replace hose.
- The engine raw water pump impeller is worn or damaged. Repair the pump.
- The engine thermostat is faulty and needs to be replaced.
- The freshwater cooling heat exchanger is clogged and needs to be cleaned.
- The exhaust manifolds or riser water ports are clogged and need to be cleaned or the manifold or riser replaced.

An engine alternator is not charging properly.

- The engine alternator belt is loose or worn. Tighten or replace the belt.
- The alternator is not charging and must be replaced.
- The isolator relay in the charging system is not working properly. Replace the isolator.
- A battery is defective and not accepting a charge.

An engine suddenly will not operate at or above cruise RPM.

- The engine emergency system has been activated. The on board computer has sensed a problem and has limited the RPM to protect the engine. Find and correct the problem.
- The tachometer is bad and needs to be replaced.
- A throttle control is not responding properly. Have the throttle setting checked by a qualified technician.

An engine is loosing RPM. The boat is not overloaded and the hull bottom and running gear are clean and in good condition.

- The fuel filter could be dirty. Inspect and replace the fuel filter.
- The electronic engine control system on the engine is malfunctioning. Repair the engine control system.

Both engines suddenly shut down and won't restart.

- The automatic fire extinguisher in the engine compartment has activated and the engines were shut down by the extinguisher shut down control. Check the monitor panel for a red light or no green light. If the red light is lit or the green light is out, wait 15 minutes, if safe to do so, to ensure a possible fire is out. Then inspect the engine compartment. Correct any problems found and then ventilate the engine compartment, activate the override switch, then the engines.

The engine runs too cold.

- The thermostat is faulty. Replace thermostat.
- The temperature gauge is not reading properly. Replace the temperature gauge or sender.

The engine starter will not operate.

- The battery selector switch is off. Turn on switch.
- The shift control is not fully engaged in neutral. Move shifter from forward to neutral and try again.
- The fuse or circuit breaker for the starting circuit is blown. Reset the breaker or replace the fuse. Repair circuit if necessary
- The battery is weak or low. Charge or replace battery.
- Corroded or loose battery connections. Tighten, clean and protect connections.

PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	
<p>The air conditioner runs for a short time & then cuts out.</p>	<ul style="list-style-type: none"> • The air conditioner pump sea strainer is clogged. Clean the strainer. • The raw water supply thru-hull valve is closed. Open the valve. • The raw water system is air-bound. Make sure the thru hull valve is open and run the boat above 15 m.p.h. The speed scoop on the thru hull fitting will force the air lock out of the system. • The air conditioner raw water pump is not pumping and needs to be repaired or replaced.
<p>The carbon monoxide detector sounds the alarm when the engines are running.</p>	<ul style="list-style-type: none"> • The canvas curtains are up and none of the forward facing vents are open, allowing carbon monoxide to accumulate in the cockpit and cabin. Open the deck hatch, windshield vents and side curtains to provide proper ventilation. • The carbon monoxide detector is defective and needs to be calibrated by the manufacturer or replaced. Have the boat checked by a professional before condemning the CO monitor.
<p>The fresh water pump runs, but will not pump water.</p>	<ul style="list-style-type: none"> • The water tank is empty. Fill the tank. • The in-line strainer for the pump is clogged. Clean the strainer. • The intake hose is damaged and sucking air. Replace or repair the hose. • The pump is defective. Repair or replace the pump.
<p>The freshwater pump breaker is on, but the pump fails to run.</p>	<ul style="list-style-type: none"> • There is a loose or corroded wiring connection. Find and repair the bad connection • The fuse or circuit breaker supplying current to the pump is blown or defective. Reset or repair fuse or breaker. • The thermal breaker on the pump is tripped. Repair or replace pump. • The pressure switch on the pump has failed. Replace the pressure switch. • The pump is defective. Repair or replace the pump.
<p>The fresh water pump fails to turn off after all outlets are closed.</p>	<ul style="list-style-type: none"> • There is a leak in a pressure line or outlet. Repair the leak. • There is an air leak in the intake line. Repair the air leak. • The pressure switch is defective. Replace the pressure switch. • The voltage to the pump is low. Check for corroded or loose wiring connections or low battery. • The strainer is clogged. Clean strainer. • The pump is defective. Repair or replace the pump.

PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	

Reduction in water flow from the bilge pump.

- Impeller screen is plugged with debris. Clean screen at the base of the pump.
- The discharge hose is pinched or clogged. Check discharge hose and clean or repair.
- Discharge hose is sagging below the pump and creating an air lock. Reroute hose so it runs uphill from the pump to the thru-hull fitting.
- Low voltage to the pump. Check the battery and wire connections.

The automatic float switch on the bilge pump raises but does not activate the pump.

- The circuit breaker near the battery switches has blown. Reset the circuit breaker.
- The battery is dead. Charge or replace the battery.
- The pump impeller is jammed by debris. Clean pump impeller housing.
- The wire connections in the bilge have corroded. Replace connectors and secure above the bilge waterline.
- The automatic switch is defective. Replace the switch.
- The pump is defective. Replace pump.

The bilge pump will not run when the manual switch is activated.

- The circuit breaker supplying the switch has tripped. Replace or reset the circuit breaker.
- The battery switch is off. Turn on the battery switch and bilge pump breaker.
- The pump impeller is jammed by debris. Clean pump impeller housing.
- The wire connections in the bilge have corroded. Replace connectors and secure above the bilge waterline.
- The switch is defective. Replace the switch.
- The pump is defective. Replace pump.

The refrigerator compressor runs frequently and the house battery life seems shorter than it should be whenever the refrigerator is operating on DC power.

- The thermostat in the refrigerator is set too cold. Check the temperature in the refrigerator and set the thermostat to a warmer setting if necessary.
- The door gasket is dirty or moldy and not sealing properly. Clean or replace the door seal.
- The battery is weak and not providing the proper voltage to the refrigerator compressor. Replace the battery.
- The refrigerator is defective. Replace the refrigerator.

PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	
Head will not flush.	<ul style="list-style-type: none"> • The circuit breaker is not activated. Turn on breaker. • There is a vacuum leak at the flush valve or the waste hose. Repair the leak. • The holding tank is full and the sensor in the holding tank has deactivated the vacuum pump. Pump out the holding tank.
Head vacuum pump runs more frequently than it should.	<ul style="list-style-type: none"> • There is a slight vacuum leak in the system. Find and repair the leak.
Holding tank will not empty.	<ul style="list-style-type: none"> • Overboard discharge valve in the engine compartment is closed. Open discharge valve. • Holding tank vent is clogged. Replace charcoal vent filter. • There is a vacuum leak in the hose from the holding tank to the deck pump out fitting. Tighten loose fittings or replace damaged hoses.
Excessive odor from marine head.	<ul style="list-style-type: none"> • Back pressure in the holding tank. Pump out holding tank or replace the vent filter. • Waste is in the discharge hose. Flush enough to move waste to the holding tank, particularly at the end of each day. • No deodorizer in the holding tank. Add deodorizer to the holding tank each time it is pumped out. • The waste in the tank is over two weeks old. Pump the holding if it has contained waste for two weeks or more.
The generator will not start.	<ul style="list-style-type: none"> • The house battery switch is off. Turn on the house battery switch. • House battery is not charged. Charge or replace battery. • The generator fuel supply valve is off. Turn on fuel supply valve. • The fuel level is too low in the fuel tank that supplies the generator. Fill the fuel tanks. <p>Note: The fuel pick up tube for the generator is shorter than the main engine pick up. Therefore, the generator will run out of fuel before the boat engine. This is to prevent the generator from consuming reserve fuel.</p>
The generator runs for a short time and shuts down.	<ul style="list-style-type: none"> • There is a problem with the generator and the emergency shut down system has activated to shut down the generator. Find and correct the problem, then restart the generator. • The fuel level is too low in the fuel tank that supplies the generator. Fill the fuel tanks. • The generator is overloaded. Manage AC accessory use to reduce excess amperage draw.



MONTEREY BOATS

1579 S.W. 18th Street

Williston, FL 32696

Phone 352-529-9181 Fax 352-529-9173

www.montereyboats.com